

Laser Marking Module Series User Guide



Disclaimer Notice

© IPG Photonics Corporation 2015. All rights reserved. You may not copy, reproduce, transmit, store in a retrieval system or adapt this publication, in any form, in any media or by any means, without the prior written permission of IPG Photonics Corporation (IPG), except as allowed under applicable copyright laws. Permitted copies shall bear the same copyright and proprietary notices which were contained on the original version.

This User Guide is provided “as is” and is subject to change and revision without notice. IPG believes that the information provided is accurate and reliable; however IPG makes no warranty or representation, express or implied, regarding this document, including without limitation any implied warranties of merchantability or fitness for a particular use, purpose or application, either alone or in combination with any other device, equipment, apparatus, materials or process. Users must take full responsibility for their application of any products.

Further, IPG does not assume responsibility for use of the information contained in this document or for any infringement of patents or other rights of third parties that may result from its use. IPG shall not be liable for errors in or omissions from this document or for any incidental, consequential, indirect or special damages, including without limitation, lost profits, lost production costs or similar damages, in connection with the furnishing, performance or use of this material.

IPG grants no license, directly or indirectly, under any patent or other intellectual property rights from use of the information provided herein.

IPG, IPG Photonics and the IPG Logo are registered trademarks of IPG Photonics Corporation. IPG has identified words that are considered trademarks. Neither the presence nor absence of trademark identifications affects the legal status of any trademarks.

Patent Rights

This product is patented. See the product for more information.

US Export Control Compliance (for US products only)

IPG is committed to complying with U.S. and foreign export, import and customs requirements. Export and re-export of lasers and other products manufactured by IPG are subject to U.S. and foreign laws and regulations, including the US Export Administration Regulations administered by the Department of Commerce, Bureau of Industry and Security. The applicable restrictions vary depending on the specific product involved, intended application, the product destination and the intended user. In some cases, an individual validated export license is required from the US Department of Commerce prior to resale or re-export of certain products.

You are ultimately responsible for exporting any IPG product in accordance with the Export Administration Regulations and the U.S. Customs and Border Protection Regulations. IPG recommends that you obtain your own legal advice when attempting to export. All export and custom classifications and information provided by IPG is subject to change without notice. IPG makes no representation as to the accuracy or reliability of the classification information provided. The stated classification only applies to equipment as it left the IPG factory. Any modifications or changes after leaving the IPG facility will be your responsibility to obtain further classifications. IPG is in no way responsible for any damages whether direct, consequential, incidental, or otherwise, suffered by you as a result of using or relying upon such classifications, groups, or symbols for any purpose whatsoever.

Information relating to U.S. export rules and regulations can be found at the U.S. Bureau of Industry and Security Website. Information related to U.S. Customs and Border Protection can be found at the U.S. Customs Website.

Preface

Ensure you read and understand this guide in its entirety and familiarize yourself with the operating and maintenance instructions before you use the product. IPG strongly recommends that all operators of the product read and pay particular attention to all safety information contained herein prior to operating the product.

This guide should stay with the product to provide you and all future operators, users, and owners of the product with important operating, safety, and other information.

For technical assistance concerning the product, contact IPG Customer Service.

Audience

The audience for this guide are system integrators and technicians responsible for installing and operating the Laser Marking Module in industrial and non-industrial installations.

Contents

Preface

Audience	i-i
-----------------------	-----

1 Overview

Introduction	1-1
Additional Documentation	1-1
Applications - Industrial and General Manufacturing	1-1
Key Terms	1-1
Certification	1-2
Recommended Requirements	1-2
Safety Information and Conventions	1-3
EMC Compliance	1-4
Laser Classification	1-4
Safety Label Locations	1-5
General Safety Instructions	1-12
Specular Reflections	1-12
Equipment and Solvents	1-12
Optical Safety	1-13
Electrical Safety	1-14
Environmental Safety	1-14
Safety Features	1-15
Fiber Interlock Loop	1-15
Additional Safety Resources	1-15

2 Using the Laser Marker Module

Overview	2-1
Specifications	2-3
Unpacking Instructions	2-5
Unpacking a Unit from the Shipping Carton	2-5
Optical Scanner Head	2-7
Bolt Pattern and Field Center	2-9
Mounting the Laser Marker Module	2-10
Example of a Laser Marker Module Setup	2-11
Connecting the Cables — Laser Marking Module: XY2-100 Version ..	2-12
Connecting the Cables — Laser Marking Module: Integrated Scan	
Controller Version	2-12
Calibration Files (XY2-100 Version Only)	2-12
Laser Marking Module: XY2-100 Version — Rear Panel View	2-13
Power Supply Pinouts	2-14
Power Requirements	2-14
Laser Control Pinouts	2-18
XY2-100 Sockets	2-20
Miscellaneous Signal Sockets	2-22
RS-232 DB-9 Pinouts	2-23
Laser Marking Module: Integrated Scan Controller Version — Rear	
Panel View	2-24
Power Supply Pinouts	2-26
Power Configuration Options	2-26
37-Pin I/O Pinouts	2-30
RS-232 DB9 9-Pin Sockets	2-32

3 Installing the IPG ScanPack and WinLase 6

Overview	3-1
Requirements	3-1
Installing IPG ScanPack	3-2
Installing the WinLase 6 Software	3-9

Activating WinLase 6	3-15
Creating a License File Request	3-15
Activating WinLase 6 with a License Key	3-18
Configuring a DHCP IP Address	3-20
Installing the Scan Controller Upgrade Utility	3-24
Running the Scan Controller Upgrade Utility	3-29
4 WinLase 6 Quick Start	
Overview	4-1
Starting WinLase 6	4-2
Creating a Job	4-4
Configuring Marking Parameters	4-6
Saving a Job	4-6
Previewing a Job	4-8
Running a One-Time Job	4-8
5 Computer Interface/Commands —XY2-100 Version	
RS-232 Configuration	5-1
RS-232 Command Codes	5-1
6 Integration with a Motor or Gantry System	
Overview	6-1
Installing the Stage Configuration Utility	6-2
Running the Stage Configuration Utility	6-6
Advanced Settings	6-10
Configuring the Motor Control Interface	6-11
Scan Interface — 37-Pin Sockets	6-13
Digital I/O — 15-Pin Sockets	6-15
Motor Control I/O - P1, P2, P3	6-16
Motor Control Inputs	6-17
Fiber Interlock Inputs	6-18

PCB Configuration and Testing	6-20
SW1 and SW2 - Pushbutton Test Signals	6-20
SW3 - PIO[0], GPIO[1] Direction	6-20
SW4 - Encoder Interface Setup - SW4	6-20
A Maintenance	
Overview	A-1
B Service	
Service and Repairs	B-1
C Warranty	
Limited Express Product Warranties	C-1
Warranty Limitations	C-1
Limitation of Remedies and Liabilities	C-2
Software	C-2
Firmware License Agreement	C-2
Software License Agreement for LaserNet™	C-6
IPG Laser GmbH®	C-6
Single Use License	C-6
MICROSOFT CORPORATION EMBEDDED SOFTWARE END USER LICENSE AGREEMENT	C-10
D Product Returns	
Returns to the United States	D-1
Shipping Instructions:	D-2
Warranty Returns	D-2
Non-Warranty Returns	D-2
Returns to Germany	D-3
E Glossary	
.	E-1

Overview

Introduction

The Laser Marking Module consists of a new generation pulsed fiber laser, which is fully integrated with a two-axis scanning system. High-pulse energy of the YLP-Series laser combined with the fast and accurate positioning of the scanning sub-module provide high-marking speeds.

The Laser Marking Module also includes control electronics and scanning optics. This complete module comes fully optimized, pre-calibrated, and designed to help integrators enhance their laser marking products.

The Laser Marking Module also lets you use industry standard command inputs for use with your own scan controller and marking software.

There are two versions of the Laser Marker Module covered in this guide:

- Laser Marker Module XY2-100
- Laser Marker Module with Integrated Scan Controller

Additional Documentation

Refer to the following documentation included with the product:

- *Specification Ytterbium Pulsed Fiber Laser - YLP-V2 1mJ series*
- *YLP-Series Pulsed Fiber Laser User Guide*

Applications - Industrial and General Manufacturing

Varieties of Materials: Stainless Steel, Aluminum, Brass, Nickel Alloy, Silver and many others.

Key Terms

- **Laser Source** — responsible for generating the laser beam.
- **Scan Head** — deflects a laser beam using galvo-controlled mirrors through a scanning lens.
- **Laser Marking** — delivers and focuses a laser beam on a target surface.

Certification

IPG certifies that the Laser Marking Module is thoroughly tested and inspected, and meets published specifications prior to shipping.

Upon receiving your shipment, check the packaging for any possible damage that could have occurred in transit. If damage is apparent, contact IPG immediately.

This product does not comply with IEC 60825, 21 CFR 1040.10 and/or 1040.11. For use as a system component only. It is the responsibility of the purchaser/end-user to bring the end system into full compliance with all applicable regulations.

Recommended Requirements

IPG Photonics recommends the following additional requirements for your Laser Marker system:

- Safety Switch
- Z Stage Positioner to hold Optical Scanner Head
- Fume Extraction System to remove gases and particles released during the laser marking process.




Safety Information and Conventions

To ensure the safe operation and optimal performance of the product, follow all warnings in this guide. Safety precautions must be observed during all phases of operation, maintenance, and service.

Operators must adhere to these recommendations and to apply sound laser safety practices at all times. Never open the chassis. There are no user serviceable parts, equipment or assemblies associated with this product. All internal service and maintenance should only be performed by qualified IPG personnel.

Table 1-1 lists safety conventions and their meanings. These conventions are used throughout this guide.

Table 1-1. Safety Symbols

Symbol	Description
 Electrical	<p>Text marked with an Electrical Warning symbol or Laser Warning symbol refers to a potential personal hazard. It requires a procedure that, if not correctly followed, can result in bodily harm to you or others.</p> <p>Do not proceed beyond the Electrical Warning or Laser Warning symbols until you completely understand and meet the required conditions.</p>
 Laser	
	<p>Text marked with a Caution symbol refers to a potential product hazard. It requires a procedure that, if not correctly followed, can result in damage or destruction to the product or components.</p> <p>Do not proceed beyond the Caution symbol until you completely understand and meet the required conditions.</p>
No symbol	<p>Text marked with Important refers to pertinent information regarding the operation of the product. Ensure you do not overlook this information.</p>

EMC Compliance

The YLP-Series lasers are components and should be integrated into finished system. The EMC (CE mark relevant) standards are not applicable to the laser modules, however applicable to the complete systems. The system integrator is responsible to comply with all applicable standards to the final laser system.

Results of IPG testing program have demonstrated possibility to build a CE compliant laser system with an integrated YLP-series laser module.

Laser Classification

This device is classified as a high power Class IV laser product under 21 CFR 1040.10. This product emits invisible laser radiation at or around a wavelength of 1062 nm, and the total light energy radiated from the optical output is up to 110W Average. This level of light can cause damage to the eye and skin. Despite the radiation being invisible, the beam can cause irreversible damage to the cornea. Laser safety eyewear is not provided with this product, but must be worn at all times while the laser is operational.



WARNING: Use appropriate laser safety eyewear when operating this device. The selection of appropriate laser safety eyewear requires the end user to accurately identify the range of wavelengths emitted from this product. If the device is a tunable laser or Raman product, it emits light over a range of wavelengths and the end user should confirm the laser safety eyewear used protects against light emitted by the device over its entire range of wavelengths.



WARNING: Use of controls or adjustments or performance of procedures other than those set forth in this guide can result in hazardous radiation exposure.



WARNING: The red guide laser can be installed in the module. It can emit up to 1mW average power near 660nm wavelength and is classified as class 2m visible laser radiation in terms of IEC 60825-1:2007. Avoid direct eye exposure.



CAUTION: Do not attempt to install or terminate fibers to the Laser Marking Module when laser is active.

Safety Label Locations

Figure 1-1 shows the required laser safety labels and the locations on the device. These include warning labels indicating removable or displaceable protective housings, apertures through which laser radiation is emitted and labels of certification and identification.

Figure 1-1. Safety Label Locations — Laser Marker Module




Figure 1-2. Safety Label Locations — Optical Scanner Head









Table 1-2 on page 1-7 provides the safety label descriptions.



Table 1-2. Safety Label Descriptions

Item	Label Name	Description
1	Optical Properties Po is average power. Pp is peak power.	
2	Certification Label	<p style="text-align: center;">THIS PRODUCT DOES NOT COMPLY WITH IEC 60825, 21 CFR 1040.10 AND 1040.11 FOR USE AS A SYSTEM COMPONENT ONLY</p>
3	Laser Radiation Hazard Label	





Overview



Safety Information and Conventions

4	Class 4 Laser Product (Model YLP Series)	 <p>VISIBLE AND/OR INVISIBLE LASER RADIATION CLASS 4 LASER PRODUCT</p> <p>DANGER CLASS 4 LASER RADIATION WHEN OPEN</p> <p>AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION</p> <p>Per IEC 60825-1:2014; 21 CFR 1040: 10(g)</p>
5	Laser Product	 <p>MAX. AVERAGE OUTPUT POWER: 1mW WAVELENGTH RANGE: 600-700nm VISIBLE LASER RADIATION DO NOT STARE INTO THE BEAM OR VIEW DIRECTLY WITH OPTICAL INSTRUMENTS CLASS 2M LASER PRODUCT</p> <p>Per IEC 60825-1:2014; 21 CFR 1040: 10(g)</p>
6	Aperture Label Location	 <p>AVOID EXPOSURE - VISIBLE AND/OR INVISIBLE LASER RADIATION IS EMITTED FROM THIS APERTURE</p> <p>Per IEC 60825-1:2014; 21 CFR 1040: 10(g)</p>

	<p>Class 4 Laser Product (Model YLP Series)</p>	 <p>The label features a red oval with the word "DANGER" in white. Below it is a red sunburst symbol. To the right of the symbol, the text reads: "INVISIBLE LASER RADIATION AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION". A horizontal line separates this from the technical specifications: "MAXIMUM OUTPUT: 110 W Average, 100 kW Peak", "PULSE DURATION: 1-1000 ns", "WAVELENGTH: 1000-1200 nm", and "CLASS IV LASER PRODUCT".</p>
	<p>Identification Plate (Products Made in the United States)</p>	 <p>The plate includes a QR code, the part number "PD038135", and the manufacturer "IPG Photonics Corporation" with address "50 Old Webster Rd, Oxford, MA 01540". It also shows the date of manufacture "DOM:04/08/2015" and "MADE IN USA". The model is "YLP-1/100/20/20-HC" and the serial number is "SN: PL1519427". A barcode is located below the model name.</p>
	<p>Identification Plate (Products Made in Germany)</p>	 <p>The plate features the "IPG LASER" logo and manufacturer information: "IPG Laser GmbH, Siemensstrasse 7, D-57299 Burbach, Made in Germany". It lists the model name "YLP-V2-0.5-100-100-50-DC", serial number "13051434", date of manufacture "May, 2013", and supply specifications "24 VDC, max 11 A".</p>

Overview
 Safety Information and Conventions

	<p>Identification Plate (Products Made in Russia)</p>	
	<p>Optical Scanner Head Aperture Label</p>	
	<p>Optical Scanner Head Caution Label — Class 4</p>	
	<p>Warranty Void Sticker</p>	

	<p>Caution Label - consult accompanying documentation.</p>	
	<p>Functional Earth Label</p>	

General Safety Instructions



WARNING: You must exercise caution to avoid and minimize specular reflections as these reflections occur at the laser's wavelength and are invisible.

Specular Reflections

Often there can be numerous secondary laser beams produced at various angles near the laser aperture. These beams are called “Specular Reflections” and are produced when the laser light reflects off a surface where the primary beam is incident.

Although these secondary beams can be less powerful than the total power emitted from the laser, the intensity can be great enough to cause damage to the eyes and skin as well as materials surrounding the laser.



WARNING: The laser light is strong enough to cut or weld metal, burn skin, clothing, and paint. In addition, this light can ignite volatile substances such as alcohol, gasoline, ether, and other solvents. Exposure to solvents or other flammable materials and gases must be avoided and must be relocated away from this device.



Equipment and Solvents

Light-sensitive elements in equipment, such as video cameras, photomultipliers, and photodiodes can also be damaged from exposure to the laser light.

The laser light is strong enough to cut or weld metal, burn skin, clothing, and paint. In addition, this light can ignite volatile substances such as alcohol, gasoline, ether and other solvents.

Exposure to solvents or other flammable materials and gases must be avoided and must be relocated away from the device.

Optical Safety



CAUTION: Never look directly into a live fiber or collimator and make sure that you wear appropriate laser safety eyewear at all times while operating the product.

Never look into the scanner head when power is on.

Do not stare into the beam of view directly with optical instruments.

If the output of the device is delivered through a lens with an anti-reflection coating, ensure that the lens is of good quality and clean. Hot or molten pieces of metal might be present where the laser beam is emitted in the end application. Exercise caution if debris is being generated in your application.

Hot or molten pieces of metal can be present when using this laser. Exercise caution if debris is being generated in your application.

Do not exceed the maximum specified optical input for the Laser Marker Module.

Ensure all electrical and optical connections are connected to the correct locations. Ensure work cell electrical connections and workcell optical connections are matched properly.

Proper enclosures must be used to secure a laser safe work area. This includes but is not limited to laser safety signs, interlocks, appropriate warning devices and training/safety procedures. In addition, it is important to install the output assembly away from eye level.

The interaction between the laser and the material being processed can also generate high intensity UV and visible radiation. Ensure that all laser enclosures are in place to prevent eye and skin exposure to visible and invisible collateral radiation.

Electrical Safety



WARNING: Ensure the device is properly grounded through a low impedance functional earth conductor.

To ensure electrical safety:

1. Always use your device in conjunction with properly grounded power source.
2. Before supplying the power to the product, make sure that the correct voltage of the DC power source is used. Failure to use the correct voltage could cause damage to the product.
3. Before switching the power on, ensure the voltage corresponds to the specified level.
4. There are no operator serviceable parts inside. Do not attempt replacement of any parts. Refer all servicing to qualified IPG personnel. Do not remove covers. Any tampering with the product might void the warranty.
5. Connections to external circuits except for Mains connections: the external connections between this product and other external devices are PELV (Protected Extra-Low Voltage) as defined by IEC 61140. Non-Mains outputs of other devices connected to this product should also be PELV or SELV (Safety Extra-Low Voltage).
6. Keep away from sources of shock or vibrations.

Environmental Safety



WARNING: Ensure that all personal protective equipment (PPE) is suitable for the output power and wavelength range listed on the laser safety labels that are affixed to the laser.



CAUTION: Damage to the laser is possible, unless caution is employed in operating the device.

IPG provides the following recommendations to promote the long life of the Laser Marker Module:

- Do not expose the device to a high moisture environment (>95% humidity).

- Ensure that the work area is properly vented. Gases, sparks and debris that can be generated from interaction between the laser and the work surface can pose additional safety hazards.

Safety Features



Fiber Interlock Loop

A Fiber Interlock Loop is connected between the laser module and the optical head. Two relay outputs are available at the customer interface indicating the status of this interlock. These signals are provide for integrating into the customers safety electronics.

Additional Safety Resources

For additional information regarding Laser Safety, refer to the following list:

Laser Institute of America (LIA)

13501 Ingenuity Drive, Suite 128
Orlando, Florida 32826
Phone: 407.380.1553, Fax: 407.380.5588
Toll Free: 1.800.34.LASER

American National Standards Institute

ANSI Z136.1, American National Standard for the Safe Use of Lasers
(Available through LIA)

International Electro-technical Commission

IEC 60825-1, Edition 2
Safety of laser products -
Part 1: Equipment classification, requirements and user's guide.
(Available through LIA)

Center for Devices and Radiological Health

21 CFR 1040.10 - Performance Standards for Light-Emitting Products
US Department of Labor - OSHA
Publication 8-1.7 - Guidelines for Laser Safety and Hazard Assessment

Overview

Additional Safety Resources

US Department of Labor - OSHA

Publication 8-1.7 - Guidelines for Laser Safety and Hazard Assessment

Laser Safety Equipment

Laurin Publishing

Laser safety equipment and Buyer's Guides

Note

IPG Photonics recommends that the user of this product investigate any local, state or country requirements as well as facility or building requirements that might apply to installing or using a laser or laser device.

Ensure that the standard you are using such as ANSI, IEC, and OSHA are current.

Using the Laser Marker Module

Overview

The Laser Marker Module consists of a laser device connected to an optical head by a flexible cord. Components are located in the base enclosure with the laser board, laser diodes, and optical scanner.

Figure 2-1 illustrates the Laser Marker Module, XY2-100 Version architecture.

Figure 2-1. Laser Marker Module Architecture





Figure 2-2 illustrates the Laser Marker Module with Integrated Scan Controller Version architecture.

Figure 2-2. Laser Marker Module Scan Controller Architecture



The Scan Controller interfaces between a software dll on a PC, servo drivers, stages, encoders, lasers, and any other external systems. When used with external stages, the Scan Controller can monitor the stage location and output the image objects when the correct workspace location is in view, or control external stages.

Specifications

Table 2-1 and Table 2-2 list the specifications for the Laser Marking Module and the Optical Scanner Head.

Table 2-1. Laser Marker Module Specifications

Average Output Power	10W	20W	30W	50W
Mode of Operation	Pulsed			
Polarization	Random			
Maximum Pulse Energy	1 mJ			
Nominal Average Output Power (in watts)				
Minimum	9.5	19	28	47
Typical	10	20	30	50
Maximum	11	21	32	53
Output Power Adjustment Range	10 - 100 %			
Nominal Power Adjustment Range	10W	20W	30W	50W
Pulse Duration $\Delta\tau$				
Minimum	80 ns			
Typical	100 ns			
Maximum	120 ns			
Central Emission Wavelength	1064 nm			
Pulse Repetition Rate	2 - 200 kHz			
Laser Switching On/Off Time	2 - 3 μ s			

Table 2-2. Optical Scanner Head Specifications

Unit	Description
Clear Aperture	12 mm
Square Field Size Options	60 mm (100 mm working distance) 110 mm (163 mm working distance) 170 mm (254 mm working distance)
Tracking Delay	100 μ sec
Protection Class (Process Unit)	IP67
Weight (Process Unit)	9 lbs.

Unpacking Instructions

Note

If the packaging shows any signs of external damage, check unit for damages and notify the shipping agent immediately.

Particular care must be taken when you remove the unit from the shipping carton to ensure that the fiber optic cord is not broken or damaged.




CAUTION: To minimize the risk of damage to the device, IPG Photonics recommends that you unpack your Laser Marker Module and Optical Scanner using the following procedure.

Unpacking a Unit from the Shipping Carton

To unpack your unit from the shipping carton:

1. Place the package on a stable surface such as the floor or a large table.
2. Open the carton and remove the foam cover and store for later use.
3. Carefully lift the Laser Marker Module and Optical Scanner Head out of the box. The flexible yellow cord is already connected to the Optical Scanner Head. IPG strongly recommends two people to lift the unit to avoid damaging the fibers in the flexible yellow scanner cord.
4. Carefully place contents on a stable surface.
5. Remove the cover from the Optical Scanner Head before use. Store for later use if needed.
6. If you have the XY2-100 version, remove the USB memory stick and store it in safe place. Calibration files for third-part controllers are stored in the USB memory stick. See “Calibration Files (XY2-100 Version Only)” on page 2-12 for instructions.

Figure 2-3. Optical Scanner Head with Cover



7. Retain all packaging for future transportation or storage needs.

Optical Scanner Head

The Optical Scanner Head connects to the optical outlet with a flexible yellow cord. The cord is connected prior to shipment.

Figure 2-4. Optical Scanner Head




The Optical Scanner Head has the following features:

- 2D Factory Calibrated Marker
- 12mm CA Optics
- Optional Focus Laser
- IP67 Head Enclosure

Figure 2-5 illustrates the available configurations for the optical scanner head.

Figure 2-5. Optical Scanner Head Configurations



The Optical Scanner Head includes three lens options as listed in Table 2-3.

Table 2-3. Specifications for Three Lens Options

Item	Len 1	Len 2	Len 3
Focal Length (mm)	100	163	254
Spot Size @ 1/e2 (mm)	11	25	40
Working Distance (mm)	102	189	289
Field Size (mm)	60 x 60	110 x 110	170 x 170

Note

Working distances are taken from the edge of the lens housing.

Bolt Pattern and Field Center

The bolt pattern and field center diagrams are shown in Figure 2-6 (horizontal configuration) and Figure 2-7 (vertical configuration).

Figure 2-6. Scanner Head Diagram - Horizontal Configuration





Figure 2-7. Scanner Head Diagram - Vertical Configuration




Mounting the Laser Marker Module

You can mount the Laser Marker Module to a base plate using the four holes in the housing. The output head should be clamped to the mounting surface.

Example of a Laser Marker Module Setup

Table 2-8 illustrates the Laser Marker Module bolted on a platform with the lens working distance, marking surface, and field size.

Figure 2-8. Laser Marker Module Setup



Connecting the Cables — Laser Marking Module: XY2-100 Version

IPG does not include cables in the shipment of the Laser Marker Module. You are responsible for providing your own cable connectors. Contact IPG Customer support if you need assistance.

See “Laser Marking Module: XY2-100 Version — Rear Panel View” on page 2-13 for details on the rear panel.

To connect the cables to the Laser Marker Module XY2-100:

1. Connect a 5-pin female cable to the 5-pin male Power Supply.
2. Connect a 25-pin female cable to the 25-pin male Laser Control interface.
3. Connect a 25-pin male cable to the 25-pin female XY2-100 interface.
4. Connect a 9-pin female cable to the 9-pin male RS-232 interface.

Connecting the Cables — Laser Marking Module: Integrated Scan Controller Version

See “Laser Marking Module: Integrated Scan Controller Version — Rear Panel View” on page 2-24 for details on the rear panel.

To connect the cables to the Laser Marker Module with the Integration Scan Controller:

1. Connect a 5-pin female cable to the 5-pin male Power Supply.
2. Connect an Ethernet cable to the Ethernet interface.
3. Optionally, connect a 37-pin female cable to the 37-pin male D connector.
4. Connect a 9-pin male to the 9-pin female RS-232 DB9 sockets.

Calibration Files (XY2-100 Version Only)

Calibration files for both the main laser and the guide laser in .cbt format are included on the USB memory stick included with your shipment. If you are using a third-party controller, you need to load these configuration to your system.

Laser Marking Module: XY2-100 Version — Rear Panel View

Figure 2-9 shows the rear panel of the Laser Marking Module. Table 2-4 provides details on each component.

Figure 2-9. Laser Marking Module - Rear Panel




Table 2-4. Rear Panel Descriptions

Item	Component	Description
1	5-pin Male Power Supply	DB 5W5 connector used as the main power supply for the Laser Marking Module.
2	25-pin Male Laser Control	Connector used to control the laser.
3	25-pin Female XY2-100 Sockets	XY2-100 D connector used to control the galvanometers.
4	9-pin Male RS-232	Controls the laser via a RS-232 port.
5	9-pin Female Sockets	D connector for miscellaneous signals.
6	Optical Output	Connects to the optical scanning head by a flexible cord.

Power Supply Pinouts

Figure 2-10 illustrates the male DB 5W5 5-pin Power Supply pinouts.

Figure 2-10. Power Supply Pinouts




Table 2-5 lists details for the Power Supply pinouts.

Table 2-5. Power Supply Pinout Functions

Pin	Function	Description
A5	-V Scanner	Isolated Scanner Power (+V)-(-V) = 24V to 30V
A4	+V Scanner	
A3	Return	Return For HK and Laser Power. Laser Control and XY2-100 Interface Reference
A2	+V LaserHK	House Keeping Power 24V
A1	+V LaserPower	Laser Diode Power 24V

Power Requirements

Table 2-6. Power Requirements

Type	Description
Scanner Power	24-30V +/-5% @ 10Amp Peak/2 Amp Average
Laser HK Power*	24V +/-5% @ < 1 Amp
Laser Power*	24V +/-5% @ Max Laser Power Watts / (6 Volts)
Laser Power	10W = 1.7 amps 20W = 3.3 amps 30W = 5 amps 50W = 8.3 amps

*Maximum values.

Table 2-7. Power Supply Options

Wiring Options	Pin	Voltage
Split Supply: +/-15 Volt Supply for scanner (10Amp Peak / 2Amp RMS) 24V Supply for laser (8 Amp RMS for 50W laser)	A5	-15V
	A4	+15V
	A3	RET
	A2	+24V
	A1	+24V Safety Switched
Single Supply: 24V Supply for laser and scanner (18Amp Peak / 10Amp RMS)	A5	RET
	A4	+24V
	A3	RET
	A2	+24V
	A1	+24V Safety Switched

Figure 2-11 on page 2-16 shows a split-supply operation for the XY2-100 Version.

Figure 2-12 on page 2-17 shows a single-supply operation for the XY2-100 Version.

Figure 2-11. Split-Supply Operation: XY2-100





Figure 2-12. Single-Supply Operation: XY2-100



Laser Control Pinouts

Figure 2-13 illustrates the 25-pin Laser Control pinouts.

Figure 2-13. Laser Control Pinouts




Table 2-8 lists details for the Laser Control pinouts.

Table 2-8. Laser Control Pinout Descriptions

Socket	Description
1	D0
2	D1
3	D2
4	D3
5	D4
6	D5
7	D6
8	D7
9	Latch
10	Auxin1
11	Alarm2
12	Alarm3
13	Auxin2
14	Gnd
15	5V_Aux_Out
16	Alarm1

Using the Laser Marker Module
Laser Marking Module: XY2-100 Version — Rear Panel View

Socket	Description
17	Gl_Pwr
18	Mo_On
19	Pa_On
20	Sync
21	Alarm0
22	Gl_On
23	Emer_Off
24	Auxin3
25	Auxin4

Using the Laser Marker Module

Laser Marking Module: XY2-100 Version — Rear Panel View

XY2-100 Sockets

Figure 2-14 illustrates the 25-pin female XY2-100 sockets, which are used for control and status of the galvanometers.

Figure 2-14. XY2-100 Sockets




Table 2-8 lists provides details for the XY2-100 sockets.

Table 2-9. XY2-100 Socket Descriptions

Socket	Name	I/O	Description
1	CK-	O	2Mhz Clock
14	CK+	O	
2	SYNC-	O	Sync Signal
15	SYNC+	O	
3	XD-	O	X Channel Data
16	XD+	O	
4	YD-	O	Y Channel Data
17	YD+	O	
5	ZD-	O	Z Channel Data (if Z axis is present)
18	ZD+	O	
6	STAT-	I	XYZ-100 Status Word
19	STAT+	I	
7	NC	-	No Connect
20	NC	-	
8	NC	-	

Using the Laser Marker Module
Laser Marking Module: XY2-100 Version — Rear Panel View

Socket	Name	I/O	Description
21	NC	I	No Connect
9	+V Servo	PWR	Positive Power Supply for galvanometers. 24-30V referenced to -V Servo. Connected to A4.
22	+V Servo		
10	+V Servo		
23	GND	PWR	GND Reference for pins 1-6 and 14-19.
11	GND		
24	GND		
12	-V Servo	PWR	Negative Power Supply Return for galvanometers. Connected to A5.
13	-V Servo		
25	-V Servo		

Miscellaneous Signal Sockets

Figure 2-15 illustrates the 9-pin female sockets.

Figure 2-15. 9-Pin Female Signal Sockets




Table 2-10 lists provides details for the 9-pin female pinouts.

Table 2-10. 9-Pin Socket Descriptions

Socket	Name	Description
1	A1	Reserved
2	B1	Reserved
3	GL_ON	Reserved
4	FL_ON	Reserved
5	NC	Reserved
6	A2	Reserved
7	B2	Reserved
8, 9	GND	Reserved

Note: Do not connect to “Reserved”

RS-232 DB-9 Pinouts

Figure 2-16 illustrates the 9-pin male RS-232 DB9 pinouts.

Figure 2-16. 9-Pin Male Pinouts




Table 2-11 lists provides details for the RS-232 DB9 pinouts.

Table 2-11. 9-Pin Pinout Descriptions

Socket	Description
1	Reserved - Do not connect
2	RX Input - Receive
3	TX Output - Transmit
4	Reserved - Do not connect
5	Common
6, 7, 8, 9	Reserved - Do not connect

Laser Marking Module: Integrated Scan Controller Version — Rear Panel View

Figure 2-17 shows the rear panel of the Laser Marking Module with Integrated Scan Controller. Table 2-12 provides details on each component.

Figure 2-17. Laser Marker Module - Rear Panel




Table 2-12. Rear Panel Descriptions

Item	Component	Description
1	5-pin Male Power Supply	DB 5W5 connector used as the main power supply for the Laser Marking Module.
2	Ethernet Interface	<p>Communication from the IPG ScanPack .dll and system console is performed over Ethernet.</p> <p>Configure an Ethernet connection for DHCP. For optimal results, IPG recommends you use a direct Ethernet connection (capable of 100Mbit/s) directly from the PC to the Scan Controller.</p> <p>To change an IP Address to static, run the IPG Scan Controller Upgrade Utility. See “Installing the Scan Controller Upgrade Utility” on page 3-24 for details.</p>

Item	Component	Description
3	37-pin Male D Connector	(Optional) Used for external interface to external controllers, encoders, and safety logic.
4	9-pin Female DB9 RS-232	The RS-232 port can be used as a system console to set up IP addresses.
5	Optical Output	Connects to the optical scanning head by a flexible cord.

Power Supply Pinouts

Figure 2-18 illustrates the male DB 5W5 5-pin Power Supply pinouts.

Figure 2-18. Power Supply Pinouts




Table 2-13 lists details for the Power Supply pinouts.

Table 2-13. Power Supply Pinout Functions

Pin	Function
A5	-V Servo
A4	+V Servo
A3	GND Laser
A2	+V LaserAux
A1	+V LaserPower

Power Configuration Options

Table 2-14 lists details for the Power configuration options.

Table 2-14. Power Supply Options

Wiring Options	Pin	Voltage
Split Supply: +/-15 Volt Supply for scanner 24V Supply for laser	A5	-15V
	A4	+15V
	A3	GND
	A2	+24V
	A1	+24V Safety Switched

Single 24V Supply for laser and scanner	A5	GND
	A4	+24V
	A3	GND
	A2	+24V
	A1	+24V Safety Switched

Figure 2-19 on page 2-28 shows a split-supply operation for the Integrated Scan Controller Version.

Figure 2-20 on page 2-29 shows a single-supply operation for the Integrated Scan Controller Version.

Using the Laser Marker Module

Laser Marking Module: Integrated Scan Controller Version — Rear Panel View

Figure 2-19. Split-Supply Operation: Integrated Scan Controller





Figure 2-20. Single-Supply Operation: Integrated Scan Controller



37-Pin I/O Pinouts

Figure 2-21 illustrates the 37-pin I/O pinouts.

Figure 2-21. 37-Pin I/O Pinouts




Table 2-15 lists details for the 37-pin I/O pinouts.

Table 2-15. 37-Pin I/O Pinout Descriptions

Pin	Name	I/O	Description
1	Active	Out	Mark in Progress
20	GND	3VTTL	
2	Ready	Out	Ready/Waiting Signal
21	GND	3VTTL	
3	Error	Out	Error Condition
22	GND	3VTTL	
4	Start	In	Start Signal Input
23	GND	3VTTL	Pulled up to 3.3V
5	Stop	In	Stop Signal Input Active Low
24	GND	3VTTL	Pulled up to 3.3V
6	GPIO[0]	In/Out	General Purpose Input/Output for Synchronization
25	GND	3VTTL	Pulled up to 3.3V
7	GPIO[1]	In/Out	General Purpose Input/Output for Synchronization
26	GND	3VTTL	Pulled up to 3.3V
8	A_Axis_A+	In/Out	Axis A Phase A
27	A_Axis_A-	RS-422	

Using the Laser Marker Module
 Laser Marking Module: Integrated Scan Controller Version — Rear Panel View

9	A_Axis_B+	In/Out	Axis A Phase B
28	A_Axis_B-	RS-422	
10	A_Axis_Z+	In	Axis A Phase Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V)
29	A_Axis_Z-	RS-422	
11	B_Axis_A+	In/Out	Axis B Phase A
30	B_Axis_A-	RS-422	
12	B_Axis_B+	In/Out	Axis B Phase B
31	B_Axis_B-	RS-422	
13	B_Axis_Z+	In	Axis B Phase Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V)
32	B_Axis_Z-	RS-422 or 3VTTL	
14	C_Axis_A+	In/Out	Axis C Phase A
33	C_Axis_A-	RS-422	
15	C_Axis_B+	In/Out	Axis C Phase B
34	C_Axis_B-	RS-422	
16	C_Axis_Z+	In/Out	Axis C Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V) or ClkIn/ClkOut Differential for Synchronization to laser.
35	C_Axis_Z-	RS-422 or 3VTTL	
17	FiberInterlockA0	Out Relay	FiberInterlock is safe when 1 is connected to 0.
36	FiberInterlockA1		
18	FiberInterlockB0	Out Relay	FiberInterlock is safe when 1 is connected to 0.
37	FiberInterlockB1		
19	GND	Out	Logic Ground

RS-232 DB9 9-Pin Sockets

Figure 2-22 illustrates the 9-pin female RS-232 DB9 sockets.

Figure 2-22. 9-Pin Female Sockets



Table 2-16 lists provides details for the RS-232 DB9 sockets.

Table 2-16. 9-Pin Socket Descriptions

Socket	Description
1	Reserved - Do not connect
2	Receive Data Output
3	Transmit Data Input
4	Reserved - Do not connect
5	GND
6	Data Set Ready Internally Connected to Pin 4 Data Terminal Ready
7	Request to Send Internally Connected to Pin 8 Clear to Send
8, 9	Reserved - Do not connect

Installing the IPG ScanPack and WinLase 6

Overview

This chapter explains how to install IPG ScanPack and the WinLase 6 laser marking software on your system for use with the Laser Marker Module with the Integrated Scan Controller. It also explains how to activate the WinLase 6 program and configure a LAN connection over Ethernet.

Requirements

The following requirements are necessary:

- Windows 7 or 8 Operating System
- IPG Laser Marker Module with Integrated Scan Controller
- IPG ScanPack software
- WinLase 6 software
- WinLase 6 licensing key for product activation

Installing IPG ScanPack

You need to install IPG ScanPack to use the WinLase 6 program with the Laser Marker Module with the Integrated Scan Controller.


ScanPack is a .dll file in which WinLase 6 interfaces for communicating with your Scan Controller over Ethernet. The ScanPack installation program installs Bonjour (a protocol that discovers IP addresses over the network), Microsoft Visual C++ Runtime Libraries, and the ScanPack dll on your system.

Before installing ScanPack, uninstall any previous versions of ScanPack, if applicable.

To install IPG ScanPack:


1. Open a web browser and go to **software.ipgphotonics.com**.
2. Click the Marker folder.
3. Click the ScanPack folder.
4. Download the ScanPack.zip file to your computer.
5. Once downloaded, extract the ScanPack.zip file. A folder called ScanPack is created.
6. Open the folder and run **setup.exe** and click **Next**. The Bonjour Installer appears as shown in Figure 3-1.

Figure 3-1. Bonjour Installer




7. Click **Accept** to accept the license agreement. The following dialog box appears as shown in Figure 3-2.

Figure 3-2. Visual C++ 2010 Runtime Libraries Installation




8. Click **Install** to installation Visual C++ 2010 Runtime Libraries to your system. The following status message appears.

Figure 3-3. Status Message




Next, the Microsoft Visual C++ 2010 x86 Redistributable Setup window appears as shown in Figure 3-4.

Figure 3-4. Microsoft Visual C++ 2010 x86 Redistributable Setup




9. Click **I have read and accept the license terms** and click **Install**. The following window appears with the Microsoft Visual C++ 2010 x86 Redistributable installation progress as shown in Figure 3-5.

Figure 3-5. Installation Progress Window




Next, the Installation is Complete window appears as shown in Figure 3-6.

Figure 3-6. Installation Is Complete




10. Click **Finish**. The ScanPack Setup Wizard appears as shown in Figure 3-7.

Figure 3-7. ScanPack Setup Wizard




11. Click **Next** to proceed. The Select Installation Folder window appears as shown in Figure 3-8.

Figure 3-8. ScanPack Setup - Select Installation Folder




12. Click **Next** to accept the default Start Menu folder.
 - a. Click **Browse** if you want to change the default Start menu to another location.
 - b. Click **Everyone** to allow all users to have access to the ScanPack dll or **Just me** if only you want access.
13. Click **Next** to begin the installation. The Installation Progress window appears as shown in Figure 3-13.

Figure 3-9. Installing ScanPack



14. Click **Next** to proceed. The Installation Complete window appears as shown in Figure 3-10.

Figure 3-10. Installation Complete



15. Click **Close** to exit the program. ScanPack is successfully installed on your system.

Installing the WinLase 6 Software

The WinLase 6 program is only compatible with the Laser Marker Module — Integrated Scan Controller version.


Before installing the WinLase 6 software, you need to uninstall any previous versions of WinLase 6, if applicable. You also need to first install IPG ScanPack as explained in “Installing IPG ScanPack” on page 3-2.

With WinLase 6, you can edit nodes and vectors and change properties without using an external graphics software package. You can also keep multiple instances of the software open for side-by-side editing of jobs.

To install the WinLase 6 software:


1. Open a web browser and go to **software.ipgphotonics.com**.
2. Click the Marker folder.
3. Click the WinLase6 folder.
4. Download the WinLase6.zip file to your computer.
5. Once downloaded, extract the WinLase 6.zip file. A folder called WinLase6 is created.
6. Open the folder and run **setup.exe**. The WinLase 6 Setup Wizard appears as shown in Figure 3-11.

Figure 3-11. WinLase 6 Setup Wizard




7. Click **Next**. The Select Installation Folder window appears as shown in Figure 3-12.

Figure 3-12. WinLase 6 Setup - Select Installation Folder



8. Click **Next** to accept the default Start Menu folder.
 - a. Click **Browse** if you want to change the default Start menu to another location.
 - b. Click **Everyone** to allow all users to access the WinLase 6 program or **Just me** if only you want access.
9. Click **Next**. The Confirm Installation window appears as shown in Figure 3-13.

Figure 3-13. WinLase 6 Setup - Confirm Installation




10. Click **Next** to proceed. The License Agreement window appears as shown in Figure 3-14.

Figure 3-14. WinLase 6 Setup - License Agreement




11. Click **I Agree** to accept the License Agreement.
12. Click **Next** to proceed. The Installing WinLase 6 window appears as shown in Figure 3-15.

Figure 3-15. WinLase 6 Setup - Installing WinLase 6



13. Once installation is complete, the Installation Complete window appears as shown in Figure 3-16.

Figure 3-16. WinLase 6 Setup - Installation Complete



14. Click **Close** to exit the window. WinLase 6 is successfully installed on your system.
15. See “Activating WinLase 6” on page 3-15 to activate the WinLase 6 program using the license key provided by IPG Photonics.

Note

You cannot use WinLase 6 without activating it with a valid license key.

Activating WinLase 6

This section explains how to:


- Create a license file request.
- Emailing the license file request to IPG Photonics for obtaining a license key.
- Activating WinLase 6 on your computer.

Creating a License File Request

To create a license file request:


1. Open the WinLase 6 program. A message displays prompting you for a license key to use the product.
2. Click **Cancel** to proceed.
3. Select **Software Activation** from the **Help** menu. The Software Activation Wizard appears as shown in Figure 3-17.

Figure 3-17. Software Activation Wizard




4. Click **Next** to continue. The following window appears as shown in Figure 3-18.

Figure 3-18. Activate Software on This Computer




5. Click **Activate software on this computer** and click **Next** to continue.
The Select Activation Method window appears as shown in Figure 3-19.

Figure 3-19. Select Activation Method




6. Click **Create license request file** and click **Next**. The Create License Request File appears as shown in Figure 3-20.

Figure 3-20. Create License Request File



7. Save the file with the serial number of the laser to a location on your computer. For example, 15041235.WibuCmRaC.
8. Click **Next** to continue. The following confirmation message appears as shown in Figure 3-21.

Figure 3-21. License Request Complete




9. Click **Done** to exit WinLase 6.
10. Email the license request file from the saved location to IPG Photonics at:
marker@ipgphotonics.com
11. Enter “**Winlase6 License Request**” in the subject line of the email.
IPG Photonics emails you the license file once your email is received. The license key is valid for one activation only (one user).

Activating WinLase 6 with a License Key

To activate WinLase 6 with a license key:


1. Once you receive the license file from IPG Photonics, follow steps 1 to 5 in “Creating a License File Request” on page 3-15.
2. Click **Import license file**.

Figure 3-22. Software Activation Wizard - Import License File



3. Click **Next** to continue. The following window appears as show in Figure 3-23.

Figure 3-23. Import License File From Saved Location



4. Import the license file to the computer where you generated the request for the license.

Note

Once the file is activated on your computer, it cannot be used on another computer.

5. Click **Next** to continue. A message appears confirming that the WinLase 6 activation was successful.
6. Click **Done** to exit the window. WinLase 6 is activated and ready for use on your computer.
7. See “WinLase 6 Quick Start” on page 4-1 for step-by-step instructions for creating and running a laser marker job.

Configuring a DHCP IP Address

This section explains how to configure a DHCP IP address, which is necessary for use with WinLase 6 marking software with the Laser Marker Module — Scan Controller version.

For optimal configuration, IPG recommends that you use an Ethernet connection (capable of 100Mbit/s) directly from the host PC to the Laser Marker with the Integrated Scan Controller.


Note

If you want to configure a static IP address, you need to run the Scan Controller Upgrade Utility. See “Installing the Scan Controller Upgrade Utility” on page 3-24 and “Running the Scan Controller Upgrade Utility” on page 3-29 to for step-by-step instructions for changing your network settings.

To configure a DHCP IP Address:


1. Connect your computer to the Ethernet interface on the rear of the Laser Marker/ Scan Controller using a standard Ethernet cable.
2. Go to **Control Panel -> Network and Internet -> Network and Sharing Center**.
3. Click **Change adapter settings**.
4. Select a Local Area Connection icon. The following window appears as shown in Figure 3-24.

Figure 3-24. Local Area Connection Status




5. Click **Properties**. The following window appears as shown in Figure 3-25.

Figure 3-25. Local Area Connection Properties



6. Select **Internet Protocol Version 4 (TCP/IPv4)**.
7. Click **Properties**. The following window appears as shown in Figure 3-26.

Figure 3-26. Internet Protocol Version 4 Properties



8. Click the **Obtain an IP address automatically** radio button to automatically assign a DHCP IP address.
9. Click the **Obtain an DNS server address automatically** radio button to automatically assign the DNS server address.
10. Press **OK** to accept your changes.


Installing the Scan Controller Upgrade Utility

You set a static IP address and change the host name of the Scan Controller using the Scan Controller Upgrade Utility.

To install the Scan Controller Upgrade Utility:


1. Open a web browser and go to **software.ipgphotonics.com**.
2. Click the Marker folder.
3. Click the Utilities folder.
4. Download the ScanControllerUtility.zip file to your computer.
5. Once downloaded, extract the Utilities.zip file. A folder called Utilities is created.
6. Open the folder and run **setup.exe** and click **Next**. The following windows appears as shown in Figure 3-27.

Figure 3-27. Scan Controller Upgrade Utility Window




7. Click **Next**. The Select Installation Folder window appears as shown in Figure 3-28.

Figure 3-28. Select Installation Folder




8. Click **Next** to accept the default Start Menu folder.
 - a. Click **Browse** if you want to change the default Start menu to another location.
 - b. Click **Everyone** to allow all users to access the Scan Controller Upgrade Utility or **Just me** if only you want access.
9. Click **Next**. The Confirm Installation window appears as shown in Figure 3-29.

Figure 3-29. Confirm Installation Folder




10. Click **Next** to continue with installation. The Installation Progress window appears as shown in Figure 3-30.

Figure 3-30. Installation Progress Window



11. Click **Next** to continue with installation as shown in Figure 3-31.

Figure 3-31. Installation Complete Window




12. Click **Close** to complete installation.

Running the Scan Controller Upgrade Utility

To run the Scan Controller Upgrade Utility:


1. Select **All Programs ->Scan Controller Upgrade Utility**.

Figure 3-32. Scan Controller Upgrade Utility Program



The Scan Controller Upgrade Utility window appears as shown in Figure 3-33. The Scan Controller host name automatically appears in the Scanners List (this may take several seconds).

Figure 3-33. Scan Controller Upgrade Utility Window



2. To change the host name of the Scan Controller, enter a new name in the **Change Host Name** text box and click **Apply**. A progress status message appears in the Events Log pane.
3. To use a static IP address for the Scan Controller, enter the IP address in the **IP Address** text box and Net Mask in the **Net Mask** text box under **Change Network Settings** and click **Apply**. A progress status message appears in the Events Log pane.
4. Click **Exit** to close the Scan Controller Upgrade Utility.

WinLase 6 Quick Start

Overview

This chapter explains how to create, save, and run a one-time job using the WinLase 6 program with the Laser Marker Module, Integrated Scan Controller version.

Before you begin, ensure you have met the following requirements:

- Installed IPG ScanPack as explained in “Installing IPG ScanPack” on page 3-2.
- Installed and activated WinLase 6 as explained in “Installing the WinLase 6 Software” on page 3-9 and “Activating WinLase 6” on page 3-15.
- Configured a local area network as explained in “Configuring a DHCP IP Address” on page 3-20.
- Have your protective eyeglasses ready to wear when operating the Laser Marker.


Starting WinLase 6

WinLase 6 provides drawings tools for creating custom images. You can also import file formats, for example, dxf, .bmp, and .hpgl formats.

To start the WinLase 6 program:


1. Go to **All Programs ->WinLase 6 folder**.
2. Select **WinLase 6**.

Figure 4-1. WinLase 6 Program




The Job Editor Workspace appears as shown in Figure 4-2. The Job Editor Workspace provides editing functions and full control sets.

Figure 4-2. Job Editor Workspace



The Laser Marker Module is automatically detected and appears in the Laser System Explorer window (this may take several seconds).

Figure 4-3. Laser System Explorer Window



3. See “Creating a Job” to continue.


Creating a Job

This section explains how to create a job and interact with objects within this job. A job lets you assemble a series of objects that are marked on the material using the scan head.

To create a job:

1. Select **New Job** from the **File** menu. An unsaved and untitled job appears as shown in Figure 4-4.

Figure 4-4. New Job Window




2. Define the marking layout by selecting the objects you want to mark. You can add a variety of objects such as text, barcodes, and point arrays. You can also import images by selecting **Import...** from the **File** menu. Figure 4-4 shows an example job.
3. Select **Properties Window** from the **View** menu to display the Properties window in the Job Editor Workspace. Drag the window the right side of the workspace. Make configuration changes in the Properties window if needed.

4. Select **Mark Parameters** from the **View** menu to display the Mark Parameters window in the Job Editor Workspace. Drag the window the right side of the workspace. See “Configuring Marking Parameters” on page 4-6 for a recommended marking parameter configuration.

An example of a job with the Properties and Mark Parameters windows displayed is shown in Figure 4-5.

Figure 4-5. Example of a Job



The order in which the objects appear in the Index window is the order in which they mark when you run the job.

Configuring Marking Parameters

The following marking controls are available in the Marking Parameters window:

- **Optimization** — lets you adjust the speed or quality of the marking job.
- **Pulse Energy** — lets you adjust the energy per laser pulse. The adjustment range is 0 to 0.1 mJ.
- **Pitch** — lets you adjust the overlapping of the pulses on the laser marking area. This marking parameter lets you modify the contrast of the marking or to create various dot patterns in the engraving (for example, continuous line vs. perforated line).

For a 163mm lens, you can use the following settings for obtaining good results on most metals:

1. Set the Pitch parameter to 0.020mm.
2. Set the Pulse Energy parameter to 0.5mJ.
3. Leave the Optimization parameter as “Default.”

Note

For Bitmaps, the pitch is inherited from the output resolution and is set to approximately the spot size.

Quality optimization is automatically be invoked if limited by Laser Power. Setting the Pulse Energy to higher than needed can slow performance. Optimal Pulse Energies and spot sizes change with focal length selection.

Figure 4-6 on page 4-7 illustrates the marking parameters configuration options.


Saving a Job

The job file contains the basis for all interaction with the Laser Marker Module.

To save a job:

1. Select **Save Job** from the **File** menu.
2. Select a location for the saved job.
3. Enter the name your want for the job in the File name box.
4. Click **Save**.

Figure 4-6. Marking Parameters Configurations




Previewing a Job

To preview a job:

1. Select **Preview Mark...** from the **Mark** menu to preview the job and align where you want to mark to appear on the targeted surface.

Figure 4-7. Preview Mark Dialog Box




2. Click **Go**.

Running a One-Time Job

To run a one-time job:

1. Power on the Laser Marker Module.
2. Position the material to be marked on the targeted surface base.
3. Select an object or group of objects in the workspace to be marked using the arrow tool. The object appears with anchor points around it to indicate selection. The name of the object is bolded in the Index window.
4. Select **QuickMark...** from the **Mark** menu to preview the job and align where you want to mark to appear.
5. Click **Selected** to mark a single object or **Go** to mark all objects currently in the job.

Figure 4-8. QuickMark Dialog Box



6. Click **Go**. A progress bar is displayed indicating the status of the job. The optical scanner head draws the shape over the targeted surface.
7. When the marking is complete, the status bar at the bottom of the dialog box displays the mark time.

Computer Interface/Commands —XY2-100 Version

RS-232 Configuration

A three-wire (RxD, TxD, GND) interface is used (null modem cable). The individual commands are described in Table 5-2 on page 5-2.

The RS-232 interface is configured with the following parameters:

Table 5-1. RS-232 Parameters

Parameter	Value
Baud Rate	57,600
Data Bits	8
Stop Bits	1
Parity	None
Flow Control	None

RS-232 Command Codes

The command code is a decimal ASCII representation of a number individual for each command. The list of command numbers is shown in Table 6.

Command parameter is a text string. If the parameter is a numerical value, it should be converted into a decimal ASCII string.

The returned value is also a text string. If the requested value is numerical, the opposite conversion from text string to the numerical value is required.

All commands should be terminated by carriage return symbol, hexadecimal value "0x0D." The RS-232 buffer of the laser receives bytes until the CR symbol occurs. All bytes before this symbol are interpreted as a command. Bytes after CR until next CR is interpreted as a next command.

For all "set" commands device returns as the parameter "Y" if the command was successfully executed and "N" if the command was not executed.

For all strings sent to the laser, which were not recognized as valid commands, the laser sends “E” as parameter. In case an option is not applicable for a particular laser the command could answer “E.”

Table 5-2. RS-232 Command Codes: Laser Monitoring and Configuration

Type	Command	Command Code	Parameters or Return Values	Description/Parameters
Read	Device ID	1	string, up to 64 characters	Read device identifier written to the laser in the factory.
Read	Device SN	2	string, up to 24 characters	Read device serial number.
Read	FW revision	3	string, up to 255 characters	Read device firmware revision.
Read	Vendor	99	string, up to 255 characters	Read device vendor written to the laser in the factory.
Read	Device Status	4	string, up to 32 characters	Read device status, decimal to binary decoding is required.
Read	Device Temperature	5	float, 1 digit after point	Read module temperature in degree celsius.
Read	Digital interface Status	10	up to 32 bit integer	Reads digital interface status, decimal to binary decoding is required.
Read	Extended Status	11	up to 32 bit integer	Read device extended status, decimal to binary decoding is required.
Read	BR Counter	12	up to 32 bit integer	Read back reflection counter.
Read	Session BR Counter	13	up to 32 bit integer	Read back reflection counter for the current session. The session starts with supplying voltage to the laser module.
Read	Nominal average Power	14	float, 1 digit after point	Read nominal average power of the laser in [W]. Return value is float in [W].
Read	Nominal Pulse Duration	15	float, up to 6 digits after point	Read nominal pulse duration of the laser [ns].
Read	Nominal Pulse Energy	16	float, 1 digit after point	Read nominal peak power of the laser in [kW]. Value is calculated from the nominal energy and the nominal pulse duration.
Read	Nominal Peak Power	17	float, 1 digit after point	Read nominal peak power of the laser in [kW]. Value is calculated from the nominal energy and the nominal pulse duration.

Type	Command	Command Code	Parameters or Return Values	Description/Parameters
Read	PRR Range	18		Read pulse repetition rates range. Return value is two floats separated by a semicolon, corresponding to minimum and maximum PRR [kHz].
Read	Head Temperature	19	float, 1 digit after point	Read remote head temperature in degree Celsius, if the head is installed.
Read	Main Supply Voltage	21	float, 1 digit after point	Read main 24V supply voltage in [V].
Read	24V Housekeeping Voltage	22	float, 1 digit after point	Read 24V housekeeping supply voltage in [V].
Read	Operating Mode	23	32-bit integer	Read active control interface operating mode, decimal to binary decoding is required.
Read	Operating Mode	24	32-bit integer	Set active control interface operating mode, binary to decimal encoding is required. The command parameter is validated before the execution. If some bits are not correct, the command is not executed. All 32 bits (even unused) should have correct values. To set correctly all bits, the existing operating mode should be read by the command 24. Only necessary bits should be updated and then new value sent to the device.
Read	Installed Options	25	32-bit integer	Read list of installed options and operating modes. Decimal to binary decoding is required.
Read	Start Operating Mode	27	32-bit integer	Read control interface operating mode, which activates after connecting the laser to the supply voltage. The value is stored permanently in the laser EEPROM. Decimal to binary decoding is required.
Read	Operating Power [W]	33	float, 2 digit after point	Read back operating power in [W] set by command 32 (in RS-232 mode) or via digital interface (in DB-25 mode). Recalculated into Watts using nominal laser parameters.
Read	Operating Power [%]	34	float, 2 digit after point	Read back operating power in [%] set by command 32 (in RS-232 mode) or via digital interface (in DB-25 mode). Recalculated into [%] using nominal laser parameters.
Read	Operating Pulse Energy	36	float, 2 digit after point	Read operating pulse energy in [mJ]. Value is calculated using nominal laser parameters and power settings.

Type	Command	Command Code	Parameters or Return Values	Description/Parameters
Read	PRR monitor	38	float, 1 digit after point	Read back operating PRR in [kHz] set by command 28 (in RS-232 mode) or applied via Sync input of digital interface (in DB-25 mode).
Read	Alarm counters	70	16-bit integer	Read alarm counters. The command contains a parameter which specifies the alarm counter: 1 - 24V main supply 2 - 24V housekeeping supply 3 - System 4 -Temperature 5 -Head Temperature
Read	Module Temperature range	58	float, 1 digit after point	Read operating temperature range. Return value is two floats separated by a semicolon, corresponding to minimum and maximum temperatures in degree Celsius.
Read	Nominal frequency	59	float, 1 digit after point	Read back nominal PRR in [kHz].
Read	Critical error counter	95	16-bit integer	Read critical error counter.
Read	Critical error code	96	32-bit integer	Read critical error code.
Set	Reset critical error alarms	97	32-bit integer	Reset the critical error. The command contains one parameter, which is a one-time use code generated in IPG factory. If the correct code is sent to the device, the command is executed with answer “Y” and the critical error is cleared.

Table 5-3. RS-232 Command Codes: Control Interface

Type	Command	Command Code	Parameters or Return Values	Description/Parameters	Equivalent DB-25 Control Line
Set	Set PRR	28	float, 1 digit after point	Set operating pulse repetition rate in [kHz].	Sync
Read	Read PRR	29	float, 1 digit after point	Read back operating pulse repetition rate in [kHz] set by command 28.	EM
Set	Laser Emission ON	30		Switch ON laser emission.	EM

Type	Command	Command Code	Parameters or Return Values	Description/Parameters	Equivalent DB-25 Control Line
Set	Laser Emission OFF	31		Switch OFF laser emission.	EM
Set	Operating Power	32	float, 1 digit after point	Set operating power in [%]. Range 0...100, resolution 255 levels for the full scale.	D0-D7 and Latch
Set	Guide Laser ON	40		Switch ON guide laser.	RG
Set	Guide Laser OFF	41		Switch OFF guide laser.	RG
Set	EE ON	42		Switch ON Emission Enable.	EE
Set	EE OFF	43		Switch OFF Emission Enable	EE
Set	Reset Alarms	50		Reset alarms	Reset Sequence

Table 5-4. Commands for Adjustable Pulse Duration (ADP) Mode

Type	Command	Command Code	Parameters or Return Values	Description/Parameters
Read	Read the number of APD modes.	55	16-bit integer	Read number of APD modes (N).
Read	Read APD mode description.	56	Parameter: M Answer: string, up to 128 characters	Read a text description of APD mode with index M. Parameter is M is APD mode index, integer, range 0 to N-1. N is number of APD modes read by command \$55.
Read	Read APD mode index.	68	16-bit integer	Read current APD mode index.
Set	Set APD mode index.	69	1- bit integer	Set APD mode index.
Set	Save APD mode index.	54		Permanently save the APD mode index to EEPROM. Next start the device is initialized by the saved APD mode index.

Table 5-5. Commands for Manual Rising Time Compensation (Manual Pre-Pump) Model

Type	Command	Command Code	Parameters or Return Values	Description/Parameters
Read	Maximum Pre-pump	63	16-bit integer	Return maximum value of the pre-pump compensation. The value is always 10000.
Set	Pre-Pump	64	16-bit integer	Set the pre-pump compensation value. Range is 0...10000.
Read		65	16-bit integer	Read back value of the pre-pump compensation set by command \$64 or through DB-25 serial interface.

Table 5-6. Commands “\$4” “Read Device Status” - Return Value Description

Bit	State	Description
0	1 0	Rack reflection Alarm active No BR alarm
1	1 0	Temperature Alarm active. Laser module temperature is out of specified range. No temperature alarm
2	1 0	System Alarm active No system alarm
3	1 0	System Alarm active No system alarm
4	1 0	+24V main supply Alarm active. Over-voltage or under-voltage of the main electrical supply occurred during the laser emission. No supply alarm
5	1 0	HK supply Alarm active. Overvoltage or Undervoltage of the 24V housekeeping electrical supply occurred during the laser emission. No supply alarm
6	1 0	Laser is ready for emission Laser is not ready for emission
7	1 0	At least one of the warnings is activated No warning is activated
8-31	1 0	Reserved

Table 5-7. Commands “\$10” “Read Digital Interface DB-25 Status” - Return Value Interpretation

Bit	DB-25 Control Line	Description of Line/Data
0	Latched D0	D0 latched power setting
1	Latched D1	D1 latched power setting
2	Latched D2	D2 latched power setting
3	Latched D3	D3 latched power setting
4	Latched D4	D4 latched power setting
5	Latched D5	D5 latched power setting
6	Latched D6	D6 latched power setting
7	Latched D7	D7 latched power setting
8	D0	D0 power setting
9	D1	D1 power setting
10	D2	D2 power setting
11	D3	D3 power setting
12	D4	D4 power setting
13	D5	D5 power setting
14	D6	D6 power setting
15	D7	D7 power setting
16	Latch	
17	AuxOFF	Auxiliary Emission OFF
18	EM	Emission Modulation
19	RG	Guide laser control
20	Sync	External Synchronization Input
21	EE	Emission enable
22	Serial Input	
23	Serial Clock	
24	State1	
25	State2	

Bit	DB-25 Control Line	Description of Line/Data
26	State0	
27	Serial Output	
28	Serial Enable	
29	Reserved	Bit is reserved for future use.
30	Reserved	Bit is reserved for future use.
31	Reserved	Bit is reserved for future use.

Return bits reflect status of the corresponding pins or internal data.

“1” means that the pin/data is HIGH.

“0” means that the pin/data is LOW.

Table 5-8. Commands “\$11” “Read Device Extended Status” - Return Value Interpretation

Bit	State	Description	Message Type
0	1 0	Emergency stop was activated. Emergency stop was not activated.	Warning
1	1 0	External PRR at Sync line is above specification. Not above specification.	Warning
2	1 0	External PRR at Sync line is below specification. Not below specification.	Warning
3		Reserved	
4		Reserved	
5	1 0	Guide laser was activated. Guide laser was not activated.	Warning
6		Reserved	
7		Reserved	
8	1 0	Laser emission is ON (laser is pumped). Laser emission is OFF (laser is not pumped).	Information
9		Reserved	
10		Reserved	

Bit	State	Description	Message Type
11	1 0	Laser emission ON command was received by RS-232. Laser emission OFF command was received by RS-232. This bit is valid in RS-232 control mode only.	Information
12	1 0	Guide laser ON command was received by RS-232. Guide laser OFF command was received by RS-232. This bit is valid in RS-232 control mode only.	Information
13	1 0	24V Main supply voltage is in specified range. 24V Main supply voltage is not in specified range.	Warning
14	1 0	HK supply voltage is in specified range. HK supply voltage is not in specified range.	Warning/Information
15	1 0	Emission Enable is switched ON by RS-232. Emission Enable is switched OFF by RS-232.	Warning/Information
16-31		Reserved	

Integration with a Motor or Gantry System

Overview

The Scan Controller Motor Interface allows the Laser Marker Module to work with common types of motor drivers, such as a Gantry overhead lift structure. It can be configured to send controller commands or monitor encoder feedback.

Installing the Stage Configuration Utility

To install the Stage Configuration Utility:


1. Open a web browser and go to:
software.ipgphotonics.com
2. Click the Welder folder.
3. Click the IPGWeld folder.
4. Download the installation program zip file to your computer.
5. Once downloaded, extract the zip file. A folder is created.
6. Open the folder and run **setup.exe**. The Setup Wizard appears as shown in Figure 6-1.

Figure 6-1. Setup Wizard




7. Click **Next**. The Select Installation Folder window appears as shown in Figure 6-2.

Figure 6-2. Select Installation Folder




8. Click **Next** to accept the default Start Menu folder.
 - a. Click **Browse** if you want to change the default Start menu to another location.
 - b. Click **Everyone** to allow all users to access the Stage Configuration Utility program or **Just me** if only you want access.
9. Click **Next**. The Confirm Installation window appears as shown in Figure 6-3.

Figure 6-3. Confirm Installation




10. Click **Next** to proceed. The Installing Stage Configuration Utility window appears as shown in Figure 6-4.

Figure 6-4. Installing Stage Configuration Utility



11. Once installation is complete, the Installation Complete window appears as shown in Figure 6-5.

Figure 6-5. Installation Complete




12. Click **Close** to exit the window. The Stage Configuration Utility is successfully installed on your system.

Running the Stage Configuration Utility

To run the Stage Configuration Utility:


1. Open the Stage Configuration Utility program. The main window appears as shown in Figure 6-6.

Figure 6-6. Stage Configuration Utility Main Window




2. Select a controller from the list in the left pane. The controller you select changes to locked mode (red) as shown in Figure 6-7.

Figure 6-7. Selecting a Controller



3. Click **Configure Stages**.

Figure 6-8. Stage Configuration



4. Select a stage, such as Z Axis.
5. Select a linear unit.

Integration with a Motor or Gantry System

Running the Stage Configuration Utility

6. Click **Next**.
7. Select the stage configuration options as shown in Figure 6-9.


Figure 6-9. Linear Z Axis (Stage C)

The screenshot shows the 'Stage Configuration' window for the 'Linear Z Axis (Stage C)'. The window is divided into several sections:

- Counts/m:** A text input field containing the value '1968502'.
- Travel Length (m):** A text input field containing the value '0.3000007'.
- Speed:** A group box containing three radio buttons: 'Fast', 'Medium', and 'Slow'. The 'Slow' radio button is selected.
- Signal Type:** A group box containing three radio buttons: 'Quad', 'PulseDir', and 'CC/CCW'. The 'PulseDir' radio button is selected.
- Home Sensor:** A group box containing two sub-sections:
 - Active:** Two radio buttons: 'Low' (selected) and 'High'. A green 'OFF' label is next to the 'Low' radio button.
 - Position:** Two radio buttons: 'Positive End' (selected) and 'Negative End'.
- Length from sensor to focus position (m):** A text input field containing the value '0.012'.
- Reverse Direction:** A checkbox that is currently unchecked.
- Pulse Width (us):** A text input field containing the value '1'.
- Buttons:** 'Next' and 'Cancel' buttons are located at the bottom right of the window.


8. Click **Next**. A confirmation message appears as shown in Figure 6-10.

Figure 6-10. Confirmation Message



9. Click **Next**. A window appears displaying the local path for the configuration file.

Figure 6-11. Stage Configuration - Finish Message




10. Click **Finish**.

Advanced Settings

To modify advanced settings:

1. Click **File->Advanced Settings**. The Advanced Settings window appears as shown in Figure 6-12.

Figure 6-12. Advanced Settings



2. Make necessary changes and click **Save Changes**.

Configuring the Motor Control Interface

The Motor Control interface allows the Laser Marker Module to control or listen to common types of motor drivers. It is connected to the 37-pin connector on the controller box.

Figure 6-13 shows the Motor Control Interface front view.

Figure 6-13. Motor Control Interface — Front View




Table 6-1 on page 6-12 provides details on each component.

Integration with a Motor or Gantry System
 Configuring the Motor Control Interface

Table 6-1. Motor Control Interfaces Descriptions

Item	Component	Description
1	Power Supply +24V IN	+24V power supply for board. It is isolated from the 5V output supply and 3V input supply.
2	Scan Interface - 37-pin Female Sockets	Used for external interface to the 37-pin Male interface on the controller box rear panel. See "Controller Box Rear Panel View — High-Power Scanner" on page 2-12 or more information.
3	Digital I/O - Female DB15	The digital I/O is a 15-pin female interface that connect to the 37-pin interface and is isolated and at 5V logic levels.
4	Motor Controller I/O - P1, P2, P3 (Axis X, Y, Z)	This connector interfaces with a motor controller to drive a stage. There are three connectors with identical pinouts intended for XYZ control. The connectors can be configured to drive or receive signals at 5V logic and can be single-end or differential.
5	Motor Control Inputs - Female DB9	This connector is multiplexed with P2 Y axis. Depending on the logic level of P4-4 (normally high), you can enable the use of P2's signals or P4's. The Y axis signals or the Rotary axis signals are mutually exclusive. The Y axis is enabled normally; pulling P4-4 to GND enables the Rotary axis and disable the Y axis.
6	Fiber Interlock	Brings the fiber interlock signals from the scan controller out to screw taps.

Scan Interface — 37-Pin Sockets

Figure 6-14 illustrates the Scan Controller 37-pin female sockets.

Figure 6-14. 37-Pin Sockets



Table 6-2 provides details for the 37-pin sockets.

Table 6-2. 37-Pin Descriptions

Pin	Name	I/O	Description
1	Active	Out	Mark in Progress
20	GND	3VTTL	
2	Ready	Out	Ready/Waiting Signal
21	GND	3VTTL	
3	Error	Out	Error Condition
22	GND	3VTTL	
4	Start	In	Start Signal Input
23	GND	3VTTL	Pulled up to 3.3V
5	Stop	In	Stop Signal Input Active Low
24	GND	3VTTL	Pulled up to 3.3V
6	GPIO[0]	In/Out	General Purpose Input/Output for Synchronization
25	GND	3VTTL	Pulled up to 3.3V
7	GPIO[1]	In/Out	General Purpose Input/Output for Synchronization
26	GND	3VTTL	Pulled up to 3.3V
8	A_Axis_A+	In/Out	Axis A Phase A
27	A_Axis_A-	RS-422	

Integration with a Motor or Gantry System
 Configuring the Motor Control Interface

9	A_Axis_B+	In/Out	Axis A Phase B
28	A_Axis_B-	RS-422	
10	A_Axis_Z+	In	Axis A Phase Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V)
29	A_Axis_Z-	RS-422	
11	B_Axis_A+	In/Out	Axis B Phase A
30	B_Axis_A-	RS-422	
12	B_Axis_B+	In/Out	Axis B Phase B
31	B_Axis_B-	RS-422	
13	B_Axis_Z+	In	Axis B Phase Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V)
32	B_Axis_Z-	RS-422 or 3VTTL	
14	C_Axis_A+	In/Out	Axis C Phase A
33	C_Axis_A-	RS-422	
15	C_Axis_B+	In/Out	Axis C Phase B
34	C_Axis_B-	RS-422	
16	C_Axis_Z+	In/Out	Axis C Home (or Zero) Differential or Single Ended (on Z+ Pulled up to 3.3V) or ClkIn/ClkOut Differential for Synchronization to laser.
35	C_Axis_Z-	RS-422 or 3VTTL	
17	FiberInterlockA0	Out Relay	FiberInterlock is safe when 1 is connected to 0.
36	FiberInterlockA1		
18	FiberInterlockB0	Out Relay	FiberInterlock is safe when 1 is connected to 0.
37	FiberInterlockB1		
19	GND	Out	Logic Ground

Digital I/O — 15-Pin Sockets

Figure 6-15 illustrates the Digital I/O 15-pin female sockets.

Figure 6-15. 15-Pin Female Sockets



Table 6-3 provides details for the 9-pin female sockets.

Table 6-3. Digital I/O 15-Pin Descriptions

Socket	Name	i/O	Description
1	GND		
2	Stop	Input	Stop signal input, active low. Pulled up to +5V.
3	Ready	Output	Ready, waiting for start.
4	GPIO[0]	Input	If pin 6 on DB37 is an input use this pin. Must configure SW2-1 for input.
5	GND		
6	GPIO[1]	Output	If pin 7 on DB37 is an output use this pin. Must configure SW2-2 for output.
7	GND		
8	GND		
9	Start	Input	Start signal input. Pulled up to +5V.
10	Active	Output	Mark in progress.
11	Error	Output	Error Condition
12	GPIO[1]	Input	If pin 7 on DB37 is an input use this pin. Must configure SW2-2 for input.
13	GPIO[0]	Output	If pin 6 on DB37 is an output use this pin. Must configure SW2-2 for output.
14	GND		
15	GND		

Motor Control I/O - P1, P2, P3

Figure 6-16 illustrates the Motor Control I/O 9-pin female sockets.

Figure 6-16. 9-Pin Female Sockets



Table 6-4 provides details for the 9-pin female sockets.

Table 6-4. Motor Control I/O 9-Pin Descriptions

Num	Name	i/O	Description
5	AXIS_IO0+	IO	Can be a 5V command or encoder feedback (SE or Differential) depending on SW1.
9	AXIS_IO0-		Only used if differential signal is needed.
4	GND		
8	AXIS_IO1+	IO	Can be a 5V command or encoder feedback (SE or Differential) depending on SW1.
3	AXIS_IO1-		Only used if differential signal is needed.
7	GND		
2	Home_sensor+	Input	Home sensor input. Can be SE or differential depending on SW1.
6	Home_sensor-	Input	Only used if differential signal is needed.
1	GND		

Motor Control Inputs

Figure 6-17 illustrates the Motor Control I/O 9-pin female sockets.

Figure 6-17. 9-Pin Female Sockets



Table 6-5 provides details for the 9-pin female sockets.

Table 6-5. Motor Control I/O 9-Pin Descriptions

Num	Name	i/O	Description
5	ROTARY_IN0+	IO	Can be a 5V command or encoder feedback (SE or Differential) depending on SW1.
9	ROTARY_IN0-		Only used if differential signal is needed.
4	ROTARY_SEL_L	Input	Pulled up to +5V. When this signal is high, the Y axis is enabled; when it is low the Rotary axis is enabled.
8	ROTARY_IN1+	Input	Can be a 5V command or encoder feedback (SE or Differential) depending on SW1.
3	ROTARY_IN1-		Only used if differential signal is needed.
7	GND		
2	Home_sensor+	Input	Home sensor input. Can be SE or differential depending on SW1.
6	Home_sensor-	Input	Only used if differential signal is needed.
1	GND		

Fiber Interlock Inputs

Figure 6-18 illustrates the Fiber Interlock pin female sockets.

Figure 6-18. 9-Pin Female Sockets



Table 6-6 provides details for the 9-pin female sockets.

Table 6-6. Motor Control I/O 9-Pin Descriptions


Num	Name	i/O	Description
1	INTLK_A0	Out	Fiber Interlock is Safe when 1 connected to 0.
2	INTLK_A1		
3	INTLK_B0	Out	Fiber Interlock is Safe when 1 connected to 0
4	INTLK_B1		

PCB Configuration and Testing

There are two sets of dip switches used to configure the board. Two momentary contact push buttons can also test the operation of the “Start” and “Stop” commands.

Figure 6-20 shows the Motor Control Interface side view.

Figure 6-19. Motor Control Interface - Side View



SW1 and SW2 - Pushbutton Test Signals

SW1 - When pressed, the Start signal is low. Normally high.

SW2 - When pressed, the Stop signal is low. Normally high.

SW3 - PIO[0], GPIO[1] Direction

The switch is marked with an arrow pointing down that is labeled “ON.” When the dip switch is pointed down, it is in the ON position. When it is pointed up, it is in the OFF position.

Position 1 - This switch sets pin 6 of the 37-pin DSUB (J1-6) as an input or output.

- ON - GPIO[0] is an input. Send a 5V signal to J2-4.
- OFF - GPIO[0] is an output. J2-13 can drive a 5V signal to a controller.

Position 2 - This switch sets pin 7 of the 37-pin DSUB (J1-7) as an input or output.

- ON - GPIO[1] is an input. Send a 5V signal to J2-12.
- OFF - GPIO[1] is an output. J2-6 can drive a 5V signal to a controller.

SW4 - Encoder Interface Setup - SW4

The switch is marked with an arrow pointing down that is labeled “ON.” When the dip switch is pointed down, it is in the ON position. When it is pointed up, it is in the OFF position.

Position 1 - This switch sets up the home sensor as differential or single-ended when toggled.

- ON - Home sensor is a single-ended signal connected to pin 2 of P1, P2, P3, or P4.
- OFF - Home sensor is a differential signal connected to pins 2, 6 of P1, P2, P3, or P4.

Position 2 - This switch sets up the encoder signals as differential or single-ended when toggled.

- ON - Encoder signals are single-ended
- OFF - Encoder signals are differential

Position 3 - This switch determines the direction of the encoder signals.

- ON - Encoder commands are sent to the DB9 connectors to control a motor driver.
- OFF - Encoder signals are readback to the DB9 connectors so the IPGP523 can monitor stage locations.

The rotary axis cannot be used if Position 3 is in the OFF position.

Position 4 - Reserved

Maintenance

Overview

The Laser Marker Module is incorporated into a given fixed installation. The safety functions have to be tested in a defined periodic maintenance interval.

The time cycle of this interval is dependent on the safety analysis of the system where the Laser Marker Module is installed.

Only personnel knowledgeable in the related functional safety assessment of the system can determine such maintenance.

Maintenance
Overview

Service

Service and Repairs

Refer all servicing to qualified IPG Customer Service personnel.

Many issues and questions regarding the safety, set-up, operation and maintenance of the IPG products can be resolved by reading this user's guide. However, if you have questions regarding the safety, set-up, operation or maintenance of your IPG product, call the IPG Photonics Customer Service department.

If you cannot resolve the issues by using this guide or over the telephone with our technical support group, you might need to return the product to IPG. See “Product Returns” on page D-1 for more details.

Service
Service and Repairs

Warranty

Limited Express Product Warranties

IPG warrants to the original Buyer or, if Buyer is an authorized IPG reseller or distributor, to Buyer's original customer of the IPG Product, that the IPG Product conforms to applicable IPG Product specifications and is free from defects in materials and workmanship. These non-transferable warranties start on the shipment date from IPG (or other date specifically referencing the warranty start date in IPG's sales order/order acknowledgement), and continue until the end of the warranty period listed in IPG's sales order/order acknowledgement. If there is no warranty period listed, then warranty period is one year. Products or major components manufactured by parties other than IPG bear the original manufacturer's warranty and warranty period. The obligations of IPG are limited to the repair or replacement (at IPG's option) of any Product that does not meet the IPG warranty during the warranty period. IPG warrants repaired or replaced Products under warranty only for the remaining un-expired period of time in the original warranty. IPG reserves the right to issue a credit note for any defective Products that have proved defective through normal usage; Buyer debit memos are not allowed. This warranty governs over any conflicting terms in Buyer's purchase order or other IPG documents except as expressly provided herein.

Warranty Limitations

This warranty excludes and does not cover defects or damage resulting from any of the following: contamination of external optical surfaces; unauthorized modification, misuse or mishandling, disassembly or opening, neglect, or damage from accident; operation outside environmental specifications or product ratings; user software or interfacing; components and accessories manufactured by companies other than IPG, which have separate warranties; improper or inadequate installation, site preparation or maintenance; or failure to follow information and precautions contained in the operating manual. Additional warranty exceptions, limitations and exclusions may apply for laser systems manufactured by IPG and its affiliates as set forth in the applicable quotation and sales order/order acknowledgement. All products or components (including software) identified as experimental, prototypes or to be used in field trials are not warranted and are provided to the Buyer on an "as is" basis. IPG assumes no responsibility for Buyer or third-party supplied material, components, systems or equipment. Products and repaired Products may contain components that have been previously used in other

Warranty

Limitation of Remedies and Liabilities

products, however such Products meet IPG Product specifications for newly manufactured Products. The Buyer must give prompt notification to IPG of any claim under the warranty in writing. IPG has no responsibility for warranty claims more than 30 days after the Buyer discovers or becomes aware of the claimed defect. Buyer is responsible for providing appropriate utilities and operating environment as stated in the operating manual and the specifications. This warranty applies only to the original Buyer at the initial installation or delivery point. Buyer must make all claims under this warranty and no claim will be accepted from any third party.

EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY SET FORTH ABOVE, IPG SPECIFICALLY DISCLAIMS ANY AND ALL OTHER WARRANTIES AND REPRESENTATIONS TO BUYER, INCLUDING WITHOUT LIMITATION, ANY AND ALL IMPLIED WARRANTIES, SUCH AS FREEDOM FROM INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Limitation of Remedies and Liabilities

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL IPG BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES (EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES) ARISING FROM OR RELATING TO THIS ORDER OR THE PRODUCTS (INCLUDING, LOSS OF PROFITS) WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY. IPG'S MAXIMUM LIABILITY ARISING UNDER THESE TERMS AND CONDITIONS WILL NOT EXCEED, IN THE AGGREGATE, THE TOTAL AMOUNT PAID FOR THE PRODUCTS BY BUYER. THESE LIMITATIONS MAY NOT APPLY TO YOU UNDER THE LAWS OF CERTAIN JURISDICTIONS.

Software

Firmware License Agreement

CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE OPENING THIS PACKAGE OR SIGNIFYING YOUR ACCEPTANCE BY CLICKING THE APPROPRIATE DIALOG BOX. OPERATING THE PRODUCT, CLICKING THE APPROPRIATE DIALOG BOX OR USING ANY PART OF THE SOFTWARE SIGNIFIES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE WITH THEM, PROMPTLY RETURN THE PRODUCT UNUSED ALONG WITH ANY OTHER RELATED ITEMS THAT WERE INCLUDED IN THE SAME ORDER FOR FULL CREDIT.

You, as the Customer, agree as follows:

1. DEFINITIONS

"IPG" shall mean the IPG Photonics Corporation affiliate providing Licensed Software to Customer pursuant to this Agreement.

"IPG Software" shall mean those portions of the Licensed Software owned by IPG or IPG affiliates.

"Licensed Software" shall mean the software, in object code form only, supplied by IPG pursuant to this Agreement.

"Licensed Product" shall mean the Licensed Software and/or its accompanying documentation.

"Third Party Software" shall mean those portions of the Licensed Software owned or licensed by a third party, including but not limited to operating system code, that is embedded within the Licensed Software.

2. LICENSE

2.1 Except as provided in section 2.2 below, you are granted a non-transferable, nonexclusive license to use the Licensed Software only as embedded in or to be used on a single IPG product. You may copy the Licensed Product, for backup purposes only, in support of your use of the Licensed Software, limited to one copy. No other copies shall be made unless authorized in writing by IPG. You must reproduce and include all applicable copyright notices on any copy. You may not reverse compile or otherwise reverse engineer, or modify the Licensed Software. The Licensed Software, comprising proprietary trade secret information of IPG and/or its licensors, shall be held in confidence by Customer and Customer shall not disclose it to third parties, unless disclosure is required by law or legal process. In response to such legal requirements, the Customer shall promptly notify IPG in advance of such disclosure and reasonably cooperate in attempts to maintain the confidentiality of the Licensed Software. No title to the intellectual property is transferred. Licensed Software shall not be copied, reproduced, or used for any other purpose outside of operation of the IPG product, and shall not be used on any other piece of hardware other than the IPG product with which it was provided.

2.2 If you transfer the IPG product on which the Licensed Software is used, you may transfer the Licensed Software to the end user of the product provided that the end user agrees to be bound by terms no less restrictive than the provisions of this Agreement, and provided that all proprietary markings are maintained. Any other transfer is void and automatically terminates this license. You shall use your best efforts to enforce such agreement and shall promptly report any violation or

suspected violation to IPG. In the event you do not enforce such agreement after a breach, you shall, to the extent permissible by applicable law, grant IPG the right to enforce such agreement.

2.3 The Licensed Software may include Third Party Software licensed to IPG in addition to the licenses below. The owner of this Third Party Software (the "Third Party") and its licensors are intended third party beneficiaries of this Agreement, and the provisions of this Agreement relating to the Licensed Software, as the same incorporates Third Party Software, are made expressly for the benefit of, and are enforceable by, the Third Party and its licensors. The Third Party and its licensors retain ownership of all copies of the Third Party Software. The Licensed Software is warranted by IPG in accordance the above Warranty and the Third Party does not provide an additional warranty. All Third Party Software included in the Licensed Software is provided "AS IS" without warranty from the Third Party, and each Third Party disclaims all warranties, either express or implied, including but not limited to the implied warranties of merchantability, title, non-infringement or fitness for a particular purpose with regard to the Third Party Software. The Third Party shall not have any liability for special, indirect, punitive, incidental or consequential damages.

2.4 In addition to the IPG Software licensed above, IPG may provide certain files embedded in or to be used on the IPG hardware product which may be subject to the terms of the GNU General Public License (GPL) or the GNU Lesser General Public License (LGPL), the current text of which may be found at: <http://www.gnu.org>, or another open source license. The IPG Software is proprietary software not subject to the GPL or LGPL or other open source license, and Customer has no license to take any action, and shall take no action, which would have the effect of subjecting the IPG Software or any portion of the IPG Software to the terms of the GPL or LGPL or other open source license. Customer may consult the user documentation for identifications and further information.

2.5 For the rights granted in this Agreement, Customer shall pay to IPG the price for the IPG hardware product in which the Licensed Software is embedded.

2.6 You understand that IPG may, at any time and in its sole discretion, update or modify the Licensed Product or discontinue updating and/or supporting the Licensed Product. In the case of an update or modification, you agree to allow IPG to automatically install the Licensed Software on the IPG hardware product on which the Licensed Software is used. Any updated or modified Licensed Product made available and/or installed by IPG on the IPG hardware product shall become part of the Licensed Software and subject to this Agreement.

3. TERM AND TERMINATION

3.1 You may terminate the license granted hereunder at any time by destroying the Licensed Product together with all copies thereof and notifying IPG in writing that all use of the Licensed Product has ceased and that same has been destroyed.

3.2 IPG may terminate this Agreement or any license hereunder upon notice to Customer if Customer breaches any of the terms and conditions of this Agreement or if Customer attempts to assign this Agreement or any license hereunder without IPG's prior written consent. Within twenty (20) days after any termination of this Agreement, Customer shall certify in writing to IPG that all use of the Licensed Product has ceased, and that the same has been destroyed.

3.3 All provisions of this Agreement related to disclaimers of warranty, limitation of liability, IPG's intellectual property rights, or export shall survive any expiration or termination and remain in effect. Termination of this Agreement or any license hereunder shall not relieve Customer of its obligation to pay any and all outstanding charges hereunder nor entitle Customer to any refund of such charges previously paid.

If your product includes LaserNet™ Software, the following applies:

Software License Agreement for LaserNet™

IPG Laser GmbH®

Single Use License

PLEASE READ THIS SOFTWARE LICENSE AGREEMENT ("LICENSE") CAREFULLY BEFORE USING THE SOFTWARE OR THE EQUIPMENT. BY CLICKING ON THE "ACCEPT" BUTTON, USING THIS SOFTWARE, OR USING THE EQUIPMENT THAT CONTAINS THIS SOFTWARE, YOU ARE CONSENTING TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT AGREE TO ALL OF THE TERMS OF THIS AGREEMENT, CLICK THE "DO NOT ACCEPT" BUTTON AND THE INSTALLATION PROCESS WILL NOT CONTINUE, RETURN THE PRODUCT TO THE MANUFACTURER.

1. General. The software, documentation and any fonts accompanying this License whether on disk, in read only memory, on any other media or in any other form (collectively the "IPG Software") are licensed, not sold, to you by IPG Laser GmbH and its affiliates ("IPG") for use only under the terms of this License, and IPG reserves all rights not expressly granted to you. The rights granted herein are limited to IPG's and its licensors' intellectual property rights in the IPG Software and do not include any other patents or intellectual property rights. You own the media on which the IPG Software is recorded but IPG and/or IPG's licensor(s) retain ownership of the IPG Software itself. The terms of this License will govern any software upgrades provided by IPG that replace and/or supplement the original IPG Software product, unless such upgrade is accompanied by a separate license in which case the terms of that license will govern.

2. Permitted License Uses and Restrictions.

A. This License allows you to install and use one copy of the IPG Software on a single computer at a time. This License does not allow the IPG Software to exist on more than one computer at a time, and you may not make the IPG Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the IPG Software in machine-readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.

B. Except as and only to the extent permitted in this License and by applicable law, you may not copy, decompile, reverse engineer, disassemble, modify, or create derivative works of the IPG Software or any part thereof. THE IPG SOFTWARE IS NOT INTENDED FOR USE IN THE OPERATION OF NUCLEAR FACILITIES,

AIRCRAFT NAVIGATION OR COMMUNICATION SYSTEMS, AIR TRAFFIC CONTROL SYSTEMS, OR OTHER EQUIPMENT IN WHICH THE MALFUNCTION OF THE IPG SOFTWARE WOULD RESULT IN THE FORESEEABLE RISK OF INJURY OR DEATH TO THE OPERATOR OF THE EQUIPMENT OR SYSTEM OR TO OTHERS.

3. Transfer. You may not rent, lease, lend, redistribute or sublicense the IPG Software. You may, however, make a one-time permanent transfer of all of your license rights to the IPG Software (in its original form as provided by IPG) to another party, provided that: (a) the transfer must include all of the IPG Software, including all its component parts, original media, printed materials and this License; (b) you do not retain any copies of the IPG Software, full or partial, including copies stored on a computer or other storage device; and (c) the party receiving the IPG Software reads and agrees to accept the terms and conditions of this License.

4. Termination. This License is effective until terminated. Your rights under this License will terminate automatically without notice from IPG if you fail to comply with any term(s) of this License. Upon the termination of this License, you shall cease all use of the IPG Software and destroy all copies, full or partial, of the IPG Software.

5. Limited Warranty on Media. IPG warrants the media on which the IPG Software is recorded and delivered by IPG to be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of original purchase. Your exclusive remedy under this Section shall be, at IPG's option, replacement of the IPG Software which is returned to IPG or an IPG authorized representative. THIS LIMITED WARRANTY AND ANY IMPLIED WARRANTIES ON THE MEDIA INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, OF SATISFACTORY QUALITY, AND OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF ORIGINAL PURCHASE.

6. Disclaimer of Warranties. YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE IPG SOFTWARE IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU. EXCEPT FOR THE LIMITED WARRANTY ON MEDIA SET FORTH ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE IPG SOFTWARE IS PROVIDED "AS IS", WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, IPG AND ITS SUPPLIERS FURTHER DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF TITLE, NON- INFRINGEMENT, ACCURACY, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, AND ANY WARRANTIES THAT MAY ARISE FROM COURSE OF

DEALING, COURSE OF PERFORMANCE, OR TRADE PRACTICE. THE ENTIRE RISK ARISING OUT OF THE USE OR PERFORMANCE OF THE IPG SOFTWARE OR RELATED MATERIALS REMAINS WITH YOU. APPLICABLE LAW MAY NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO YOU. IPG MAY MAKE CHANGES TO THE IPG SOFTWARE AND HAS NO OBLIGATION TO DISTRIBUTE NEWER VERSIONS.

7. **Limitation of Liability.** NEITHER IPG NOR ANY OF ITS SUPPLIERS SHALL BE RESPONSIBLE OR LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY, PUNITIVE OR OTHER DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS, LOSS OF DATA OR LOST PROFITS), UNDER ANY CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHER THEORY ARISING OUT OF OR RELATING IN ANY WAY TO THE IPG SOFTWARE EVEN IF IPG OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. YOUR SOLE REMEDY FOR DISSATISFACTION WITH THE IPG SOFTWARE IS TO STOP USING THE IPG SOFTWARE. THE SOLE AND EXCLUSIVE MAXIMUM LIABILITY TO IPG FOR ALL DAMAGES, LOSSES AND CAUSES OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE) OR OTHERWISE, SHALL BE THE TOTAL AMOUNT PAID BY YOU, IF ANY, FOR USE OF THE IPG SOFTWARE. THESE LIMITATIONS MAY NOT APPLY TO YOU UNDER THE LAWS OF CERTAIN JURISDICTIONS.

The foregoing limitations will apply even if the above stated remedy fails of its essential purpose.

8. **Export Law Assurances.** You acknowledge that IPG Software is subject to U.S. and European Union export jurisdiction. You agree to comply with all applicable international and national laws that apply to the IPG Software, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.

9. **Government End Users.** The IPG Software and related documentation are "Commercial Items", as that term is defined at 48 C.F.R. §2.101, consisting of "Commercial Computer Software" and "Commercial Computer Software Documentation", as such terms are used in 48 C.F.R. §12.212 or 48 C.F.R. §227.7202, as applicable. Consistent with 48 C.F.R. §12.212 or 48 C.F.R. §227.7202-1 through 227.7202-4, as applicable, the Commercial Computer Software and Commercial Computer Software Documentation are being licensed to U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein. Unpublished-rights reserved under the copyright laws of the United States.

10. Controlling Law and Severability. This License will be governed by and construed in accordance with the laws of the State of Massachusetts, as applied to agreements entered into and to be performed entirely within Massachusetts between Massachusetts residents. This License shall not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If for any reason a court of competent jurisdiction finds any provision, or portion thereof, to be unenforceable, the remainder of this License shall continue in full force and effect.

11. Complete Agreement; Governing Language. This License constitutes the entire agreement between the parties with respect to the use of the IPG Software licensed hereunder and supersedes all prior or contemporaneous understandings regarding such subject matter. No amendment to or modification of this License will be binding unless in writing and signed by IPG. Any translation of this License is done for local requirements and in the event of a dispute between the English and any non-English versions, the English version of this License shall govern.

If your product includes Microsoft Corporation embedded software, then the following applies:

MICROSOFT CORPORATION EMBEDDED SOFTWARE END USER LICENSE AGREEMENT

You have acquired a device ("EQUIPMENT") that includes software licensed by IPG Photonics Corporation or its affiliates (collectively, "IPG") from an affiliate of Microsoft Corporation ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. IPG, MS and its suppliers (including Microsoft Corporation) own the title, copyright, and other intellectual property rights in the SOFTWARE. The SOFTWARE is licensed, not sold. All rights reserved.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE EQUIPMENT OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT IPG FOR INSTRUCTIONS ON RETURN OF THE UNUSED EQUIPMENT(S) FOR A REFUND. **ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE OF THE EQUIPMENT, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).**

This EULA is valid and grants the end-user rights ONLY if the SOFTWARE is genuine and a genuine Certificate of Authenticity for the SOFTWARE is included. For more information on identifying whether your software is genuine, please see <http://www.microsoft.com/piracy/howtotell>.

GRANT OF SOFTWARE LICENSE. This EULA grants you the following license:

1. You may use the SOFTWARE only on the EQUIPMENT.
2. Restricted Functionality. You are licensed to use the SOFTWARE to provide only the limited functionality (specific tasks or processes) for which the EQUIPMENT has been designed and marketed by IPG. This license specifically prohibits any other use of the software programs or functions, or inclusion of additional software programs or functions that do not directly support the limited functionality on the EQUIPMENT. Notwithstanding the foregoing, you may install or enable on a EQUIPMENT, systems utilities, resource management or similar software solely for the purpose of administration, performance enhancement and/or preventive maintenance of the EQUIPMENT.
3. If you use the EQUIPMENT to access or utilize the services or functionality of Microsoft Windows Server products (such as Microsoft Windows Server 2003), or use the EQUIPMENT to permit workstation or computing devices to access or utilize

the services or functionality of Microsoft Windows Server products, you may be required to obtain a Client Access License for the EQUIPMENT and/or each such workstation or computing device. Please refer to the end user license agreement for your Microsoft Windows Server product for additional information.

4. NOT FAULT TOLERANT. THE SOFTWARE IS NOT FAULT TOLERANT. IPG HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE EQUIPMENT, AND MS HAS RELIED UPON IPG TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.

5. NO WARRANTIES FOR THE SOFTWARE. THE SOFTWARE is provided "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE EQUIPMENT OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.

6. No Liability for Certain Damages. EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).

7. Restricted Uses. The SOFTWARE is not designed or intended for use or resale in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or other devices or systems in which a malfunction of the SOFTWARE would result in foreseeable risk of injury or death to the operator of the equipment or system, or to others.

8. Limitations on Reverse Engineering, Decompilation, and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

9. SOFTWARE as a Component of the Equipment-Transfer. This license may not be shared, transferred to or used concurrently on different computers. The SOFTWARE is licensed with the EQUIPMENT as a single integrated product and may only be used with the EQUIPMENT. If the SOFTWARE is not accompanied by

EQUIPMENT, you may not use the SOFTWARE. You may permanently transfer all of your rights under this EULA only as part of a permanent sale or transfer of the EQUIPMENT, provided you retain no copies of the SOFTWARE. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE. This transfer must also include the Certificate of Authenticity label. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the SOFTWARE must agree to all the EULA terms.

10. Consent to Use of Data. You agree that MS, Microsoft Corporation and their affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. MS, Microsoft Corporation and their affiliates may use this information solely to improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation and their affiliates may disclose this information to others, but not in a form that personally identifies you.

11. Internet Gaming/Update Features. If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally identifies you.

12. Internet-Based Services Components. The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation or their affiliates may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your EQUIPMENT. Microsoft Corporation or their affiliates do not use these features to collect any information that will be used to identify you or contact you. For more information about these features, please see the privacy statement at <http://go.microsoft.com/fwlink/?LinkId=25243>.

13. Links to Third Party Sites. You may link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of MS or Microsoft Corporation, and MS or Microsoft are not responsible for the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites. MS or Microsoft Corporation is not responsible for webcasting or any other form of transmission received from any third party sites. MS or Microsoft Corporation are providing these links to third party sites to you only as a convenience, and the inclusion of any link does not imply an endorsement by MS or Microsoft Corporation of the third party site.

14. **Notice Regarding Security.** To help protect against breaches of security and malicious software, periodically back up your data and system information, use security features such as firewalls, and install and use security updates.
15. **No Rental/Commercial Hosting.** You may not rent, lease, lend or provide commercial hosting services with the SOFTWARE to others.
16. **Separation of Components.** The SOFTWARE is licensed as a single product. Its component parts may not be separated for use on more than one computer.
17. **Additional Software/Services.** This EULA applies to updates, supplements, add-on components, product support services, or Internet-based services components ("Supplemental Components"), of the SOFTWARE that you may obtain from IPG, MS, Microsoft Corporation or their subsidiaries after the date you obtain your initial copy of the SOFTWARE, unless you accept updated terms or another agreement governs. If other terms are not provided along with such Supplemental Components and the Supplemental Components are provided to you by MS, Microsoft Corporation or their subsidiaries then you will be licensed by such entity under the same terms and conditions of this EULA, except that (i) MS, Microsoft Corporation or their subsidiaries providing the Supplemental Components will be the licensor with respect to such Supplemental Components in lieu of the "COMPANY" for the purposes of the EULA, and (ii) TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE SUPPLEMENTAL COMPONENTS AND ANY (IF ANY) SUPPORT SERVICES RELATED TO THE SUPPLEMENTAL COMPONENTS ARE PROVIDED AS IS AND WITH ALL FAULTS. ALL OTHER DISCLAIMERS, LIMITATION OF DAMAGES, AND SPECIAL PROVISIONS PROVIDED BELOW AND/OR OTHERWISE WITH THE SOFTWARE SHALL APPLY TO SUCH SUPPLEMENTAL COMPONENTS. MS, Microsoft Corporation or their subsidiaries reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.
18. **Recovery Media.** If SOFTWARE is provided by IPG on separate media and labeled "Recovery Media" you may use the Recovery Media solely to restore or reinstall the SOFTWARE originally installed on the EQUIPMENT.
19. **Backup Copy.** You may make one (1) backup copy of the SOFTWARE. You may use this backup copy solely for your archival purposes and to reinstall the SOFTWARE on the EQUIPMENT. Except as expressly provided in this EULA or by local law, you may not otherwise make copies of the SOFTWARE, including the printed materials accompanying the SOFTWARE. You may not loan, rent, lend or otherwise transfer the backup copy to another user.
20. **End User Proof of License.** If you acquired the SOFTWARE on a EQUIPMENT, or on a compact disc or other media, a genuine Microsoft "Proof of License"/ Certificate of Authenticity label with a genuine copy of the SOFTWARE identifies

Warranty

MICROSOFT CORPORATION EMBEDDED SOFTWARE END USER LICENSE AGREEMENT

a licensed copy of the SOFTWARE. To be valid, the label must be affixed to the EQUIPMENT, or appear on IPG's software packaging. If you receive the label separately other than from IPG, it is invalid. You should keep the label on the EQUIPMENT or packaging to prove that you are licensed to use the SOFTWARE.

21. Product Support. Product support for the SOFTWARE is not provided by MS, Microsoft Corporation, or their affiliates or subsidiaries. For product support, please refer to IPG support number provided in the documentation for the EQUIPMENT. Should you have any questions concerning this EULA, or if you desire to contact IPG for any other reason, please refer to the address provided in the documentation for the EQUIPMENT.

22. Termination. Without prejudice to any other rights, IPG may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

23. EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is subject to U.S. and European Union export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments. For additional information see <http://www.microsoft.com/exporting>.

Product Returns

Returns to the United States

All product returns require a Return Merchandise Authorization (RMA) from IPG.

To obtain an RMA, call the Customer Service department of IPG Photonics Corporation at 508-373-1100 (US) or +49 2736 44 20 451 (Germany).

If you return a product with a RMA, please perform the following procedure:

1. Products must be carefully packed in a suitable shipping container(s). Buyer assumes all responsibility for products damaged in shipment to IPG.
2. Buyer must issue a purchase order for the value of the replaced parts/service items and IPG will issue credit or invoice when the parts/service is received. Speak to IPG Service Manager for the amount authorized under the required purchase order.
3. All requests for repair or replacement under this warranty must be made to IPG within 30 days after discovery of the defect (but not later than 7 days after warranty expiration).
4. All products returned to IPG but which meet applicable specifications, not defectively manufactured or used not in accordance with this User's Guide, will result in the Buyer being charged IPG's standard examination charge.
5. Complete packing list with product model and serial number will ensure prompt repair.
6. Be sure to include with the returned product your 'ship to' address for the return of the serviced product.

Shipping Instructions:

Warranty Returns

Domestic & International Buyers* pay for one-way freight costs and insurance to IPG. IPG will pay for freight return cost and insurance back to the Buyer.

Non-Warranty Returns

Domestic & International Buyers* pay for two-way freight costs and insurance to IPG. If shipment consists of returns that are both warranty and non-warranty, the shipment will be considered as non-warranty.

Shipping address for returns to US:

IPG Photonics Corporation

50 Old Webster Road

Oxford, MA 01540

Attn: Product Returns

Tel: 508-373-1100

Returns to Germany

Shipping address for returns to Germany:

IPG Laser GmbH

Siemensstrasse 7

D-57299 Burbach, Germany

Attn: Product Returns

Tel: +49-(0)2736-44-20-451

1. IPG Laser GmbH will only accept returns for which an approved Return Material Authorization (RMA) has been issued by IPG Laser GmbH. You should address to the customer support team at +49-(0)2736-44-20-451 or support.europe@ipg-photonics.com to discuss the return and request an RMA number. You must return defective products freight prepaid and insured to IPG Laser at the address shown herein. All products which have returned to IPG Laser but which are found to meet all previously applicable specifications for such products or which indicate damage to the fiber connectors not resulting from defect manufacturing, shall be subject to IPG Laser' standard examination charge in effect at the time and these costs shall be charged to the Buyer. All products returned to IPG Laser which are not accompanied by an itemized statement of defects, shall be returned to the Buyer at the Buyer's expense and IPG Laser shall not carry out any evaluation of such products. IPG Laser warrants to Buyer that its services, labor and replacement parts, assemblies and modules will be free of defects in material and workmanship for ninety (90) days from the date of shipment or performance of services.
2. Warranty Returns - Domestic & *International Buyers should pay for one-way freight costs to IPG Laser. IPG Laser will reimburse Buyers for applicable reasonable third-party freight costs and IPG Laser will pay for freight return cost back to the Buyer.
3. Non-Warranty Returns - Domestic & *International Buyers are responsible for two-way freight costs. If shipment consists of returns that are both warranty and non-warranty, the shipment will be considered as non-warranty. Any UNAUTHORIZED shipments billed to IPG Laser without authorization will be re-invoiced to the Buyer. Confirming purchase orders are required for non-warranty returns.

Product Returns
Returns to Germany

4. *International Returns must include applicable DUTIES AND TAXES, and you must mark air bills with "RETURNED FOR REPAIR." In any event, where IPG Laser accepts a shipment, IPG Laser will invoice to the Buyer for any charges as stated above.
5. Returns for credit will not be accepted unless authorized in advance, in writing by IPG Laser, in accordance with IPG Laser' Terms and Condition, including the warranty provisions. In most cases, restocking fees will apply.
6. All returns must be packaged adequately to avoid damage during shipment.
7. Complete packing list with product model and serial number will insure prompt repair, if the other terms of this form are followed.
8. See the IPG Terms and Conditions for the applicable warranty for the products before you request the return of the products.
9. RMA number will expire 31 days after the date of issue. Thereafter, units received in under the expired RMA number will result in a longer turnaround time. Include a copy of the completed RMA form with the return of your unit(s).

Glossary

°C	Degrees centigrade or Celsius
°F	Degrees Fahrenheit
λ	Lambda (wavelength symbol)
μs	Microsecond = 10^{-6} second
Amp	Amperes
AC	Alternating current
ADC	Analog-to-digital converter
ASCII	American Standard Code for Information Interchange (U.S. Government)
BTU	British thermal unit
CAN	Controller Area Network
CDRH	Center for Devices and Radiological Health (U.S. Government)
CFR	Code of Federal Regulation (U.S. Government)
cm	Centimeters = 10^{-2} meters
CPU	Central processing unit
CW	Continuous wave (operating mode)
DC	Direct current
EN	European Norm
Hz	Hertz or cycles per second (frequency)
kg	Kilograms
kV	Kilovolts = 10^3 volts
kW	Kilowatts = 10^3 watts

Glossary

l	Liters (volume)
lbs	Pounds
IP	Internet protocol
LD	Laser diode
LCD	Liquid crystal display
LED	Light emitting diode
nm	Nanometer = 10^{-9} meters
mA	Milliamps = 10^{-3} amperes
mm	Millimeter = 10^{-6} meters
MHz	Megahertz = 10^6 Hertz
mrad	Milliradian = 10^{-3} radians (geometry)
rms	Root mean square or quadratic mean
QCW	Quasi-Continuous wave (operating mode)
TCP	Transmission control protocol
VAC	Voltage alternating current
VDC	Volts Direct Current
W	Watts (power)

Index

Numerics

25-Pin Female XY2-100 Sockets ... 2-20
25-Pin Laser Control Pinouts ... 2-18
37-Pin I/O Pinouts ... 2-30
37-Pin I/O Pinouts for Motor Control Interface ... 6-13
5-Pin Male Power Supply ... 2-24
9-Pin Female RS-232 DB9 Sockets ... 2-32
9-Pin Female Signal Sockets ... 2-22
9-Pin Male RS-232 DB9 Pinouts ... 2-23

C

cables connections ... 2-12
Calibration Files ... 2-12
Certification ... 1-2
configurations for optical scanner head ... 2-7
configuring a LAN connection ... 3-20
connecting cables ... 2-12

D

DB 5W5 Connector ... 2-26
DB 5W5 connector ... 2-14
DHCP IP address configuration ... 3-20

E

Electrical Safety ... 1-14
Environmental Safety ... 1-14
Ethernet Interface ... 2-24

F

Fiber Interlock Loop ... 1-15
Field Size ... 2-8
Focal Length ... 2-8
Fume Extraction System ... 1-2

I

Interface Commands ... 5-1
IP address configuration ... 3-20

L

LAN connection ... 3-20
Laser Control Pinouts ... 2-30
Laser Control pinouts ... 2-18
Laser Marker Setup Example ... 2-11
Lens Options ... 2-8
license key ... 3-15

M

Marking Parameters ... 4-6
Miscellaneous Signal Sockets ... 2-22
Motor Control Interface ... 6-11
Mounting ... 2-10

O

Optical Safety ... 1-13
Optical Scanner Head ... 2-7
 bolt pattern ... 2-9
 configurations ... 2-7
 field center ... 2-9
Optimization Parameter ... 4-6

P

Pitch Parameter ... 4-6
Power Requirements ... 2-26
 XY2-100 Version ... 2-14
Power Supply Pinouts ... 2-26
 XY2-100 Version ... 2-14
Product Returns ... D-1
Pulse Energy Parameter ... 4-6

R

rear panel
 Integrated Scan Controller Version ... 2-24
 XY2-100 Version ... 2-13
returns ... D-1
RS-232 Configuration ... 5-1
RS-232 DB-9 Pinouts ... 2-7, 2-23
RS-232 DB-9 pinouts ... 2-32

S

- Safety Features ... 1-15
- Safety Information ... 1-3
- Safety Instructions ... 1-12
- Safety Label Locations ... 1-5
- Scan Controller
 - Host Name ... 3-30
 - static IP address ... 3-30
- Scan Controller Upgrade Utility
 - installing ... 3-24
 - running ... 3-29
- ScanPack Installation ... 3-2
- Single-Supply Operation ... 2-17, 2-29
- Specifications ... 2-3
- Split-Supply Operation ... 2-16, 2-28
- Spot Size ... 2-8
- Stage Configuration Utility
 - Installing ... 6-2
 - Running ... 6-6
- static IP address configuration ... 3-30

T

- Table ... 6-13, 6-16, 6-17, 6-18

U

- Unpacking Instructions ... 2-5
- USB Memory Stick ... 2-5

W

- WinLase 6
 - Activating ... 3-15
 - Installation ... 3-9
 - Quick Start ... 4-1
- Working Distance ... 2-8

X

- XY2-100 sockets ... 2-20

Z

- Z Stage Positioner ... 1-2



To learn more, visit www.ipgphotonics.com

© Copyright 2015 IPG Photonics Corporation

This user guide and any data disclosed therein is the property of IPG Photonics Corporation and its affiliates, and constitutes and contains proprietary information. Neither receipt nor possession of this document confers or transfers any right to duplicate, use, or disclose any information contained herein except as expressly authorized in writing by IPG Photonics Corporation. No representations and warranties are made hereby, except in a binding purchase order.

Part Number
P21-010109