




# IPGScan Software

---

## User Manual



Part Number: DOCOXUGGUIXX0001  
Published: 8/10/2018  
Revision: 1  
DCO: 2387

## Disclaimer Notice

© IPG Photonics Corporation 2018. All rights reserved. You may not copy, reproduce, transmit, store in a retrieval system or adapt this publication, in any form, in any media or by any means, without the prior written permission of IPG Photonics Corporation (IPG), except as allowed under applicable copyright laws. Permitted copies shall bear the same copyright and proprietary notices which were contained on the original version.

This User Guide is provided "as is" and is subject to change and revision without notice. IPG believes that the information provided is accurate and reliable; however IPG makes no warranty or representation, express or implied, regarding this document, including without limitation any implied warranties of merchantability or fitness for a particular use, purpose or application, either alone or in combination with any other device, equipment, apparatus, materials or process. Users must take full responsibility for their application of any products.

Further, IPG does not assume responsibility for use of the information contained in this document or for any infringement of patents or other rights of third parties that may result from its use. IPG shall not be liable for errors in or omissions from this document or for any incidental, consequential, indirect or special damages, including without limitation, lost profits, lost production costs or similar damages, in connection with the furnishing, performance or use of this material.

IPG grants no license, directly or indirectly, under any patent or other intellectual property rights from use of the information provided herein.

IPG, IPG Photonics and the IPG Logo are registered trademarks of IPG Photonics Corporation. We have identified words that we consider as trademarks. Neither the presence nor absence of trademark identifications affects the legal status of any trademarks.

## PATENT RIGHTS

This product may be patented in one or more jurisdictions. See the product for more information.

## Export, Import and Customs Control Compliance (For US Products Only)

IPG is committed to complying with U.S. and foreign export, import and customs requirements. Export and re-export of lasers and other products manufactured by IPG are subject to U.S. and foreign laws and regulations, including the US Export Administration Regulations administered by the Department of Commerce, Bureau of Industry and Security. The applicable restrictions vary depending on the specific product involved, intended application, the product destination and the intended user. In some cases, an individual validated export license is required from the US Department of Commerce prior to resale or re-export of certain products.

You are ultimately responsible for exporting any IPG product in accordance with the Export Administration Regulations and the U.S. Customs and Border Protection Regulations. IPG recommends that you obtain your own legal advice when attempting to export. All export and custom classifications and information provided by IPG is subject to change without notice. IPG makes no representation as to the accuracy or reliability of the classification information provided. The stated classification only applies to equipment as it left the IPG factory. Any modifications or changes after leaving the IPG facility will be your responsibility to obtain further classifications. IPG is in no way responsible for any damages whether direct, consequential, incidental, or otherwise, suffered by you as a result of using or relying upon such classifications, groups, or symbols for any purpose whatsoever.

Information relating to U.S. export rules and regulations can be found at the U.S. Bureau of Industry and Security Website. Information related to U.S. Customs and Border Protection can be found at the U.S. Customs Website.

# Table Of Contents

<b>1. Overview</b> .....	<b>1</b>
1.1 Requirements.....	1
<b>2. Software Installation</b> .....	<b>2</b>
2.1 Installing IPG ScanPack .....	2
2.2 Installing IPGScan .....	8
<b>3. Scan Controller Utility</b> .....	<b>13</b>
3.1 Installing IPG Scan Controller Utility .....	13
3.2 Running the Scan Controller Utility .....	15
3.2.1 Loading Configuration Files .....	16
<b>4. System Security</b> .....	<b>18</b>
4.1 Overview .....	18
4.2 Setting-Up Users and Groups .....	18
4.2.1 Manually Adding User Groups Using Windows Manager .....	18
4.2.2 Adding Users Using Windows Manager.....	19
4.3 Security Settings in IPGScan.....	22
<b>5. IPGScan Software</b> .....	<b>23</b>
5.1 Starting the IPGScan Software .....	23
5.2 IPGScan Overview.....	24
5.3 System Settings .....	25
5.4 Creating a Job.....	26
5.5 Process Features and Tools .....	27
5.5.1 Copy and Pasting Objects.....	28
5.5.2 Moving an Object .....	28
5.5.2.1 Object Properties .....	29
5.5.2.2 Nudge Tool.....	29
5.5.2.3 Manual Selection of Objects .....	30
5.5.2.4 Guide Laser Positioning .....	30
5.6 Modifying Object Properties.....	30
5.6.1 General Properties .....	30
5.6.1.1 Applied Offsets.....	32
5.6.2 Welding Properties.....	33
5.6.2.1 Wobble .....	34
5.6.2.2 Energy Offset .....	34
5.6.3 Marking Properties .....	35
5.6.4 Cleaning Properties.....	35
5.6.4.1 Laser Table .....	36
5.7 Creating a Parameter Profile .....	38
5.8 Action Controls and Groups.....	39
5.8.1 No Action.....	39
5.8.2 User Action.....	39
5.8.3 Delay Action .....	39
5.8.4 Streaming Data Action .....	40
5.8.5 Reset Tracking .....	40
5.8.6 Set Coordination Flags.....	40
5.8.7 Set Coordination Mode .....	40
5.8.8 Wait .....	41
5.8.9 Go To Group .....	41
5.8.10 Write Register .....	41
5.8.11 Park At Action .....	41
5.8.12 Load Register.....	41
5.8.13 Stage Motion Action .....	43

5.8.14 Exit Action .....	43
5.9 Previewing and Running an IPGScan Job .....	43
<b>6. Digital Camera .....</b>	<b>45</b>
6.1 Installing a Digital Camera .....	45
6.2 Configuring the Digital Camera Options .....	45
6.3 Connecting to a Digital Camera .....	45
6.4 Starting the Camera .....	46
6.5 Scanning Workspace with the Camera .....	47
6.6 Stopping the Camera .....	47
6.7 Adjusting the Camera Image to the Center of View .....	47
<b>7. Robotic Point &amp; Shoot .....</b>	<b>49</b>
7.1 Overview .....	49
7.2 IPGScan Configuration Parameters .....	49
7.3 Robot Software .....	50
7.3.1 Special Cases .....	51
7.3.1.1 FANUC .....	51
7.3.1.2 Yaskawa Motoman .....	51
7.3.1.3 KUKA .....	51
7.3.1.4 ABB .....	51
7.3.2 Sequence of Events .....	51
7.3.3 Example Program .....	52
<b>8. Coordinated Stage Motion .....</b>	<b>53</b>
8.1 Overview .....	53
8.2 IPGScan Configuration Parameters .....	53
8.3 IPGScan Software .....	53
<b>9. Robotic On-The-Fly .....</b>	<b>54</b>
9.1 Overview .....	54
9.2 Connections/Robot Software .....	54
9.2.1 Scanner Requirements .....	54
9.2.2 Robot Requirements .....	54
9.3 Robot Controllers .....	54
9.4 Robot Setup .....	54
9.4.1 FANUC .....	55
9.4.1.1 KAREL .....	55
9.4.2 Yaskawa Motoman .....	55
9.4.3 KUKA .....	55
9.5 Robot Options in IPGScan .....	56
9.6 IPGScan Workspace Calibration .....	57
9.6.1 IPGScan Workspace Calibration with a KUKA Robot .....	59
9.7 Creating an IPGScan On-The-Fly Job .....	59
9.8 Using Coordination Flags .....	59
9.8.1 Selecting Coordination Flags .....	60
9.8.1.1 FANUC .....	60
9.8.1.2 Yaskawa Motoman .....	60
9.8.1.3 KUKA .....	61
9.8.2 Setting the Coordination Flag Action Control .....	61
9.9 Object Placement and Trajectory Building .....	61
9.9.1 Snap To .....	61
9.9.2 Alignment .....	61
9.9.3 Alignment with Robot Pendant .....	62
9.10 On-The-Fly Robot Programming Setup .....	63
9.10.1 KUKA On-The-Fly Programming .....	63

9.11 Recording a Trajectory.....	64
9.12 Loading a Trajectory .....	64
9.13 Testing an On-The-Fly Job .....	64
9.14 Executing an On-The-Fly Job .....	65
9.14.1 Looping an On-The-Fly Job .....	65
<b>10. Errors .....</b>	<b>66</b>
<b>A. Service and Support .....</b>	<b>67</b>
A.1 Technical Support.....	67
<b>B. Warranty .....</b>	<b>68</b>
B.1 Limited Express Product Warranties .....	68
B.2 Warranty Limitations.....	68
B.3 Limitation of Remedies and Liabilities .....	69
B.4 Software .....	69
B.4.1 Firmware License Agreement.....	69
B.5 Software License Agreement for LaserNet™ .....	71
B.6 Microsoft Corporation Embedded Software End User License Agreement.....	73
<b>C. Product Returns .....</b>	<b>77</b>
C.1 Returns to the United States .....	77
C.1.1 Shipping Instructions: .....	77
C.2 Returns to Germany .....	78
C.2.1 Shipping Instructions: .....	78
<b>D. Stage Configuration Software .....</b>	<b>79</b>
<b>Glossary .....</b>	<b>81</b>

# 1.0 Overview

IPGScan and the Scan Controller seamlessly interface to IPG lasers. With the addition of the application software, IPG is able to offer a complete remote solution to Integrators and OEMs.

## 1.1 Requirements

The following requirements are necessary for installation and use of the IPGScan software

- Windows 7 & 10, Professional or higher
- IPG ScanPack software
- IPGScan (for Welding, Marking or Cleaning applications)

## 2.0 Software Installation

### 2.1 Installing IPG ScanPack

You need to install IPG ScanPack to use IPGScan with your scanner system.

ScanPack is a DLL file in which IPGScan interfaces for communicating with the Scan Controller over Ethernet. The ScanPack installation installs Bonjour (a protocol that discovers IP addresses over the network), Microsoft Visual C++ Runtime Libraries, and the ScanPack DLL on your system.


Before installing IPG ScanPack, uninstall any previous versions, if applicable.

To install IPG ScanPack:

1. Open a web browser and go to “[software.ipgphotonics.com](http://software.ipgphotonics.com)”.
2. Click the “**ScannerCommon**” folder.
3. Click the “**ScanPack**” folder.
4. Download the ScanPack.zip file to your computer.
5. Once downloaded, extract the ScanPack.zip file. A folder called ScanPack is created.
6. Open the folder and run **setup.exe** and click “**Next**”. The Bonjour EULA Window appears as shown in Figure 2.1.


**Note:** The MSI file will not automatically install Bonjour or Visual C++.

Figure 2.1 ScanPack Bonjour EULA Window



7. Click “**Accept**” to accept the license agreement. The following dialog box appears as shown in Figure 2.2.

Figure 2.2 Visual C++ Runtime Libraries Installation



8. Click **"Install"** to install Visual C++ 2010 Runtime Libraries to your system. The following status message appears.
  - a. If the computer already has Microsoft Visual C++ 2010 x86 installed, a prompt to repair or remove the installation will appear. Select "Repair" and click **"Next"**. Figure 2.3 shows this window.

Figure 2.3 Status Message Window






Figure 2.4 Visual C++ Repair






9. Next, the **Microsoft Visual C++ 2010x86 Redistributable Setup** window appears as shown in Figure 2.5.

Figure 2.5 Microsoft Visual C++2010 x86 Redistributable Setup Window




10. Click "I have read and accept the license terms." and click "Install". The following window appears with the **Microsoft Visual C++ 2010 x86 Redistributable** installation progress as shown in Figure 2.6.

Figure 2.6 Installation Progress Window



11. Next, the "Installation Is Complete" window appears as shown in Figure 2.7.


Figure 2.7 Installation Complete Window



12. Click "Finish".


13. A Bonjour window should appear to show it's installing, Figure 2.8.

Figure 2.8 Bonjour Installer




14. The **ScanPack Setup Wizard** appears as shown in Figure 2.9.

Figure 2.9 ScanPack Setup Wizard Window




15. Click "**Next**" to proceed. The "**Select Installation Folder**" window appears, as shown in Figure 2.10.

Figure 2.10 ScanPack Setup - Select Installation Folder




16. Click **Next** to accept the default folder.
  - a. Click **Browse** if you want to change the default folder to another location.
  - b. Click **Everyone** to allow all users to have access to the ScanPack DLL or **Just Me** if only you want access.
17. Click **Next** to begin installation. The **Installation Progress** window appears, as show in Figure 2.11.

Figure 2.11 Installation Progress Window



18. Click **Next** to proceed. The **Installation Complete** window appears, as shown in Figure 2.12.

Figure 2.12 Installation Complete Window



19. Click “**Close**” to exit the program. ScanPack is successfully installed on your system.


## 2.2 Installing IPGScan

Before installing IPGScan, you need to uninstall any previous versions if applicable.

To install the IPGScan software:


1. Open a web browser and go to **software.ipgphotonics.com**.
2. Click the “**ScannerSoftware**” folder. Click the “**IPGScan**” folder.
3. Download the installation IPGScan zip file to your computer.
4. Once downloaded, extract the zip file. A folder is created.
5. Open the folder and run **setup.exe**. The **Setup Wizard** appears, as shown in Figure 2.13.

Figure 2.13 Setup Wizard



6. The next menu will have two options shown in Figure 2.14.
  - a. **"Bypass User Security"**: automatically skips the login and password requirement when IPGScan is started.
  - b. **"Start When Computer Starts"**: automatically start IPGScan when the computer starts.

Figure 2.14 Select Settings




7. Click **"Next"**. Now select which **mode(s)** to install (Figure 2.15). On this window you can install any of the IPGScan modes, including all of them at the same time.

**Note:** The main difference between the welding, cleaning and marking modes is how the laser parameters are defined. You can access all the features in each mode; however the


default setup will be which program you run. If you install multiple modes, there will be different ".exe" for each.

Figure 2.15 Select IPGScan mode: Welding, Cleaning, Marking




8. Click "**Next**". The **installation path** for IPGScan can be set in this window, Figure 2.16.

Figure 2.16 Select Installation Path



9. Click "**Next**". The **Confirm Installation** window will appear, as shown in Figure 2.17.


Figure 2.17 Confirm Installation Window



10. Click "**Next**" to proceed.

11. The **Installing IPGScan** window appears, as shown in Figure 2.18.


Figure 2.18 Installation IPGScan Window



12. When the installation is complete the User Groups window, shown in Figure 2.19, will appear. If IPGScan was previously installed, no restart is required. For more information on user groups see Section 4.2.



Figure 2.19 User Groups have been Created Window



## 3.0 Scan Controller Utility


### 3.1 Installing IPG Scan Controller Utility

Users can set a static IP address and change the host name of the Scan Controller using the Scan Controller Utility. The Scan Controller Utility also lets you select the correct configuration files for use in IPGScan.

To install the Scan Controller Utility:


1. Open a web browser and go to **software.ipgphotonics.com**.
2. Click the **ScannerCommon** folder.
3. Click the **Utilities** folder.
4. Download the **ScanControllerUtility.zip** file to your computer.
5. Once downloaded, extract the **Utilities.zip** file. A folder called Utilities is created.
6. Open the folder and run **setup.exe** and click “**Next**”. The following window appears as shown in Figure 3.1.

Figure 3.1 Scan Controller Utility Window




7. Click “**Next**”. The **Select Installation Folder** window will appear as shown in Figure 3.2.

Figure 3.2 Select Installation Window




8. Click **“Next”** to accept the default folder.
  - a. Click **Browse** if you want to change the default folder to another location.
  - b. Click **Everyone** to allow all users to access the Scan Controller Utility or **Just me** if only you want access.
9. Click **“Next”**. The Confirm Installation window appears as shown in Figure 3.3.

Figure 3.3 Confirm Installation Window




10. Click **“Next”** to continue with installation. The installation progress window appears as shown in Figure 3.4.

Figure 3.4 Installation Progress Window



11. Click "**C**lose" to complete installation as shown in Figure 3.5.

Figure 3.5 Installation Complete Window




## 3.2 Running the Scan Controller Utility

To run the Scan Controller Utility:


1. Select All Programs → Scan Controller Utility (Figure 3.6).

Figure 3.6 Scan Controller Utility Program



2. The Scan Controller Utility window appears as shown in Figure 3.7. The Scan Controller hostname automatically appears in the Scan Controllers List (this may take several seconds). Lock a scan controller to enable the controls to the right.

Figure 3.7 Scan Controller Utility Window



3. See “**Loading the Configuration Files**” for instructions on selecting a scanner and loading the configuration file for use with IPGScan.
4. Apply Changes button is only for changing the IP Address. In order to change the scanner’s name you must press “**Enter**”.
5. “To use a static IP Address for the Scan Controller, navigate to the **Change Network Settings** box on the right. Enter an IP address in the **IP Address** box. Then enter a Net Mask in the **Net Mask** box underneath. Click “**Apply**”.
6. Click “**Exit**” to close the Scan Controller Utility.

### 3.2.1 Loading Configuration Files

To load the laser configuration files:

1. Start the Scan Controller Utility. The Scan Controller Utility window appears as shown in Figure 3.7.
2. Select a scanner from the list.
3. Click the “**Lock**” icon for the selected scanner.
4. To install the configuration file for the laser, click **Install Files**. The select file window will appear.
5. Go to the following path: **C:\ProgramData\IPGP\ScanPack\Default\Lasers** and select the folder for the laser you are using. Within that folder, select the **Laser Specifications** file and click “**Open**”.
6. Once the configuration file is transferred, click exit to close the Scan Controller Utility.

If the **focus lens** is changed, the lens configuration files will need to be changed. To install the configuration files for the focus lens, follow the same steps above, except, load files “Calibration 1” and “Calibration 2” under **C:\ProgramData\IPGP\ScanPack\Default\Lenses**.

**Note:** Both files are required! One file is for the actual laser beam, while the other is for the guide beam.

**Note:** If you are using different lasers or focus lenses with your scanner, you need to change the configuration file each time you change the laser or the focus lens. Make sure to back up old configuration files before reloading new files.

# 4.0 System Security

## 4.1 Overview

IPGScan offers the ability for Users and Groups to have different levels of access. The primary user has the ability to choose what privileges each group has, whether operator, technician, supervisor, or engineer. A Windows user with administrative rights is required to create and assign users to groups.

## 4.2 Setting-Up Users and Groups

Before starting the IPGScan software, you need to set up groups using Windows Manager. Groups can be differentiated based on frequency of use, subsets of product functions used, technical expertise, security, privilege levels, educational level, or experience.

Options and features available in IPGScan are configurable based on groups. If preferred, this option may be omitted with the “**Bypass User Security**” option shown in Section 2.2.


**Note:** In IPGScan/IPGWeld versions 1.0.0.5045 or newer, the installer creates the four user groups automatically. In this case, you can skip Section 4.2.1.

### 4.2.1 Manually Adding User Groups Using Windows Manager

To add user groups:


1. Ensure you have Administrator rights.
2. Open Windows User Manager by clicking the **Start Menu** → **Run** and entering: **lusrmgr.msc**.
3. Click on the “**Groups**” folder in the left pane as shown in Figure 4.1.

Figure 4.1 Selecting A Group



4. Right click and select "**New Group**". The **New Group** window, Figure 4.2, will appear. You need to create the following four groups. Each groups is a different security level in IPGScan.

Figure 4.2 New Group Window



5. For each new group, Click "**Create**" on the **New Group** window to create the group, Figure 4.2.
6. To add users, see Section 4.2.2, Step 6.


#### 4.2.2 Adding Users Using Windows Manager

Both network and local users can be used. To add users to Windows groups:

1. Ensure you have Administrator rights.
2. Open Windows User Manager by clicking the **Start Menu** → **Run** and entering: **lusrmgr.msc**. The following window will appear:




Figure 4.3 Local Users and Groups Window




3. Click the **“Users”** folder in the left panel.
4. Right-click and select **“New User...”**. The New User window appears as shown in Figure 4.4.

Figure 4.4 New User Window




5. Enter a **Username**, **Password** and **Confirmed Password**. Click **“Create”**.
6. Once all users are created, click on the **“Groups”** folder in the left panel.
7. Double click on any of the four groups (**Engineer**, **Supervisor**, **Technician**, **Operator**) to add a user.
8. The group properties window will appear, shown in Figure 4.5.

Figure 4.5 Group Properties Window



9. Click **“Add”**.
10. Enter the names of the users on your **network** or **local** machine (Figure 4.6) on the Select Users Window.

Figure 4.6 Select Users Window



11. Click **“OK”** to complete.

12. Re-login into Windows or restart the computer for changes to take effect.

### 4.3 Security Settings in IPGScan

There are four security levels in IPGScan. From lowest security setting to highest:

- **Operator** - only can perform operations assigned to Operator
- **Technician** - only can perform operations assigned to Operator or Technician
- **Supervisor** - only can perform operations assigned to Operator, Technician or Supervisor
- **Engineer** - can perform any operations

Examples of different security settings:

1. If a processes permission level is set to Operator, all users with higher access (Technician, Supervisor and Engineer) will also be able to complete the process.
2. If a processes permission level is set to Supervisor, only Supervisors and Engineers can perform the process.

By default all settings are set to Engineer level. You can select View → Options → Security within IPGScan to modify these privileges.

# 5.0 IPGScan Software


## 5.1 Starting the IPGScan Software

The IPGScan software lets you create and modify welding, cleaning and marking jobs. You can create and modify welding objects such as text, shapes, and imported vector files.

To start the IPGScan program:


1. Ensure “**Setting-Up Users and Groups**”, Section 4.2 has been completed.
2. Go to Window’s Start Menu. Under **All Programs** → **IPG Photonics** folder.
3. Select **IPGScan**. The IPGScan Login window will appear, as shown in Figure 5.1.

Figure 5.1 IPGScan Login Window



4. Enter your user name and password.
  - a. If you added users on your **network**, enter the network domain name in the user name in the User Name box. *Example: XYZCompany-Domain\smith.*
  - b. If you added users on your **local drive**, enter the local computer name in the user name in the User Name box. *Example: MyPC\smith.*
  - c. If you were the last user logged in it will not ask you to login again.
5. Click “**Login**”. The IPGScan Workspace appears, as shown in Figure 5.2.

Figure 5.2 IPGScan Workspace



## 5.2 IPGScan Overview


This chapter explains how to use the IPGScan software for remote welding, cleaning or marking. IPGScan allows users to create jobs and operate the scanner in production. Users can also configure a digital camera.

Before you begin, ensure you have met the following requirements:

- Installed IPG ScanPack as explained in "Installing IPG ScanPack" (Section 2.1)
- Install IPGScan software as explained in "Installing IPGScan Software" (Section 2.2)
- Have your protective eyeglasses ready to wear when operating the laser.

The following Figure shows the IPGScan Software main window layout.

Figure 5.3 IPGScan Software Layout Window



Refer to Table 5.1 for IPGScan Software Layout Descriptions.

Table 5.1 New User Window

Number	Description
1	Job Tree
2	Tool Bar
3	Canvas Field of View
4	Data/Parameter Window
5	System Status
6	Logs
7	Laser System
8	Scan Controllers
9	Camera Window
10	Program Information
11	File Menu

### 5.3 System Settings

Before creating an IPGScan Program, it is important to have an understanding of the system settings and how users can adjust settings in IPGScan to fit their needs.

In order to access the IPGScan Options:

1. Click on “**View**”.
  - a. In the dropdown menu, users will find options for resetting the IPGScan layout.
  - b. The ability to open any status windows that may have been closed.
  - c. The “Options” (Alt+O) menu.

Under the Options menu, the following settings can be adjusted:


- **Settings:** The option menu contains a number of settings that the user can modify. Settings include:
  - IPGScan colors
  - Units (metric or standard)
  - Shape Parameter defaults
  - TCP/IP server information
  - Viewport settings
- **Canvas:** The canvas settings are where the user can go to adjust their InView window size. The canvas size can also be obtained by clicking the “Get Canvas Size” button under this menu.
- **Camera:** IPGScan has the ability to interface with an Ethernet camera. These settings are only needed for camera integration and setup. See Section 6 for Camera setup.
- **Robot:** The robot settings are only required for Robotic On-The-Fly. When using Point and Shoot, the user does not need to change any of these settings. See Section 9.0 for instructions on how to set up Robotic On-The-Fly.
- **Security:** The security settings are where privileges can be set for given user levels. By clicking on the setting name a description of the setting will show up at the bottom of the settings box. See Section 4.3 for more information.
- **Shapes Enabler:** This allows the user to select which features they would like to have displayed in the Tool Bar and Tool Menu.

## 5.4 Creating a Job

This section explains how to create a new job in IPGScan.

1. Select **File** → **New** to create a new job file. An unsaved and untitled job will appear as shown in Figure 5.4.


Figure 5.4 New Job Window



The Job Explorer pane displays the new job. When the job is selected, the type of job is listed in the Properties window to the right. Job types (Default / On The Fly) can be changed in this menu.

When you create multiple groups within a job, the job is divided into groups of objects. The default group names are G1, G2 and G3 shown in Figure 5.5. You can rename a group by double-clicking on it.

Figure 5.5 Job Explorer Pane



2. Select a group in the Job Explorer pane.
3. Select an object from the Tools menu to draw an object. Tool icons are available from the menu bar on the top right-side of the Main window.
  - a. Select the type of file (such as DXF and STL) from the Tools menu if you want to import a vector file. The Open dialog box appears where you can select the file to import.
4. Select **File** → **Save** to save and name your job.

## 5.5 Process Features and Tools

IPGScan includes a number of standard objects and features that can be used in the creation of jobs. Objects can be found in the Tool Bar, shown in Figure 5.6.

Figure 5.6 Tool Bar



Objects can also be found by clicking the “**Tools**” menu (Figure 5.7). Keyboard shortcuts for each object are also listed in the Tool Menu.

Figure 5.7 Tool Menu











	Point	Ctrl+Alt+P
	Point Array	Ctrl+Alt+A
	Line	Ctrl+Alt+L
	Circle	Ctrl+Alt+C
	Rectangle	Ctrl+Alt+R
	Spiral	Ctrl+Alt+S
	Zigzag	Ctrl+Alt+Z
	C Shape	Ctrl+Alt+E
	S Shape	Ctrl+Alt+X
	Text	Ctrl+Alt+T
	Text	Ctrl+Alt+H
	DXF	Ctrl+Alt+D
	STL	Ctrl+Alt+Y
	Image	Ctrl+Alt+I
	Barcode	Ctrl+Alt+B
	Multi Lines	Ctrl+Alt+Y
	Points	Ctrl+Alt+O
	Action Control	Ctrl+Alt+N

Clicking on a shape in either menu will place one of the selected shape onto the canvas. Action Controls will appear in the Job Tree to the left, but not on the canvas.

Other basic features are in Table 5.2.



Table 5.2 IPGScan Features and Shortcuts

Operator	Shortcut	Icon
New	Ctrl + N	
Open	Ctrl + O	
Close	Ctrl + F4	
Save	Ctrl + S	
Save As		
Options	Alt + O	
Copy	Ctrl + C	
Paste	Ctrl + V	
Undo		
Delete	(Delete button on Keyboard)	

### 5.5.1 Copy and Pasting Objects

To copy and paste objects:

1. Highlight one or more objects in the Job Explorer pane.
2. Select **Edit** → **Copy** or press **Ctrl+C**.
3. Select a group in the Job Explorer pane to paste the copied objects.
4. Select **Edit** → **Paste** or press **Ctrl+V**.
5. To delete an object, highlight one or more objects in the Job Explorer pane and press the **Delete** key on your keyboard.

**Note:** Only objects (Shapes and Action Controls) can be copied. Groups can not be copied.

### 5.5.2 Moving an Object

There are five options for moving an object:

#### Object Pose - Center and Rotation

- This allows the user to use a direct entry method by inputting coordinates that correspond to the scanners field of view.

#### Nudge

- A button with four arrows can be found at the top of the parameter window. This provides the user with a prompt box that allows the feature to be moved.

#### Manual Selection of Objects

- This method allows the user to click on the feature in the field of view and drag it using a mouse. (You cannot preview with the guide beam and use select by pick)

#### Guide Laser Positioning (Preview Positioning)

- Guide laser positioning allows users to display the objects feature(s) using the guide beam in the scanners field of view.

#### Robot Positioning

- This option can be found by holding “**Ctrl**” and clicking then Processing Window icon. This will open up a modified Processing Window, where users can align the shapes based on a robot current position. More information on this is in Section 9.9 .

### 5.5.2.1 Object Properties

The following options can be found in the property menu for each shape object (Figure 5.8).

- The **Object Pose** alters the objects position relative to the objects center.
- The **Global Pose** alters the objects position relative to the center of the canvas. Only for OTF jobs.
- The **Center** sub-sections of Object and Global Poses translate the object in the X,Y, and Z directions.
- The **Rotation** sub-sections of Object and Global Poses rotates the object in the X,Y, and Z directions.


Figure 5.8 Object Location Parameters

Object Pose	
▲ Center	<b>0, 0, 0</b>
X	<b>0</b>
Y	<b>0</b>
Z	<b>0</b>
▲ Rotation	<b>0, 0, 0</b>
X	<b>0</b>
Y	<b>0</b>
Z	<b>0</b>
Global Pose	
▲ Center	<b>0, 0, 0</b>
X	<b>0</b>
Y	<b>0</b>
Z	<b>0</b>
▲ Rotation	<b>0, 0, 0</b>
X	<b>0</b>
Y	<b>0</b>
Z	<b>0</b>

### 5.5.2.2 Nudge Tool


Above the properties menu, select the  button to display the Nudge Window. The Nudge tab will move the objects the specified increment in the direction of the arrows (Figure 5.9).

Figure 5.9 Nudge Tab



The Space Apart tab will equally space apart multiple objects by the specified amount (Figure 5.10).

Figure 5.10 Space Apart Tab



### 5.5.2.3 Manual Selection of Objects

Users can manually manipulate the objects on the canvas with the following tools.



The **Select by Pick** feature allows users to manually manipulate the coordinates of the object on the canvas. It does not affect the rotation of the object.



The **Select by Rectangle** feature allows the user to drag and drop the rectangle in the field of view to select multiple objects.



The **Show Selected** feature will show only the selected object in the job tree. All other objects on the canvas will disappear. Note that this does not affect processing: this is only for assisting the users visually.



The **Show Curve Direction** feature displays the direction in which object vectors will be preformed.



The **Show Vertices** feature shows all the vertices in the object.

### 5.5.2.4 Guide Laser Positioning

Guide Laser Positioning or Preview Positioning, allows users to position objects by displaying them with the guide laser.

While the guide beam is displaying the objects, users can move an object using the arrow keys on their keyboard. This method of object placement allows users to accurately place objects real-time on the physical part.

## 5.6 Modifying Object Properties

Once an object feature has been created, the object properties may need to be changed. Object properties can be changed by selecting the desired object or by selecting multiple objects with a “**Ctrl/Shift**” Click in the Job Tree.


You can modify the different processing properties in the Properties pane.

**Note:** When selecting multiple features, the parameters displayed in the parameter window will be reduced to the parameters that are common between the weld features. Also, if a variable (i.e. power, length, travel speed etc.) has differing inputs between the selected features, it will appear as an empty box.

### 5.6.1 General Properties

1. Click on the **object name** (for example: Circle1) in the Job Explorer pane. The Properties pane will update with data from the selected object as shown in Figure 5.11.

Figure 5.11 Properties Pane



2. General Properties include:
  - a. **Descriptions** of a selected property can be found by clicking on the button at the top of the properties window.
  - b. **Execute** determines whether or not an object will be performed when cycling the program.
  - c. **Locked** prevents anyone from changing parameters on a specific object.
  - d. **Reverse** changes the direction that the object is performed in.
  - e. **Loop** defines the number of times a feature is performed.
3. **Fill** fills the object based on the following parameters. Default is False (OFF).

- a. **Beam Diameter** – compensation for the diameter of the beam in the fill pattern.
- b. **Fill Angle** – the angle of the fill lines.
- c. **Fill Pitch** – the pitch between laser lines for fill.
- d. **Shape Outline** – if the shape will be outlined (True) or not (False).
- e. **Fill Direction** – direction of the fill lines.
- f. **Fill Type** – the type of fill.


### 5.6.1.1 Applied Offsets

When Apply Offsets is set to true, users have the ability to apply changes to parameters (position, rotation, and process parameters) through the utilization of register values.

The following outlines how to apply offsets.

1. Select the desired features(s) in the job tree.
2. Set Apply Offsets to True in the parameter window.
  - a. This causes Offset properties to appear.
3. Click on the “...” box in the Offset Properties. The OffsetSelector Window will appear, Figure 5.12.

Figure 5.12 OffsetSelector Window



4. In the OffsetSelector Window, click “**Add**”. Offsets can be applied to the following parameters:
  - a. Object.Pose.Center.X
  - b. Object.Pose.Center.Y
  - c. Object.Pose.Center.Z
  - d. Object.Pose.Rotation.X
  - e. Object.Pose.Rotation.Y
  - f. Object.Pose.Rotation.Z
  - g. Scale.X
  - h. Scale.Y
  - i. Scale.Z
  - j. Velocity
  - k. Power
  - l. Pulse Width

- m. Pulse Frequency
  - n. Keyhole Time
  - o. Energy
  - p. Pitch
  - q. Relative Speed
  - r. Frequency
5. Once a parameter has been selected for offset, set the variable that will be referenced for the offset data.
    - a. For loading data into registers, please refer to Section 5.8.10.
    - b. Offsets are applied as a scalar value. Not as a percentage or multiple.
  6. Repeat steps 4 and 5 until all desired offsets are applied to the features(s).
  7. Once all desired offsets are applied, close the OffsetSelector Window box by clicking "OK".

## 5.6.2 Welding Properties

1. **Processing** - contains a dropdown menu to select **welding** profiles.

Figure 5.13 Welding Parameters

Processing	
Laser	Guide
▾ Vectors Welding	
KeyHole On/Off	False
▾ Vectors Welding	
Velocity	1000
Laser Power	1000
Pulse Width	0
Pulse Frequency	1000
Wobble On/Off	False

- a. **Laser** - select the guide or laser beam to be used for each object in the work-space.
- b. **Vectors** - modify the parameters to define the process settings (welding, laser power, and pulse settings) for the job.
  - i. **Velocity**: velocity of the scanner moment in user units/sec. (This is for all shapes, **except** Points and Point Arrays)
  - ii. **Time**: The time to which the laser will be on for the point (in job units). This is **only** for Points and Point Arrays.
  - iii. **Power**: Laser power
  - iv. **Pulse Frequency**: the frequency to which to fire the laser
  - v. **Pulse Width**: length of time the laser will be on for each pulse. Pulse Width has to be lower than 1/Pulse Frequency
  - vi. **Wobble**: please see wobble section
- c. **KeyHole** - set the KeyHole On/Off to "True" to enable the KeyHole feature, Figure 5.14. Set to "False" to disable the KeyHole. Modify the parameters for a dwell period to initiate to initiate the keyhole in the workpiece before the actual process begins.
- d. **Wobble** - Click the Type drop-down menu to display the four Wobble modes with amplitudes and frequencies (Circle, Line, Eight and Infinity). Use these modes to improve the quality and consistency of the welds. (See Section 5.6.2.1).
- e. **Energy Offset** – click the ellipsis button to access Energy Offset window. Ramp up and down profiles for the laser power used in the welding process. See Section 5.6.2.2.

Figure 5.14 KeyHole Parameters

Figure 5.16 KeyHole Parameters


Processing	
Laser	Laser
Vectors	Vectors Processing
KeyHole On/Off	True
KeyHole	KeyHole
Time	0
Delay	0
Laser Power	400
Pulse Width	5E-05
Pulse Frequency	1000

### 5.6.2.1 Wobble

The Wobble feature allows users to add a wobble to the weld seam. The wobble causes the TCP speed of the beam to speed up, but still allowing the weld feature to maintain a commanded linear speed. The wobble will never change the amount of time it takes to finish a weld.

Refer to Figure 5.15 for all wobble types.

Figure 5.15 Wobble Types




- Amplitude controls the width of the wobble. For example, if a circle was used then the amplitude would be the diameter of the wobble.
- Delay is the amount of time it takes wobbling to begin. The use of a negative number causes the wobble to start early.

### 5.6.2.2 Energy Offset

The Energy Offset feature allows users to ramp up or down the lasers power within an object. The percentage is based on the laser power that the users input (where 0% is the laser's power).

Figure 5.16 Energy Offset Window



- Users can drag points individually on the bottom graph.
- To create a linear progression of power between points, users can use the “**Ramp**” functionality. Under “**Ramp**” users can specify the starting and ending points and their values. Then click **generate** to create a linear ramp of weld points.
- Users can also select points on the shape using the “**Pick**” or “**Rectangle**” buttons.
- The “**Direction**” button shows the direction of the welds.

### 5.6.3 Marking Properties

1. **Processing** - contains a dropdown menu to select **marking** profiles.

Figure 5.17 Marking Parameters

Processing	
Laser	Guide
Marking	
Marking	
Relative Speed	0.5
Energy	0.00025
Pitch	0.05
Frequency	0

- a. Laser – select the guide or laser beam to be used for each object in the work-space.
- b. Relative Speed – relative speed of the laser from 0 to 1.
- c. Energy – energy of the laser in J.
- d. Frequency – frequency of the laser.
- e. Pitch – distance between the pulses on the workpiece.

These properties are applicable for any shape EXCEPT for Marking points. For Marking Points, only the Energy property is applicable from those above.

### 5.6.4 Cleaning Properties

1. **Processing** - contains a dropdown menu to select **cleaning** profiles.



Figure 5.18 Cleaning Parameters

Processing	
Laser	Guide
Vectors Cleaning	
Vectors Cleaning	
Velocity (Initial)	0
Velocity (Maximum)	1000
Acceleration (0-100%)	100
Link Rate (0-100%)	100
Link Settle	0
Laser On Adjust	0
Laser Off Adjust	0
Laser Table	<input type="checkbox"/> (Collection)

- a. **Laser** – select the guide or laser beam to be used for each object in the work-space.
- b. **Velocity** – Specifies at which velocity the mirrors are moving at the initial (beginning) and maximum (end) of each vector scanning in units/sec (mm/sec, inch/sec, etc). Depending on the length and acceleration of the vector, this velocity may not be achieved. This is only used in OTF mode: should be set to 0 otherwise.
- c. **Acceleration** – percentage of the maximum acceleration allowed by the scanner. A lower value increases time between Velocity (Initial) to Velocity (Maximum), defined above.
- d. **Link Rate** – Percentage of maximum speed allowed by the scanner for a jump (i.e. when the scanner moves from one point to another).
- e. **Link Settle** – Specifies how long until the scanner settles on a given position in units of scanner time constants. The software will limit the value to a safe maximum. Usually, a value between 3 and 6 should be used.
- f. **Laser On/Off Adjust** – adjustment on the calculated time between when the scanner reaches the point and the laser begins to fire. Only positive values are allowed.

#### 5.6.4.1 Laser Table

During an actual vector scanning, IPGclean has to manage three laser control signals. These signals are:

- **Laser Power** (in Watts)
- **Pulse Frequency** (in Hertz), assuming the pulse laser is being controlled
- **Pulse Width** (in Seconds), assuming the pulse width can be varied


These signals may change with time and they are synchronized with the galvo mirrors movement. All signals above have to be specified in terms of the scanning velocity. This is to ensure that either:

- A **constant pulse spacing** OR
- A **constant deposition of energy per linear unit**

is maintained even if the galvos are accelerating. This is achieved by the Laser Table Feature. The Laser Table feature specifies the Power, Frequency, and Pulse Width for specific Velocities.


For example, for **constant laser energy per linear distance**, increase the laser power from 0 to 100 W at a constant pulse width (50% duty cycle) and constant frequency (100 kHz) (Figure 5.19).

Figure 5.19 IPGClean Laser Table Example 1



For equally spaced pulses increase the pulse frequency from 0kHz to 100kHz at a constant power and pulse width (Figure 5.20).

Figure 5.20 IPGClean Laser Table Example 2




**Note:** The pulse distance on the surface being cleaned is simply the ratio between velocity and frequency.

**Note:** The initial and maximum velocities may not need to be equal to those on the laser table. The software will interpolate and find correspondent values in the line that passes through all values in the laser table.

The laser table editor also offers a wizard that populates the laser table based on Maximum Velocity parameter and uses the pulse distance as the input parameter.

Clicking on the Wizard button, the following dialog appears:

Figure 5.21 IPGClean Laser Table Wizard



- Vary Frequency - a table will be created in which the pulse spacing is kept constant by varying the frequency as in Example 2 above.
- Vary Power - a table will be created in which the energy per linear distance is kept constant by increasing power with increasing velocity as in Example 1 above.


## 5.7 Creating a Parameter Profile

You can create a parameters profile for frequently used materials/parameters.

To create a Parameter Profile:

1. Select **View** → **Processing Parameters**.


Figure 5.22 Welding/Marking/Cleaning Parameters



2. Click **Add** to add a new profile.
3. Rename the profile to a desired custom name as needed.
4. Modify the process parameters as needed.

5. Click **OK** to save your changes. Close the Parameters window.
6. In the Data/Parameter Window, after selecting an object, under Processing, select the profile from the drop-down menu as shown in Figure 5.23.

Figure 5.23 Processing Dropdown Menu



**Note:** The fields for the parameters are auto-filled based on the template you selected. Further modifying the shapes parameters after selecting a profile will not change the profile.

## 5.8 Action Controls and Groups

All Action Controls can be **locked**. This prevents other users from easily editing the Action Control. This property is at the bottom of the properties list, unless set to true.

Most actions have an **Action Timeout** function. \***Action Timeout** terminates the job if task is not completed after the specific timeout. To disable, set Action Timeout value to -1.

### 5.8.1 No Action

This performs no action: the program will not be affected in any way.

### 5.8.2 User Action

Provides a pop-up message for users.

<b>Prompt</b>	Message which will appear to the users. User must click OK on message box to continue the job.
<b>Action TimeOut</b>	See above*.

### 5.8.3 Delay Action

Delays the program. Delay is set in seconds. This is the fixed time unit for jobs.

<b>Delay</b>	Delay set in seconds. <b>True</b> – The overall delay from the beginning of the job. <b>False</b> – the overall delay from the end of the previous object.
<b>Absolute</b>	<p>Absolute - <b>False</b></p> <p>Absolute - <b>True</b></p>

## 5.8.4 Streaming Data Action

Sends data down to the buffer. Causes no processing delay in IPGScan.

<b>Function Call</b>	<p><b>Set Port C</b> – Sets port C value.</p> <p><b>Clear Port C</b> – Clears port C value.</p> <p><b>Set Wait On Event</b> - When event occurs on START, GPIO1 or GPIO2, the streaming action will start. User selects START, GPIO1 or GPIO2.</p> <p><b>Set Wait Invert</b> – Sets the specified input active level to low (Clear) or high (Set). User selects Set or Clear option and START, GPIO1 or GPIO2.</p>
	<p><b>Set Wait Edge</b> – Sets the detection of the specified input to level detection (Clear) or edge detection (Set). User selects Set or Clear option and START, GPIO1 or GPIO2.</p>
<b>Action TimeOut</b>	See above*.

## 5.8.5 Reset Tracking

Resets the coordination that is set by the Set Coordination Mode Action.

<b>Action TimeOut</b>	See above*.
-----------------------	-------------

## 5.8.6 Set Coordination Flags

Sets the Coordination Flags in Hex. Used with On-The-Fly (Section 8 & 9).

<b>Coordination Flag</b>	Coordination Flag in Hex.
<b>Action TimeOut</b>	See above*.

## 5.8.7 Set Coordination Mode

Sets the tracking mode for Scan Pack and IPGScan. This action is important if the Scan Head is attached to a system which can move.

<b>Coordination Mode</b>	<b>Stage Tracking</b> - Selects robot mode for the stage. This means that the stage will move to fire the laser.
	<b>Robot Tracking</b> - Start robot tracking.
	<b>Robot Stationary</b> - If a robot is connected but not moving.
	<b>Stage Auto</b> - Automatically selects between coordinated or robot mode for the stage. Coordinated move will fire the laser when the stage is stationary before moving the stage.
<b>Coordination Off</b> - Turns off coordination mode.	
<b>Action TimeOut</b>	See above*.

### 5.8.8 Wait

Waits for the buffer to empty or Port A Bit Action to be true/false (1/0).

<b>WaitFor</b>	<b>Wait for Done</b> - Waits for the buffer to be empty.
<b>MethodType</b>	<b>Port A Bit Action</b> - Waits for the specified bit to be true or false (1 or 0). User will set this condition (true or false)
<b>Action TimeOut</b>	See above*.

### 5.8.9 Go To Group

Goes to a specific object group in the IPGScan job. This Group ID can be from a register, stored in Variables 1 to 10, or provided as a constant by the programmer.

<b>GoToGroup Method</b>	<b>Register</b> – Will obtain the Group number from one of the registers (Variables 1 to 10).
	<b>Constant</b> – Manually set group number.

### 5.8.10 Write Register

Writes a register over Ethernet or to a file.

<b>WriteRegister Method</b>	<b>Ethernet</b> – Writes to an Ethernet client set by the user from IPGScan Registers, Variable 1-10.
	<b>File</b> – Writes to a file set by the user from IPGScan Registers, Variable 1-10. File format is ".log", so recorded data will also contain a date and time stamp.
<b>Action TimeOut</b>	See above*.

### 5.8.11 Park At Action

Parks the scanner output at the specified coordinates.

<b>Park At</b>	X, Y and Z Coordinates
<b>Action TimeOut</b>	See above*.

### 5.8.12 Load Register

Loads a register with a value. For any TCP functions, set IP/Port in **Options** → **Settings**.

<b>Load Register Using</b>	<p><b>Port A</b> – User must set the Shift (bit shift), Width (bit mask), and Destination Register.</p>
	<p><b>Serial Port</b> – Reads a command over the Serial Port. User must set all COM port settings. The properties Command and End Delimiter must also be set. Command is the message that will be sent from IPGScan. End Delimiter is used to signify command completion from the serial device. Acknowledgement is optional. Destination Register must be set.</p>
	<p><b>User</b> – Stores the operator’s response from the prompt into a Destination Register. Both Prompt and Destination register must be set.</p>
	<p><b>Ethernet</b> – Reads/loads a command over Ethernet. The properties Command and End delimiter must be set. Command is the message that will be sent from IPGScan. End Delimiter is used to signify command completion from Ethernet device. Acknowledgement is optional. Destination Register must be set. To change other Ethernet settings, see the options menu.</p>
	<p><b>Constant</b> – Loads a constant into the Destination Register. Constant and Destination Register must be set.</p>
	<p><b>Concatenate</b> – Combines two registers together. Note that this function doesn’t add. (e.x “4” and “5” → “45”). Operand 1 and 2, and Destination Register must be set.</p>
	<p><b>RegEx</b> – Allows a RegEx pattern to be applied from the source register to the designation. Search online for more information about RegEx patterns if needed. Pattern, Source Register and Destination Register must be set.</p>
	<p><b>Math</b> – Takes two register values and can add or multiply them. Operand 1 and 2, Operator, and Destination Register must be set.</p>
	<p><b>Increment</b> – Increments the value in the register by the set amount. Increment By and Destination Register must be set.</p>
	<p><b>Date</b> – Will load the date into the specified register. Destination Register must be set. The format is set to <i>mm/dd/yyyy</i>.</p>
<p><b>Time</b> – Will load the time into the specified register. Destination Register must be set. The format is set to <i>hh:MM:ss</i>.</p>	
<p><b>Custom Date Time</b> – Will load the date and time into the specified register. Destination Register must be set. The format of the date and time can be customized:</p>	
<ul style="list-style-type: none"> <li>• MM – minutes</li> <li>• hh – hours (12)</li> <li>• HH – hours (24)</li> <li>• ss – seconds</li> <li>• s – decimal fraction of a second</li> <li>• tt – AM or PM</li> <li>• : (colon) / (forward slash) , (comma) – (dash) and . (period) are symbols accepted in this field.</li> <li>• mm – month</li> <li>• dd – day</li> <li>• yy or yyyy – year</li> </ul>	
<p><b>Timer</b> – Can be started, stopped or reset. The value will be stored in the Destination Register which must be set.</p>	
<p><b>From XML</b> – A file path is pulled from the registers, which can be set using the Constant function. The ID Attribute is the tag ID in the XML. The retrieved value is stored in the ID Value variable.</p>	
<p><b>TCP Client</b> – Reads/loads a command over TCP. The properties Command, End delimiter, IP Address, and Port must be set. Command is the message that will be sent from IPGScan. End Delimiter is to signify command completion from TCP Server. Acknowledgement is optional. Destination Register must be set.</p>	
<p><b>Action TimeOut</b> See <i>above</i>*.</p>	

### 5.8.13 Stage Motion Action

Moves the stage to the specified coordinates.

<b>Move to</b>	X, Y and Z Coordinates. This is the position to move to.
<b>Home X, Y, Z</b>	Boolean values. If set to true, it will home the stage on that axis. On false it will not home axis.
<b>Action TimeOut</b>	See above*.

### 5.8.14 Exit Action

Ends the job. This is ignored if Loop is selected in the processing window.


<b>Action TimeOut</b>	See above*.
-----------------------	-------------

## 5.9 Previewing and Running an IPGScan Job

To preview and run a job in IPGScan:

1. Select **Tools** → **Start Processing**. The Processing window will appear as shown in Figure 5.24.

Figure 5.24 Processing Window



- If you leave the **Guide** checkbox disabled, the IPGScan program runs in the actual processing mode using the parameters you have defined.
- If you enable the **Guide** checkbox, the **Keyboard Offset** checkbox appears.
- Enable **Loop** to loop the job continuously. Loop is useful when placing objects with the guide.


**Note:** For optimal cycle time, the loop should be implemented with an action control (**GoToGroup** Action Control), not with the loop checkbox.

**Note:** After checking **Keyboard Offset**, a textbox appears. This textbox contains the unit each keypress represents and can be modified by the user.



2. Click **Close** to exit the Processing window. A message box appears prompting you for confirmation of the new position as shown in Figure 5.25.

*Figure 5.25 Message Box Confirmation*



3. Click "**Yes**" to keep the new position.

## 6.0 Digital Camera

### 6.1 Installing a Digital Camera

A digital camera provides co-axial vision of the workspace, which is useful for precisely aligning, previewing, and inspecting the workpiece.


For detailed information about installing a digital camera please refer to the 2D Scanner Series User Guide (PN P21-010211).

### 6.2 Configuring the Digital Camera Options

To configure digital camera options:

1. Ensure that the digital camera software has been downloaded and installed.
2. Camera options can be found under the **View** → **Options** → **Camera**. The Camera options window will appear as in Figure 6.1.

Figure 6.1 Camera Options




3. Set the type of camera.

### 6.3 Connecting to a Digital Camera

To connect to a digital camera:

1. Select **View** → **Camera** → **Setup**. The setup window will appear as in Figure 6.2.

Figure 6.2 Camera Setup Window




2. Click on the branches to select the camera. Interface and GigE Vision Device information is displayed in the right pane.
3. Click “OK” to accept your selections.

## 6.4 Starting the Camera

1. Select **View** → **Camera** → **Start** to start the camera. To access the camera controls, double-click on the camera window, shown in Figure 6.3.

Figure 6.3 Camera Window Controls



2. Using the camera controls, the camera view can be flipped vertically or horizontally. The Gain and Exposure Time can also be changed to get a better view of the work-space.

**Note:** You can undock the camera window or expand it as needed by clicking on the top border.

**Note:** For detailed information about a specific digital camera, refer to the IPG accompanying digital camera documentation.

## 6.5 Scanning Workspace with the Camera

1. Select **View** → **Camera** → **Scan** to scan the entire workspace.
2. Select **View** → **Camera** → **Scan Partial** to scan part of the workspace. Click the left mouse button and hold to draw a rectangle where the scan will be.
3. For both Scan types, a message at the bottom of IPGScan window will appear: “Camera scanning in progress. Please wait.” To cancel this operation click the red Cancel button by the message.

## 6.6 Stopping the Camera


1. Select **View** → **Camera** → **Stop** to stop the camera scan.

## 6.7 Adjusting the Camera Image to the Center of View

You can focus, shift, and rotate the image as necessary to align it to the scanner’s center of view. To make the image adjustments:


1. Make sure the scan head is set to the working distance above the workpiece. Use the focus guide to set the scanner head to correct working distance.
2. Blast a cross pattern on a suitable workpiece in the center of the field using the laser. The small arrow indicates the +Y direction to ensure the image orientation is correct (Figure 6.4).

*Figure 6.4 Blasting a Cross Pattern*




3. Align the image to the cross-hairs as shown in Figure 6.5.

Figure 6.5 Group Properties Window



4. If the image is not in focus, then the height of the head needs to be adjusted.
5. Rotate the camera until the cross and cross-hairs are square.
6. Move the Iris level to adjust the image brightness.
7. If the image is not centered in the camera, remove the cover as shown in Figure 6.6.

Figure 6.6 Camera Mounting



8. Adjust the four setscrews.
9. Repeat focus, rotation, and alignment until aligned to the cross-hair. Tighten the clamp.
10. Replace the cover.

# 7.0 Robotic Point & Shoot

## 7.1 Overview

Robotic Point & Shoot is where the scanner and the robot coordinate their processing within the work area. The robot will move and orient the scanner along the workpiece. When the scan head is in position the robot will signal the scanner to process the section. The scanner will then signal the robot when it is done processing the section.

The following chapter describes how to setup a robot and an IPGScan job for Robotic Point and Shoot. This processing method requires the 24V Robot Interface board: see 2D Scanner Series User Guide (PN P21-010211).

## 7.2 IPGScan Configuration Parameters

Next is to **create a Point & Shoot Job** in IPGScan. The next few steps walk through setting up the example in Figure 7.1. This example job can be found in the IPGScan Jobs folder.

**Note:** In the example, the action controls have been renamed to reflect their specific action (right click on the action control to rename).

1. Create a new job.
2. In Group 1 (G1) place the following **action controls**:

<b>Wait</b>
<i>WaitForMethodTypes: Wait For Done</i> <i>Default values for other fields.</i>
<b>Wait</b>
<i>WaitForMethodTypes: PortA Bit Action Control</i> <i>Bit: 0</i> <i>Wait For: TRUE</i> <i>Default values for other fields.</i>
<b>Load Register</b>
<i>Load Register Using Type: Port A</i> <i>Shift: 0x00000010</i> <i>Width: 9</i> <i>Default values for other fields.</i>
<b>GoToGroup</b>
<i>GoToGroup Method Type: Register</i> <i>Default values for other fields. Note that the variable in "Go To Group At..." must be the same Register Variable as the Load Register "Destination Register" field.</i>


3. In the next Group, G2:

<b>Streaming Data Action</b>
<i>Function Call: Set Wait On Event</i> <i>Event: Start</i> <i>Default values for other fields.</i>
<b>Shapes to Process</b>
<b>Go To Group</b>
<i>GoToGroupMethod: Constant</i> <i>GoTo: 1</i> <i>Default values for other fields.</i>

4. Repeat Step 3 for as many groups as needed. In this example, there are two object groups (G2 and G3).

- In the last Group, (G4 in this example) place one **Exit Action Control**. This will ensure the IPGScan Job will properly exit.

Figure 7.1 Point & Shoot Example Job



## 7.3 Robot Software

**Robot functions** are provided to simplify Robotic Point & Shoot. These functions can be called in the Robot's Point & Shoot program to interact with the scanner. The files can be found on the website [software.ipgphotonics.com](http://software.ipgphotonics.com) under the Scanner/Robot\_Files. Table 7.1 lists 6 functions provided and a description of the purpose for each function.

Table 7.1 Robot Welding Jobs

Job	Description
IPG_EXAMPLE_WELD	This is an example job of how the full system works together.
IPG_EXECUTE_WELD	This job executes the pre-selected IPGScan group.
IPG_LASER_DIS	This job configures any I/O for disabling the laser or system. It is called in IPG_SHUTDOWN_WELD. This job is not pre-configured.
IPG_LASER_EN	This job configures any I/O for enabling the laser or system. It is called in IPG_PREP_WELD and SETUP_WELD. This job is not preconfigured.
IPG_PREP_WELD/ SETUP_WELD	This job sets up all components for use in the job. This job only needs to be called once at the beginning of the robot job. This function expects the desired timeout in milliseconds.  In IPG_EXECUTE_WELD, if the robot waits longer than the timeout for the scan controller to be ready, the robot will stop. Setting the timeout to -1 will disable the timeout.  IPG_PREP_WELD and SETUP_WELD are the same job; new versions are called IPG_PREP_WELD.
IPG_SELECT_WELD	This job selects the desired processing group from IPGScan. This function needs to be called before each call to IPG_EXECUTE_WELD. It is time efficient to also call IPG_SELECT_WELD before moving the robot into position for IPG_EXECUTE_WELD.  This function expects the desired processing group as a parameter. This should be a decimal number between 0 and 511, inclusive.
IPG_SHUTDOWN_WELD/ CLOSE_WELD	This job turns off all I/O used in this system. This job only needs to be called once at the end of a robot program.  There is a small time-based wait at the beginning of this job. This gives IPGScan time to read the I/O if the Exit Action is used. The time is small enough that it will not be noticed in a single execution.  If the robot is being set-up for a looped cycle, the wait time can be removed or IPG_SHUTDOWN_WELD does not have to be called at all.  IPG_SHUTDOWN_WELD and CLOSE_WELD are the same job; new versions are called IPG_SHUTDOWN_WELD.

## 7.3.1 Special Cases

### 7.3.1.1 FANUC

An additional numeric register is required for the job IPG\_SELECT\_WELD. By default register 2 is used. Two user alarms are used as well. Their severity is setup in IPG\_SETUP\_WELD. The user alarm messages must be setup by the user in the FANUC menu. By default alarm 1 is used in case of a timeout in IPG\_EXECUTE\_WELD and alarm 2 is used in case of an invalid group ID in IPG\_SELECT\_WELD.

### 7.3.1.2 Yaskawa Motoman

The timeout provided to IPG\_PREP\_WELD is in clock ticks, not milliseconds. This value is stored in a global integer variable. Default variable is 1000.

### 7.3.1.3 KUKA

KUKA requires two additional files: IPG\_EXAMPLE\_WELD.dat and IPG\_SCAN\_VARIABLES.dat. The IPG\_EXAMPLE\_WELD.dat file contains position information used by move commands IPG\_EXAMPLE\_WELD. IPG\_SCAN\_VARIABLES.dat contains variable definitions for variables used in multiple subprograms.


### 7.3.1.4 ABB

The functions for ABB are provided as a single module file with multiple procedures.

## 7.3.2 Sequence of Events

Figure 7.2 shows an example of the Point & Shoot handshake sequence with the 24V Robot Interface board. Though its not required, this examples shows the advantage of setting the Strobe bit before moving the robot. During robot motion, the Scan Controller can process the upcoming data and get the Scan Head ready.

Figure 7.2 Robot Signals Timing





### 7.3.3 Example Program

The following example shows how the jobs are utilized:

1. Call **IPG\_PREP\_WELD**(TMO).
  - a. IPG\_PREP\_WELD only needs to be called once. TMO is the timeout used in IPG\_EXECUTE\_WELD in milliseconds. If TMO is (-1) then IPG\_EXECUTE\_WELD will run without a timeout.
2. Call **IPG\_SELECT\_WELD**(ID).
  - a. Call IPG\_SELECT\_WELD before each group, even if the same group is being repeated. Pass the IPGScan group ID as a parameter.
  - b. Perform all other operations to position the Scan Head in the desired location.
3. Call **IPG\_EXECUTE\_WELD**.
  - a. IPG\_EXECUTE\_WELD waits for the laser to finish before continuing.
4. Call **IPG\_SHUTDOWN\_WELD**.
  - a. IPG\_SHUTDOWN\_WELD only needs to be called when all processing has been completed.
  - b. If another cycle is going to begin, the robot does not have to call IPG\_SHUTDOWN\_WELD or IPG\_PREP\_WELD again.

# 8.0 Coordinated Stage Motion

## 8.1 Overview

Coordinated Stage Motion means to mark a moving target without having the target stop for the realignment of the object.

When using a real encoder, the encoder’s resolution (meters/encoder pulse) should be at equal to or less than the laser beam diameter. IPG’s software also provides a simulated encoder input so a real encoder may not be needed for some applications. Throughout this chapter the terms On-The-Fly and encoder inputs are used interchangeably.

### Requirements/Recommendations:

- The Stage Configuration Utility software must be installed.
- Encoder must have a quadrature output.
- Encoder reset is an option.
- The use of the 5V Motor Control Board (PN P30-003779) is needed.


## 8.2 IPGScan Configuration Parameters

For information regarding hardware connections and the Stage Configuration Utility, please refer to the 2D Scanner Series User Guide (PN P21-010211). For Stage Configuration Utility details, please see Appendix D.

## 8.3 IPGScan Software

1. Next is to create an On-The-Fly job in IPGScan. The next few steps walk through creating the example shown in Figure 8.1.
2. In Group 1, place an Action Control.
3. Set the Action Control to “**Set Coordination Mode**”. The Coordination Mode should be set to “**Stage Tracking**”.
4. In Group 2, place a **Reset Tracking Action Control**. After this place desired shapes.
5. In Group 3, place a **GoToGroup Action Control**. Set the Go To field to the ID of Group 2.
6. In Group 4, place an **Exit Action Control**. This Action allows IPGScan to complete the loop.

Figure 8.1 IPGScan On-The-Fly Job Example



**Note:** For the best performance, logging should be disabled when performing On-The-Fly. It is disabled by default, but this option can be found under **Options** → **Settings** → **Log Level**.

## 9.0 Robotic On-The-Fly

### 9.1 Overview

This chapter goes over Robotic On-The-Fly (OTF) processing. This chapter explains the software requirements, the IPGScan Software configuration, how to create an individual OTF IPGScan job, and how to run an OTF IPGScan job.

### 9.2 Connections/Robot Software

Utilization of this OTF software requires additional software on the robot, additional electrical connections between the robot and the scan controller, and the 24V Robot Interface Board. For information about the additional electrical requirements and the 24V Robot Interface Board, please refer to the 2D Scanner Series User Guide (PN P21-010211).

#### 9.2.1 Scanner Requirements

OTF coordination requires an additional configuration file for the scan controller, Coordination-Params.xml. Please contact an Applications Engineer at IPG Photonics for this file.

#### 9.2.2 Robot Requirements

Each robot manufacturer requires additional software options for robot to PC communications. The additional options below should be purchased from the manufacturer:

- FANUC
  - Either **Robot Server** or **KAREL** can be used. Robot Server is simpler as less configuration and no additional files are required. A higher number of coordination flags can be obtained with the Robot Server. Better performance and control can be obtained with KAREL.
  - Package Options:*
  - Robot Server**
    - SIT PC Interface (PCIF): RTL-PCIN
    - Robot Server: PC RTL-RSR
  - KAREL**
    - SIT PC Interface (PCIF): RTL-PCIN
    - KAREL: RTL-R632
    - User Socket Messaging: RTL-R648
- Yaskawa Motoman
  - MotoPlus Robot Controller Option
- KUKA
  - KUKA Robot Sensor Interface (KUKA.RSI)

### 9.3 Robot Controllers

The On-The-Fly system has been tested with the following controllers:

- FANUC R-30iB
- Yaskawa Motoman DX200
- KUKA KRC4

### 9.4 Robot Setup

Configuration files for all robots can be found on the website [software.ipgphotonics.com](http://software.ipgphotonics.com) under Scanner/Robot\_Files.

## 9.4.1 FANUC

Follow the steps to configure the robot for use with Robot Server and KAREL.

1. Configure a TCP/IP Connection between the robot and the computer.
2. To check, enter the Robot's IP Address into a web browser and the robot's home page should load.

**The setup is complete if using the Robot Server.**

### 9.4.1.1 KAREL

Follow the next steps to complete KAREL setup.

1. Load the following KAREL files (.PC) onto the robot:
  - a. IPG\_ABORT.PC
  - b. IPG\_COMM.PC
  - c. IPG\_HC\_REC.PC
2. Configure the TCP server tag. Instructions for this can be found in the KAREL Reference Manual Revision I, Section 11.3.2.
3. Select IPG\_COMM.PC and view the KAREL variables in the Data menu.
  - a. KAREL variables for the **user to set or modify** are prefixed by "USR..."
  - b. For "USR\_SRV\_TAG", enter number of the TCP Server Tag
  - c. For "USR\_SPRS\_LOG", enter TRUE or FALSE. TRUE: logging to "CONSLOG.DG" will be suppressed. If undefined, FALSE is assumed.
4. Add IPG\_COMM to "**COLD START Autoexec program**" setting on **FANUC Config Screen**.
5. Enter the port number configured in step 2 into **IPGScan Robot Options** → **Robot Port**.

#### KAREL Notes:

- IPGScan communication with the robot will not work without **IPG\_COMM running**. If a **fatal error** occurs, if **aborted**, or if **not configured** to automatically start with the robot, IPG\_COMM can be **started** from the Select Screen.
- IPG\_COMM will not change either the "Busy" status or the Active light on the robot controller.
- IPG\_COMM or IPG\_HP\_REC will not respond to the abort button. Run IPG\_ABORT to terminate.
- Error messages are located on the "User" Screen of the Pendant. Log messages are recorded in the log "CONSLOG.DG" (if not suppressed).
- If active tool frame has changed, run IPG\_ABOUT, then IPG\_COMM to reinitialize.

## 9.4.2 Yaskawa Motoman

1. Setup MotoPlus on the robot controller.
2. On the robot controller, load "**IPG\_OTF\_DX200.out**" (see *MOTOPLUS APPLICATION INSTALLATION INSTRUCTIONS* from Yaskawa Motoman (PN 166687-1CD) for instructions.).
3. Connect the robot and computer using an Ethernet connection. Configure the IPv4 Windows Network Adapter properties according to the network settings on the robot.

## 9.4.3 KUKA

1. Configure the RSI Ethernet connection to the computer which will run IPGScan. Load the following files onto the KUKA controller to the directory specified by the KUKA RSI manual:

- IPGP\_OTF\_RSI.rsi
  - IPGP\_OTF\_RSI.rsi.diagram
  - IPGP\_OTF\_RSI.rsi.xml
  - IPGP\_OTF\_RSI-Ethernet.xml
2. To help control RSI, the following modules can be called:
    - IPG\_OTF\_BEGIN\_DATA\_XFER.src
    - IPG\_OTF\_END\_DATA\_XFER.src
  3. The following module can be used for calibration and as an example:
    - IPG\_OTF\_CALIBRATION.src
    - IPG\_OTF\_CALIBRATION.dat

## 9.5 Robot Options in IPGScan

The Robot options (**Options** → **Robot**) of IPGScan are shown in Table 9.1.

Table 9.1 Robot Options

Option	Description
<b>Digital IO Start</b>	The digital output from the robot, connected to the Start pin on the scan controller. This should be the software output number on the robot.
<b>Next Button Click Bit</b>	The output from the robot which is read by IPGScan to move to the next processing object during alignment. This should be the bit number on the scan controller. <i>Optional.</i>
<b>Prev Button Click Bit</b>	The output from the robot which is read by IPGScan to move to the previous processing object during alignment. This should be the bit number on the scan controller. <i>Optional.</i>
<b>Robot</b>	The type of robot. To turn off robot related functions, set this to 'None'.
<b>Robot Flags</b>	Which robot output values should be recorded and used as coordination flags in a trajectory. These do not have to be connected to the scan controller.
<b>Robot IP Address</b>	The IP Address of the robot.
<b>Robot Port</b>	The communication port to the robot. Not required for all robot types.
<b>Save Button Click Bit</b>	The output from the robot which is read by IPGScan to save the current position to the current processing object during alignment. This should be the bit number on the scan controller. <i>Optional.</i>
<b>Start Stop Button Click Bit</b>	The output from the robot which is read by IPGScan to start or stop outputting the current processing object during alignment. This should be the bit number on the scan controller. <i>Optional.</i>


## 9.6 IPGScan Workspace Calibration

The calibration process creates an origin for IPGScan OTF jobs. The robot trajectory and all processing objects are in reference to this IPGScan origin.

**Note:** An accurate robot TCP is required for Calibration: refer to 2D Scanner Series User Guide (PN P21-010211) for more information.

1. Open the Calibration Wizard by clicking on “Calibration” in robot menu (Figure 9.1).


Figure 9.1 Robot Menu



2. During any point in the calibration, the “**Help**” button can be clicked, which will display further information to assist users in the calibration process.
3. On the first page the origin is recorded (Figure 9.2). The origin can be anywhere within the robot’s work area. When the robot is positioned, click “**Record IPGScan Origin**”. On the right window, it should now display that the IPGScan Origin is “**Recorded**”.


**Note:** Until another calibration is preformed, this point will remain the origin.

Figure 9.2 Calibration Wizard Origin




4. “**Snap All to Orthogonal**” snaps all angles to nearest multiple of 90°; this removes minor errors in the feedback. *Optional*.
5. Click “**Next**”.
6. On each of the following screens the IPGScan X, Y, and Z references are set. The robot must start at the origin before recording the new position on each page. (Figure 9.3)

Figure 9.3 Calibration Wizard X, Y, Z Axis




7. First, return the **robot to the origin**.
8. The second step requires the robot to be **moved** in only the X, Y, **OR** Z direction, with respect to the desired **IPGScan reference frame**.
9. When the robot is positioned click "**Record IPGScan ...**" to record that axis.
10. The fourth step asks in which axis did the **robot move**, with respect to the **Robot TCP Frame**. Below is an example image of the Robot and TCP frames, Figure 9.4.

Figure 9.4 Robot World & TCP Example



11. The fifth step asks which direction did the **IPGLogo move** (Figure 9.5).
12. When all points have been recorded, click "**Finish**".

Figure 9.5 IPG Logo Directions



### 9.6.1 IPGScan Workspace Calibration with a KUKA Robot

When calibrating IPGScan with a KUKA robot, RSI must be started before the robot can send information to the PC. A suggested method for IPGScan workspace calibration can be found in IPG\_OTF\_CALIBRATION. The point P1 should be saved as the IPGScan workspace origin.

The module IPG\_OTF\_CALIBRATION first starts RSI and then moves to the origin. There is a 10 second wait after the first PTP move. This wait provides the robot operator time to pause execution of the module. When execution of the module is paused, the robot can be jogged and RSI will continue to facilitate communication between the robot and the PC.

## 9.7 Creating an IPGScan On-The-Fly Job

1. Create a new job.
2. Select the name in the Job Tree.
3. In the properties window, set the **type** to “On The Fly”.

**Note:** Type should be “Default” for any jobs that are **not** On The Fly. When a robot type is set to “None” in **Options** → **Robot** new jobs will be created as “Default”. Otherwise new jobs will be set to “On The Fly”.

4. Next, create desired processing objects using the drawing tools. The order of the processing objects in the Job Tree is the sequencing the processing objects will be output.

## 9.8 Using Coordination Flags


**ActionControl** → “Set Coordination Flags” is used to set **Processing Zones** in IPGScan. A Processing Zone is active for all processing objects following the ActionControl until: 1) **the job ends** or 2) **another Processing Zone is set**.

The active Coordination Flags in the robot trajectory must match those of the current Processing Zone in order for an object to be output. Calling “Set Coordination Flags” with the default parameter of “0x00” will ignore all Processing Zones.

The process that ScanPack uses to determine whether the upcoming processing vectors should be output is found in Figure 9.6.




Figure 9.6 Coordination Flag Logic



## 9.8.1 Selecting Coordination Flags

Coordination Flags can be selected under **Options** → **Robot** → **Robot Flags** (Figure 9.7).

Figure 9.7 Setting Robot Flags



Enter values that correspond with any robot output. Coordination flags must be set **before** recording a trajectory.

### 9.8.1.1 FANUC

For FANUC robots, enter the output number as displayed on the robot. FANUC systems using the Robot Server are limited to 32 flags; systems using KAREL are limited to 5 flags. If more than 5 or 32 flags are set in the options menu, the first 5 or 32 values will be used, respectively. If a value is invalid it will not be used.

### 9.8.1.2 Yaskawa Motoman

For Yaskawa Motoman robots, enter the logical relay address number. This can be found in the Concurrent I/O manual and in the In/Out menu. Yaskawa Motoman robots are limited to 5 flags. If more than 5 flags are set in the options menu, the first 5 values will be used. If a logical relay address number is invalid it will not be used.

### 9.8.1.3 KUKA

For KUKA robots, enter the number of flags to record. If nothing is entered 0 is assumed. Values to be used as flags must be set in the RSI files before loading them onto the robot. The RSI files supplied are limited to 9 flags not including the Start signal.

## 9.8.2 Setting the Coordination Flag Action Control

In the ActionControl “Set Coordination Flags” the value of the flag is a 32-bit hexadecimal number. Each bit represents the state of one flag. Flag 0 corresponds to the first digital output listed in the IPGScan settings. The flag number does not correspond to the output number. Flags are numbered based upon their order in the options. When a flag is active, that bit is equal to 1. When a flag is inactive, that bit is equal to 0. Figure 9.8 shows the first 8 bits of the 32-bit number.

Figure 9.8 Robot Flag first 8-bits

FLAG7	FLAG6	FLAG5	FLAG4	FLAG3	FLAG2	FLAG1	FLAG0
-------	-------	-------	-------	-------	-------	-------	-------

## 9.9 Object Placement and Trajectory Building

IPGScan can be used to assist in positioning of processing objects and programming the robot. There are two primary modes: Snap To and Alignment.

### 9.9.1 Snap To

**Snap to Robot** allows users to position objects based on the robot’s position.

1. Enable **Robot Tracking** by selecting **Robot Menu** → **Robot tracking**.
2. Move the robot to the desired location. The movement of the robot will be reflected on the IPGScan Canvas.
3. Right click on any object and select “**Snap to Robot**”.
4. The current robot pose is now saved as the object’s global pose.

**Snap to Viewport** allows users to position objects based on the viewport’s current position in a trajectory.

1. Record and load a trajectory.
2. At the bottom of the canvas, scroll along the timeline by clicking on it and moving the mouse left and right.
3. When the viewport is at a desired location in the trajectory, right click on any object and select **Snap to Viewport**.
4. The current viewport pose is now saved as the object’s global pose.


### 9.9.2 Alignment

There are two alignment modes:

1. **Process alignment:** assists in aligning and positioning process objects.
2. **Robot alignment:** assists in finding robot positions.

To use either alignment mode, select objects or groups to be aligned. Hold “**Ctrl**” and click “**Start Processing**” button to access these options for the selected items. Figure 9.9 shows the alignment window.

Figure 9.9 Weld Alignment Window



- Process alignment will preview the selected object with the guide beam, at the center of the scan head without any rotation.
- The robot can then be used as a pointing tool to place the object in a desired location based upon the cell and the work piece.
- Click “**Save**” to save the current pose of the robot to the global pose of the current object.
- Robot alignment will preview as much of the selected object as possible in its programmed location based upon the current location of the robot. This can be used when programming the trajectory of the robot to determine if a location will be suitable for outputting the tested object.

### 9.9.3 Alignment with Robot Pendant

From the robot options, the different “Bit” options refer to the alignment window. These bit options should be set to outputs on the robot connected to the scan controller. Changing the state of these outputs will trigger their corresponding button on the alignment window.

For example, if in the robot option’s “Save Button Click Bit” is set to 0 (Strobe), changing the Strobe bit will save the current pose of the robot to the current processing object. Use of these bits is optional.

Table 9.2 shows the bits of user accessible digital inputs to the scan controller from the 24V Interface Board.

Table 9.2 Bits of User Accessible Digital Inputs

Signal	Bit	Signal	Bit
SELECT0	16	SELECT5	21
SELECT1	17	SELECT6	22
SELECT2	18	SELECT7	23
SELECT3	19	SELECT8	24
SELECT4	20	STROBE	0

## 9.10 On-The-Fly Robot Programming Setup

IPGScan records the motion of robot program for later use in a processing job. The robot program must be setup accordingly.

The Start signal changing from inactive to active signals IPGScan to begin recording. The Start signal changing from active to inactive signals IPGScan to finish recording.

Because IPGScan works off of a recording, only time-constant functions should be used within the recorded section of the job. For example, if the robot waits for an input, the robot and scanner will be desynchronized if the input is not triggered at the same time during each cycle.

The following pseudo-code is an example robot program for OTF.

```
// reset the start signal to off in case it is on at the start of
// the program
digitalOutput[startSignal] off
// move to a beginning home position
moveJ pHome
// any other preparations for the trajectory can be done here
// move to the first point in the trajectory
moveJ pBegin
// turn on the Start signal begins recording this trajectory
digitalOutput[startSignal] on
// any number of moves can be performed
// additional operations like setting outputs or waiting based on
// time can be performed
// moves which are not time-constant should not be used because
// IPGScan will only use a recording during execution
moveL pIntermediary1
moveL pIntermediary2
// turning off the Start signal will end the recording of this
// trajectory
digitalOutput[startSignal] off
// return to the home position
moveJ pHome
```

### 9.10.1 KUKA On-The-Fly Programming

OTF KUKA modules need to start RSI at the beginning of the program to facilitate recording.

1. To start RSI, IPG\_OTF\_BEGIN\_DATA\_XFER should be called at the beginning of the module.
2. At the end of the program, a small time delay should be called before ending the job or ending RSI to give the robot time to send out all of the information. This delay only

needs to be called during recording. Calling it after setting the Start signal to inactive will not impact the final recording.

3. IPG\_OTF\_END\_DATA\_XFER can be used to both end RSI and add a time delay. Both modules require a Boolean parameter; true if the run will be a recording and false if the run will not be a recording. Both the RSI functions and time delay will only be called during recording.

## 9.11 Recording a Trajectory

To record a trajectory in IPGScan:

1. Set the information about the robot in the Options menu.
2. Select 'Get Trajectory' from the robot menu.
3. Press 'Prepare' to prepare IPGScan and the robot for recording.
4. Press 'Start' to begin recording the trajectory.
5. The recording will begin when the Start signal is active.
6. When the Start signal turns inactive the trajectory recording will end.
7. After completing a recording, a window will display to choose a save location and a file name for the recording file.

**Note:** When recording with FANUC\_KAREL, the recording job on the robot has a very high priority and you may notice that the iPendant does not respond as expected to button presses. This is only during recording with FANUC\_KAREL and will finish after the recording completes. If you are still having trouble, run IPG\_ABORT to abort running the OTF KAREL jobs.

## 9.12 Loading a Trajectory

To load a trajectory in IPGScan:

1. Either create a new IPGScan job or open an IPGScan job.
2. Select '**Load Trajectory**' from the robot menu.

Navigate the file system and select the desired trajectory file.

## 9.13 Testing an On-The-Fly Job

An OTF job can be tested with the "Dry Run" option in the processing window. With the "Dry Run" option selected, pressing "Start" will evaluate the current job for its ability to output each processing object.

Each object is evaluated sequentially in the Job Tree. Evaluation stops after the first object fails to complete its output. If a processing object fails to complete its output, an "SPK\_ROBOT\_TIMEOUT" log message will appear.

Successful processing objects will appear as green blocks on the timeline. The start and end of each block represents the start and end of processing for that object.

If an object will not complete its output, it appears on the timeline as a long red block. It is possible for an object to start processing, stop processing part-way through, then finish processing later in the trajectory.

A processing object might fail for two primary reasons:

1. Its position is not reachable by the scan head during the trajectory.
2. The scan head does not have enough time to fully execute the object.

Use the timeline to scroll through the positions of the robot and determine where the viewport reaches the processing object throughout the trajectory. Then adjust your robot trajectory or your weld parameters. Any modification to the robot trajectory must be re-recorded

## 9.14 Executing an On-The-Fly Job

To execute an OTF job, click the “Start Processing” button; then click “Start.” After starting IPGScan, the scan controller will wait for the Start signal to be active before beginning coordinated processing. Similar to recording a trajectory, assertion of the Start signal from the robot signifies the beginning of the trajectory.

### 9.14.1 Looping an On-The-Fly Job

To loop an OTF job, the Start signal must be set to “Edge”. This can be done with the Action-Control “Streaming Data Action” with the following settings:

- Streaming Data Action
  - Function Call = Set Wait Edge
  - Event = Start
  - State = Set

To reset the Start signal, use the same ActionControl with the following parameters:

- Streaming Data Action
  - Function Call = Set Wait Edge
  - Event = Start
  - State = Clear

For the most efficient processing, looping the job should be done in the job with ActionControls instead of using the “Loop” checkbox.

## 10.0 Errors

The following are error codes that may be encountered when using IPGScan and their descriptions are listed below.

- SPK\_HARDWARE\_STOP
  - Scanner external stop is active. This is not a hardware safety stop.
- SPK\_ROBOT\_MISSING\_TRAJ
  - No trajectory is loaded in an OTF job.
- SPK\_ROBOT\_TIMEOUT
  - The OTF job failed dry run. Ensure that object positions fall within the InView Window, check if robot and vector weld speeds may need to be modified, and ensure that features are being processed in the right direction.
- SPK\_INVALID\_POSITION
  - Feature is outside of the field of view/processing window. Realign feature inside window to fix this error. If feature is within the window, but this error is still shown, check the z-position of the feature.
- SPK\_OUTPUT\_SOFTWARE\_ABORT\_ERROR
  - Current process was aborted.
- SPK\_INVALID\_INVIEW
  - CoordinationParams.xml file is missing.

## **A. Service and Support**

There are no operator serviceable parts inside. Please refer all servicing to qualified IPG personnel.

### **A.1 Technical Support**

Many issues and questions regarding the safety, set-up, operation and maintenance of the IPG products can be resolved by carefully reading this User Guide. However, if you have questions regarding the safety, set-up, operation or maintenance of your IPG product, call the IPG Photonics Customer Service department located in Oxford, Massachusetts, USA, at 508-373-1100.

If you cannot resolve the issues by using this User Guide or over the telephone with our technical support group, you might need to return the product to IPG. Refer to Section C for more details.



## B. Warranty

### B.1 Limited Express Product Warranties

IPG warrants to the original Buyer or, if Buyer is an authorized IPG reseller or distributor, to Buyer's original customer of the IPG Product, that the IPG Product conforms to applicable IPG Product specifications and is free from defects in materials and workmanship. These non-transferable warranties start on the shipment date from IPG (or other date specifically referencing the warranty start date in IPG's sales order/order acknowledgment), and continue until the end of the warranty period listed in IPG's sales order/order acknowledgment. If there is no warranty period listed, then warranty period is one year. Products or major components manufactured by parties other than IPG bear the original manufacturer's warranty and warranty period. The obligations of IPG are limited to the repair or replacement (at IPG's option) of any Product that does not meet the IPG warranty during the warranty period. IPG warrants repaired or replaced Products under warranty only for the remaining un-expired period of time in the original warranty. IPG reserves the right to issue a credit note for any defective Products that have proved defective through normal usage; Buyer debit memos are not allowed. This warranty governs over any conflicting terms in Buyer's purchase order or other IPG documents except as expressly provided herein.

### B.2 Warranty Limitations

This warranty excludes and does not cover defects or damage resulting from any of the following: contamination of external optical surfaces; unauthorized modification, misuse or mishandling, disassembly or opening, neglect, or damage from accident; operation outside environmental specifications or product ratings; user software or interfacing; components and accessories manufactured by companies other than IPG, which have separate warranties; improper or inadequate installation, site preparation or maintenance; or failure to follow information and precautions contained in the operating manual. Additional warranty exceptions, limitations and exclusions may apply for laser systems manufactured by IPG and its affiliates as set forth in the applicable quotation and sales order/order acknowledgment. All products or components (including software) identified as experimental, prototypes or to be used in field trials are not warranted and are provided to the Buyer on an "as is" basis. IPG assumes no responsibility for Buyer or third-party supplied material, components, systems or equipment. Products and repaired Products may contain components that have been previously used in other products, however such Products meet IPG Product specifications for newly manufactured Products. The Buyer must give prompt notification to IPG of any claim under the warranty in writing. IPG has no responsibility for warranty claims more than 30 days after the Buyer discovers or becomes aware of the claimed defect. Buyer is responsible for providing appropriate utilities and operating environment as stated in the operating manual and the specifications. This warranty applies only to the original Buyer at the initial installation or delivery point. Buyer must make all claims under this warranty and no claim will be accepted from any third party.

**EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY SET FORTH ABOVE, IPG SPECIFICALLY DISCLAIMS ANY AND ALL OTHER WARRANTIES AND REPRESENTATIONS TO BUYER, INCLUDING WITHOUT LIMITATION, ANY AND ALL IMPLIED WARRANTIES, SUCH AS FREEDOM FROM INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

## **B.3 Limitation of Remedies and Liabilities**

**THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL IPG BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES (EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES) ARISING FROM OR RELATING TO THIS ORDER OR THE PRODUCTS (INCLUDING, LOSS OF PROFITS) WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY. IPG'S MAXIMUM LIABILITY ARISING UNDER THESE TERMS AND CONDITIONS WILL NOT EXCEED, IN THE AGGREGATE, THE TOTAL AMOUNT PAID FOR THE PRODUCTS BY BUYER. THESE LIMITATIONS MAY NOT APPLY TO YOU UNDER THE LAWS OF CERTAIN JURISDICTIONS.**

## **B.4 Software**

### **B.4.1 Firmware License Agreement**

**CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE OPENING THIS PACKAGE OR SIGNIFYING YOUR ACCEPTANCE BY CLICKING THE APPROPRIATE DIALOG BOX. OPERATING THE PRODUCT, CLICKING THE APPROPRIATE DIALOG BOX OR USING ANY PART OF THE SOFTWARE SIGNIFIES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE WITH THEM, PROMPTLY RETURN THE PRODUCT UNUSED ALONG WITH ANY OTHER RELATED ITEMS THAT WERE INCLUDED IN THE SAME ORDER FOR FULL CREDIT.**

You, as the Customer, agree as follows:

#### **1. DEFINITIONS**

"IPG" shall mean the IPG Photonics Corporation affiliate providing Licensed Software to Customer pursuant to this Agreement.

"IPG Software" shall mean those portions of the Licensed Software owned by IPG or IPG affiliates.

"Licensed Software" shall mean the software, in object code form only, supplied by IPG pursuant to this Agreement.

"Licensed Product" shall mean the Licensed Software and/or its accompanying documentation.

"Third Party Software" shall mean those portions of the Licensed Software owned or licensed by a third party, including but not limited to operating system code, that is embedded within the Licensed Software.

#### **2. LICENSE**

2.1 Except as provided in section 2.2 below, you are granted a non-transferable, nonexclusive license to use the Licensed Software only as embedded in or to be used on a single IPG product. You may copy the Licensed Product, for backup purposes only, in support of your use of the Licensed Software, limited to one copy. No other copies shall be made unless authorized in writing by IPG. You must reproduce and include all applicable copyright notices on any copy. You may not reverse compile or otherwise reverse engineer, or modify the Licensed Software. The Licensed Software, comprising proprietary trade secret information of IPG and/or its licensors, shall be held in confidence by Customer and Customer shall not disclose it to third parties, unless disclosure is required by law or legal process. In response to such legal requirements, the Customer shall promptly notify IPG in advance of such disclosure and reasonably cooperate in attempts to maintain the confidentiality of the Licensed Software. No title to the intellectual property is transferred. Licensed Software shall not be copied, reproduced,

or used for any other purpose outside of operation of the IPG product, and shall not be used on any other piece of hardware other than the IPG product with which it was provided.

2.2 If you transfer the IPG product on which the Licensed Software is used, you may transfer the Licensed Software to the end user of the product provided that the end user agrees to be bound by terms no less restrictive than the provisions of this Agreement, and provided that all proprietary markings are maintained. Any other transfer is void and automatically terminates this license. You shall use your best efforts to enforce such agreement and shall promptly report any violation or suspected violation to IPG. In the event you do not enforce such agreement after a breach, you shall, to the extent permissible by applicable law, grant IPG the right to enforce such agreement.

2.3 The Licensed Software may include Third Party Software licensed to IPG in addition to the licenses below. The owner of this Third Party Software (the "Third Party") and its licensors are intended third party beneficiaries of this Agreement, and the provisions of this Agreement relating to the Licensed Software, as the same incorporates Third Party Software, are made expressly for the benefit of, and are enforceable by, the Third Party and its licensors. The Third Party and its licensors retain ownership of all copies of the Third Party Software. The Licensed Software is warranted by IPG in accordance the above Warranty and the Third Party does not provide an additional warranty. **All Third Party Software included in the Licensed Software is provided "AS IS" without warranty from the Third Party, and each Third Party disclaims all warranties, either express or implied, including but not limited to the implied warranties of merchantability, title, non-infringement or fitness for a particular purpose with regard to the Third Party Software. The Third Party shall not have any liability for special, indirect, punitive, incidental or consequential damages.**

2.4 In addition to the IPG Software licensed above, IPG may provide certain files embedded in or to be used on the IPG hardware product which may be subject to the terms of the GNU General Public License (GPL) or the GNU Lesser General Public License (LGPL), the current text of which may be found at: <http://www.gnu.org>, or another open source license. The IPG Software is proprietary software not subject to the GPL or LGPL or other open source license, and Customer has no license to take any action, and shall take no action, which would have the effect of subjecting the IPG Software or any portion of the IPG Software to the terms of the GPL or LGPL or other open source license. Customer may consult the user documentation for identifications and further information.

2.5 For the rights granted in this Agreement, Customer shall pay to IPG the price for the IPG hardware product in which the Licensed Software is embedded.

2.6 You understand that IPG may, at any time and in its sole discretion, update or modify the Licensed Product or discontinue updating and/or supporting the Licensed Product. In the case of an update or modification, you agree to allow IPG to automatically install the Licensed Software on the IPG hardware product on which the Licensed Software is used. Any updated or modified Licensed Product made available and/or installed by IPG on the IPG hardware product shall become part of the Licensed Software and subject to this Agreement.

### **3. TERM AND TERMINATION**

3.1 You may terminate the license granted hereunder at any time by destroying the Licensed Product together with all copies thereof and notifying IPG in writing that all use of the Licensed Product has ceased and that same has been destroyed.

3.2 IPG may terminate this Agreement or any license hereunder upon notice to Customer if Customer breaches any of the terms and conditions of this Agreement or if Customer attempts to assign this Agreement or any license hereunder without IPG's prior written consent. Within twenty (20) days after any termination of this Agreement, Customer shall certify in writing to IPG that all use of the Licensed Product has ceased, and that the same has been destroyed.

3.3 All provisions of this Agreement related to disclaimers of warranty, limitation of liability, IPG's intellectual property rights, or export shall survive any expiration or termination and remain in effect. Termination of this Agreement or any license hereunder shall not relieve Customer of its obligation to pay any and all outstanding charges hereunder nor entitle Customer to any refund of such charges previously paid.

## **B.5 Software License Agreement for LaserNet™**

If your product includes LaserNet™ Software, the following applies:

***IPG Laser GmbH®***

### **Single Use License**

**PLEASE READ THIS SOFTWARE LICENSE AGREEMENT (“LICENSE”) CAREFULLY BEFORE USING THE SOFTWARE OR THE EQUIPMENT. BY CLICKING ON THE “ACCEPT” BUTTON, USING THIS SOFTWARE, OR USING THE EQUIPMENT THAT CONTAINS THIS SOFTWARE, YOU ARE CONSENTING TO BE BOUND BY THIS AGREEMENT. IF YOU DO NOT AGREE TO ALL OF THE TERMS OF THIS AGREEMENT, CLICK THE “DO NOT ACCEPT” BUTTON AND THE INSTALLATION PROCESS WILL NOT CONTINUE, RETURN THE PRODUCT TO THE MANUFACTURER.**

1. **General.** The software, documentation and any fonts accompanying this License whether on disk, in read only memory, on any other media or in any other form (collectively the “IPG Software”) are licensed, not sold, to you by IPG Laser GmbH and its affiliates (“IPG”) for use only under the terms of this License, and IPG reserves all rights not expressly granted to you. The rights granted herein are limited to IPG's and its licensors' intellectual property rights in the IPG Software and do not include any other patents or intellectual property rights. You own the media on which the IPG Software is recorded but IPG and/or IPG's licensor(s) retain ownership of the IPG Software itself. The terms of this License will govern any software upgrades provided by IPG that replace and/or supplement the original IPG Software product, unless such upgrade is accompanied by a separate license in which case the terms of that license will govern.
2. **Permitted License Uses and Restrictions.**
  - a. This License allows you to install and use one copy of the IPG Software on a single computer at a time. This License does not allow the IPG Software to exist on more than one computer at a time, and you may not make the IPG Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the IPG Software in machine-readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.
  - b. Except as and only to the extent permitted in this License and by applicable law, you may not copy, decompile, reverse engineer, disassemble, modify, or create derivative works of the IPG Software or any part thereof. *THE IPG SOFTWARE IS NOT INTENDED FOR USE IN THE OPERATION OF NUCLEAR FACILITIES, AIRCRAFT NAVIGATION OR COMMUNICATION SYSTEMS, AIR TRAFFIC CONTROL SYSTEMS, OR OTHER EQUIPMENT IN WHICH THE MALFUNCTION OF THE IPG SOFTWARE WOULD RESULT IN THE FORESEEABLE RISK OF INJURY OR DEATH TO THE OPERATOR OF THE EQUIPMENT OR SYSTEM OR TO OTHERS.*
3. **Transfer.** You may not rent, lease, lend, redistribute or sub-license the IPG Software. You may, however, make a one-time permanent transfer of all of your license rights to the IPG Software (in its original form as provided by IPG) to another party, provided

that: (a) the transfer must include all of the IPG Software, including all its component parts, original media, printed materials and this License; (b) you do not retain any copies of the IPG Software, full or partial, including copies stored on a computer or other storage device; and (c) the party receiving the IPG Software reads and agrees to accept the terms and conditions of this License.

4. **Termination.** This License is effective until terminated. Your rights under this License will terminate automatically without notice from IPG if you fail to comply with any term(s) of this License. Upon the termination of this License, you shall cease all use of the IPG Software and destroy all copies, full or partial, of the IPG Software.
5. **Limited Warranty on Media.** IPG warrants the media on which the IPG Software is recorded and delivered by IPG to be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of original purchase. Your exclusive remedy under this Section shall be, at IPG's option, replacement of the IPG Software which is returned to IPG or an IPG authorized representative. *THIS LIMITED WARRANTY AND ANY IMPLIED WARRANTIES ON THE MEDIA INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, OF SATISFACTORY QUALITY, AND OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF ORIGINAL PURCHASE.*
6. **Disclaimer of Warranties.** *YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE IPG SOFTWARE IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU. EXCEPT FOR THE LIMITED WARRANTY ON MEDIA SET FORTH ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE IPG SOFTWARE IS PROVIDED "AS IS", WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, IPG AND ITS SUPPLIERS FURTHER DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF TITLE, NON- INFRINGEMENT, ACCURACY, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, AND ANY WARRANTIES THAT MAY ARISE FROM COURSE OF DEALING, COURSE OF PERFORMANCE, OR TRADE PRACTICE. THE ENTIRE RISK ARISING OUT OF THE USE OR PERFORMANCE OF THE IPG SOFTWARE OR RELATED MATERIALS REMAINS WITH YOU. APPLICABLE LAW MAY NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO YOU. IPG MAY MAKE CHANGES TO THE IPG SOFTWARE AND HAS NO OBLIGATION TO DISTRIBUTE NEWER VERSIONS.*
7. **Limitation of Liability.** *NEITHER IPG NOR ANY OF ITS SUPPLIERS SHALL BE RESPONSIBLE OR LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY, PUNITIVE OR OTHER DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS, LOSS OF DATA OR LOST PROFITS), UNDER ANY CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHER THEORY ARISING OUT OF OR RELATING IN ANY WAY TO THE IPG SOFTWARE EVEN IF IPG OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. YOUR SOLE REMEDY FOR DISSATISFACTION WITH THE IPG SOFTWARE IS TO STOP USING THE IPG SOFTWARE. THE SOLE AND EXCLUSIVE MAXIMUM LIABILITY TO IPG FOR ALL DAMAGES, LOSSES AND CAUSES OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE) OR OTHERWISE, SHALL BE THE TOTAL AMOUNT PAID BY YOU, IF ANY, FOR USE OF THE IPG SOFTWARE. THESE LIMITATIONS MAY NOT APPLY TO YOU UNDER THE LAWS OF CERTAIN JURISDICTIONS.*

The foregoing limitations will apply even if the above stated remedy fails of its essential purpose.

8. **Export Law Assurances.** You acknowledge that IPG Software is subject to U.S. and European Union export jurisdiction. You agree to comply with all applicable international and national laws that apply to the IPG Software, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.
9. **Government End Users.** The IPG Software and related documentation are “Commercial Items”, as that term is defined at 48 C.F.R. §2.101, consisting of “Commercial Computer Software” and “Commercial Computer Software Documentation”, as such terms are used in 48 C.F.R. §12.212 or 48 C.F.R. §227.7202, as applicable. Consistent with 48 C.F.R. §12.212 or 48 C.F.R. §227.7202-1 through 227.7202-4, as applicable, the Commercial Computer Software and Commercial Computer Software Documentation are being licensed to U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein. Unpublished-rights reserved under the copyright laws of the United States.
10. **Controlling Law and Severability.** This License will be governed by and construed in accordance with the laws of the State of Massachusetts, as applied to agreements entered into and to be performed entirely within Massachusetts between Massachusetts residents. This License shall not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If for any reason a court of competent jurisdiction finds any provision, or portion thereof, to be unenforceable, the remainder of this License shall continue in full force and effect.
11. **Complete Agreement; Governing Language.** This License constitutes the entire agreement between the parties with respect to the use of the IPG Software licensed hereunder and supersedes all prior or contemporaneous understandings regarding such subject matter. No amendment to or modification of this License will be binding unless in writing and signed by IPG. Any translation of this License is done for local requirements and in the event of a dispute between the English and any non-English versions, the English version of this License shall govern.

## **B.6 Microsoft Corporation Embedded Software End User License Agreement**

If your product includes Microsoft Corporation embedded software, then the following applies:

You have acquired a device (“EQUIPMENT”) that includes software licensed by IPG Photonics Corporation or its affiliates (collectively, “IPG”) from an affiliate of Microsoft Corporation (“MS”). Those installed software products of MS origin, as well as associated media, printed materials, and “online” or electronic documentation (“SOFTWARE”) are protected by international intellectual property laws and treaties. IPG, MS and its suppliers (including Microsoft Corporation) own the title, copyright, and other intellectual property rights in the SOFTWARE. The SOFTWARE is licensed, not sold. All rights reserved.

**IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT (“EULA”), DO NOT USE THE EQUIPMENT OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT IPG FOR INSTRUCTIONS ON RETURN OF THE UNUSED EQUIPMENT(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE OF THE EQUIP-**

**MENT, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).**

This EULA is valid and grants the end-user rights ONLY if the SOFTWARE is genuine and a genuine Certificate of Authenticity for the SOFTWARE is included. For more information on identifying whether your software is genuine, please see <http://www.microsoft.com/piracy/how-totell>.

GRANT OF SOFTWARE LICENSE. This EULA grants you the following license:

1. You may use the SOFTWARE only on the EQUIPMENT.
2. **Restricted Functionality.** You are licensed to use the SOFTWARE to provide only the limited functionality (specific tasks or processes) for which the EQUIPMENT has been designed and marketed by IPG. This license specifically prohibits any other use of the software programs or functions, or inclusion of additional software programs or functions that do not directly support the limited functionality on the EQUIPMENT. Notwithstanding the foregoing, you may install or enable on a EQUIPMENT, systems utilities, resource management or similar software solely for the purpose of administration, performance enhancement and/or preventive maintenance of the EQUIPMENT.
3. If you use the EQUIPMENT to access or utilize the services or functionality of Microsoft Windows Server products (such as Microsoft Windows Server 2003), or use the EQUIPMENT to permit workstation or computing devices to access or utilize the services or functionality of Microsoft Windows Server products, you may be required to obtain a Client Access License for the EQUIPMENT and/or each such workstation or computing device. Please refer to the end user license agreement for your Microsoft Windows Server product for additional information.
4. **NOT FAULT TOLERANT.** THE SOFTWARE IS NOT FAULT TOLERANT. IPG HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE EQUIPMENT, AND MS HAS RELIED UPON IPG TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.
5. **NO WARRANTIES FOR THE SOFTWARE.** THE SOFTWARE is provided "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE EQUIPMENT OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.
6. **No Liability for Certain Damages.** EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).
7. **Restricted Uses.** The SOFTWARE is not designed or intended for use or resale in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or other devices or systems in which a malfunction of the SOFTWARE would result in foreseeable risk of injury or death to the operator of the equipment or system, or to others.
8. **Limitations on Reverse Engineering, Decompilation, and Disassembly.** You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to

the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

9. **SOFTWARE as a Component of the Equipment-Transfer.** This license may not be shared, transferred to or used concurrently on different computers. The SOFTWARE is licensed with the EQUIPMENT as a single integrated product and may only be used with the EQUIPMENT. If the SOFTWARE is not accompanied by EQUIPMENT, you may not use the SOFTWARE. You may permanently transfer all of your rights under this EULA only as part of a permanent sale or transfer of the EQUIPMENT, provided you retain no copies of the SOFTWARE. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE. This transfer must also include the Certificate of Authenticity label. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the SOFTWARE must agree to all the EULA terms.
10. **Consent to Use of Data.** You agree that MS, Microsoft Corporation and their affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. MS, Microsoft Corporation and their affiliates may use this information solely to improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation and their affiliates may disclose this information to others, but not in a form that personally identifies you.
11. **Internet Gaming/Update Features.** If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally identifies you.
12. **Internet-Based Services Components.** The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation or their affiliates may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your EQUIPMENT. Microsoft Corporation or their affiliates do not use these features to collect any information that will be used to identify you or contact you. For more information about these features, please see the privacy statement at <http://go.microsoft.com/fwlink/?LinkId=25243>.
13. **Links to Third Party Sites.** You may link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of MS or Microsoft Corporation, and MS or Microsoft are not responsible for the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites. MS or Microsoft Corporation is not responsible for webcasting or any other form of transmission received from any third party sites. MS or Microsoft Corporation are providing these links to third party sites to you only as a convenience, and the inclusion of any link does not imply an endorsement by MS or Microsoft Corporation of the third party site.
14. **Notice Regarding Security.** To help protect against breaches of security and malicious software, periodically back up your data and system information, use security features such as firewalls, and install and use security updates.
15. **No Rental/Commercial Hosting.** You may not rent, lease, lend or provide commercial hosting services with the SOFTWARE to others.
16. **Separation of Components.** The SOFTWARE is licensed as a single product. Its component parts may not be separated for use on more than one computer.



17. **Additional Software/Services.** This EULA applies to updates, supplements, add-on components, product support services, or Internet-based services components (“Supplemental Components”), of the SOFTWARE that you may obtain from IPG, MS, Microsoft Corporation or their subsidiaries after the date you obtain your initial copy of the SOFTWARE, unless you accept updated terms or another agreement governs. If other terms are not provided along with such Supplemental Components and the Supplemental Components are provided to you by MS, Microsoft Corporation or their subsidiaries then you will be licensed by such entity under the same terms and conditions of this EULA, except that (i) MS, Microsoft Corporation or their subsidiaries providing the Supplemental Components will be the licensor with respect to such Supplemental Components in lieu of the “COMPANY” for the purposes of the EULA, and (ii) TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE SUPPLEMENTAL COMPONENTS AND ANY (IF ANY) SUPPORT SERVICES RELATED TO THE SUPPLEMENTAL COMPONENTS ARE PROVIDED AS IS AND WITH ALL FAULTS. ALL OTHER DISCLAIMERS, LIMITATION OF DAMAGES, AND SPECIAL PROVISIONS PROVIDED BELOW AND/OR OTHERWISE WITH THE SOFTWARE SHALL APPLY TO SUCH SUPPLEMENTAL COMPONENTS. MS, Microsoft Corporation or their subsidiaries reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.
18. **Recovery Media.** If SOFTWARE is provided by IPG on separate media and labeled “Recovery Media” you may use the Recovery Media solely to restore or reinstall the SOFTWARE originally installed on the EQUIPMENT.
19. **Backup Copy.** You may make one (1) backup copy of the SOFTWARE. You may use this backup copy solely for your archival purposes and to reinstall the SOFTWARE on the EQUIPMENT. Except as expressly provided in this EULA or by local law, you may not otherwise make copies of the SOFTWARE, including the printed materials accompanying the SOFTWARE. You may not loan, rent, lend or otherwise transfer the backup copy to another user.
20. **End User Proof of License.** If you acquired the SOFTWARE on a EQUIPMENT, or on a compact disc or other media, a genuine Microsoft “Proof of License”/Certificate of Authenticity label with a genuine copy of the SOFTWARE identifies a licensed copy of the SOFTWARE. To be valid, the label must be affixed to the EQUIPMENT, or appear on IPG's software packaging. If you receive the label separately other than from IPG, it is invalid. You should keep the label on the EQUIPMENT or packaging to prove that you are licensed to use the SOFTWARE.
21. **Product Support.** Product support for the SOFTWARE is not provided by MS, Microsoft Corporation, or their affiliates or subsidiaries. For product support, please refer to IPG support number provided in the documentation for the EQUIPMENT. Should you have any questions concerning this EULA, or if you desire to contact IPG for any other reason, please refer to the address provided in the documentation for the EQUIPMENT.
22. **Termination.** Without prejudice to any other rights, IPG may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.
23. **EXPORT RESTRICTIONS.** You acknowledge that SOFTWARE is subject to U.S. and European Union export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments. For additional information see <http://www.microsoft.com/exporting>.

## C. Product Returns

### C.1 Returns to the United States

All product returns require a Return Merchandise Authorization (RMA) from IPG.

To obtain an RMA, call the Customer Service department of IPG Photonics Corporation at 508-373-1100 (US) or +49 2736 44 20 451 (Germany).

If you return a product with a RMA, please perform the following procedure:

1. Products must be carefully packed in a suitable shipping container(s). Buyer assumes all responsibility for products damaged in shipment to IPG.
2. Buyer must issue a purchase order for the value of the replaced parts/service items and IPG will issue credit or invoice when the parts/service is received. Speak to IPG Service Manager for the amount authorized under the required purchase order.
3. All requests for repair or replacement under this warranty must be made to IPG within 30 days after discovery of the defect (but not later than 7 days after warranty expiration).
4. All products returned to IPG but which meet applicable specifications, not defectively manufactured or used not in accordance with this User's Guide, will result in the Buyer being charged IPG's standard examination charge.
5. Complete packing list with product model and serial number will ensure prompt repair.
6. Be sure to include with the returned product your 'ship to' address for the return of the serviced product.

#### C.1.1 Shipping Instructions:

##### Warranty Returns

Domestic & International Buyers\* pay for one-way freight costs and insurance to IPG. IPG will pay for freight return cost and insurance back to the Buyer.

##### Non-Warranty Returns

Domestic & International Buyers\* pay for two-way freight costs and insurance to IPG. If shipment consists of returns that are both warranty and non-warranty, the shipment will be considered as non-warranty.

Shipping address for returns to US:

IPG Photonics Corporation  
50 Old Webster Road  
Oxford, MA 01540  
Attn: Product Returns  
Tel: 508-373-1100



\* International Returns must include applicable DUTIES AND TAXES. You must mark air bills with "US GOODS, RETURNED FOR REPAIR"

## C.2 Returns to Germany

1. IPG Laser GmbH will only accept returns for which an approved Return Material Authorization (RMA) has been issued by IPG Laser GmbH. You should address to the customer support team at +49-(0)2736-44-20-451 or support.europe@ipgphotonics.com to discuss the return and request an RMA number. You must return defective products freight prepaid and insured to IPG Laser at the address shown herein. All products which have returned to IPG Laser but which are found to meet all previously applicable specifications for such products or which indicate damage to the fiber connectors not resulting from defect manufacturing, shall be subject to IPG Laser' standard examination charge in effect at the time and these costs shall be charged to the Buyer. All products returned to IPG Laser which are not accompanied by an itemized statement of defects, shall be returned to the Buyer at the Buyer's expense and IPG Laser shall not carry out any evaluation of such products. IPG Laser warrants to Buyer that its services, labor and replacement parts, assemblies and modules will be free of defects in material and workmanship for ninety (90) days from the date of shipment or performance of services.
2. Warranty Returns - Domestic & \*International Buyers should pay for one-way freight costs to IPG Laser. IPG Laser will reimburse Buyers for applicable reasonable third-party freight costs and IPG Laser will pay for freight return cost back to the Buyer.
3. Non-Warranty Returns - Domestic & \*International Buyers are responsible for two-way freight costs. If shipment consists of returns that are both warranty and non-warranty, the shipment will be considered as non-warranty. Any UNAUTHORIZED shipments billed to IPG Laser without authorization will be re-invoiced to the Buyer. Confirming purchase orders are required for non-warranty returns.
4. \*International Returns must include applicable DUTIES AND TAXES, and you must mark air bills with "RETURNED FOR REPAIR". In any event, where IPG Laser accepts a shipment, IPG Laser will invoice to the Buyer for any charges as stated above.
5. Returns for credit will not be accepted unless authorized in advance, in writing by IPG Laser, in accordance with IPG Laser' Terms and Condition, including the warranty provisions. In most cases, restocking fees will apply.
6. All returns must be packaged adequately to avoid damage during shipment.
7. Complete packing list with product model and serial number will insure prompt repair, if the other terms of this form are followed.
8. See the IPG Terms and Conditions for the applicable warranty for the products before you request the return of the products.
9. RMA number will expire 31 days after the date of issue. Thereafter, units received in under the expired RMA number will result in a longer turnaround time. Include a copy of the completed RMA form with the return of your unit(s).

### C.2.1 Shipping Instructions:


Shipping address for returns to Germany:

IPG Laser GmbH  
Siemensstrasse 7  
D-57299 Burbach, Germany  
Attn: Product Returns  
Tel: +49-(0)2736-44-20-451

## D. Stage Configuration Software

1. Open the **Stage Configuration Utility**.
2. **Lock** onto the desired scanner.
3. Once the scanner is connected, click on **File** → **Advanced Settings**. This will open the **Advanced Configuration Window**, Figure D.1. Below highlights the important parts of this window.

Figure D.1 Advanced Configuration Window



- a. **Stage2World Transform:** defines the transformation matrix for the software. For On-The-Fly the only parameters that should not be zero are Xx, Yy and Zz. The three non-zero values are the meters per encoder count.
- b. **Rotary Stage:** This is not applicable for encoder applications. All fields should be left as shown in Figure 8.1.
- c. **Stage Parameters:**
  - i. **Pulse Width:** not applicable for encoder input.
  - ii. **Count Min/Max:** defines the process area in pulse units.
  - iii. **Count Wrap:** Distance in encoder pulses before the software “Wraps” the weld.
  - iv. **Velocity Max:** not applicable for encoder input.
  - v. **Velocity Home:** when using the simulate encoder, Velocity Home defines the encoder velocity in pulses/sec.
  - vi. **Velocity Track:** not applicable for encoder input.
  - vii. **Accel Max / Accel Track:** not applicable for encoder input.
  - viii. **Home Sensor:** If the encoder reset signal is single ended, Single Ended flag should be checked, otherwise encoder reset is assumed differential. Active Low: if single ended, this flag indicated if the sensor is active low.
  - ix. **Signal Type & Direction:** Encoder input works in quadrature mode by definitions so Quadrature must be selected. Reverse direction is not applicable for encoder input.
  - x. **Controller Settings:** Output enable flag must be off so the controller will read encoder signals. Clear Enable is optional; as it clears position count

when the encoder reset pulse is detected. Auto Wrap is optional; as it wraps the position count if the encoder pulse count is equal to Count Max.

- xi. **Software Init Flags:** The only applicable flag is Simulate encoder which ensures that a simulated encoder signal (count settings taken from Stage2WorldTransform) is initiated when the software starts. Other flags not applicable for encoder input.
- d. **Coordination Mode:**
  - i. **Coordination Off:** When checked, coordination with external motion is disabled.
  - ii. **Stage Tracking:** When checked, enabled coordination with external motion control. This setting must be selected when using On-The-Fly.
  - iii. **Robot Tracking:** used with robot motion. Not applicable for encoder input.
- e. **InView & InViewHysteresis:** Controls the size of the volume in which the scanner mirrors are allowed to move when Stage Tracking is enabled.

**Note:** For Most 2D applications, InView X and Y should be set from  $-\frac{1}{4}$  of the lens's optical field to  $+\frac{1}{4}$  of the lens's optical field. The InViewHysteresis should be set to  $-\frac{1}{2}$  of the lens's optical field to  $+\frac{1}{2}$  of the lens's optical field. For the Z setting, the same rule applies, however the focal depth (not the lens's optical field) is used.

- f. **Flags:**
  - i. **Wait in View & Use Stage:** enables or disabled each axis for encoder input. For most applications Wait in View should be checked anytime Use Stage is checked.
  - ii. **Wait Position Reset:** for a moving target, waits until mirrors reset their position before outputting the next vector. Must be on for On-The-Fly.
  - iii. **Stage Master:** informs the software whether to control external motion or not. Must be off for On-The-Fly since an encoder is controlling the software (software must be controlled externally).
  - iv. **Split Long Vectors:** if enabled, vectors that are longer than the area specified by the InView, will be split into multiple vectors that will fit the InView window. Must be checked for On-The-Fly.
  - v. **Return to Zero:** Not applicable for On-The-Fly.
  - vi. **Auto Reset Tracking:** automatically resets encoder tracking when laser is enabled. Should be off when using IPGScan.
- g. **Wait Events:** are not related to On-The-Fly specifically, but are included for convenience. Wait Event Flags are used to set up the behavior of the general I/O's for the scanner controller, including external start.
- h. **Polarity:** defines if the signal is active high or active low. This system is active high by default.
- i. **Edge/Level:** defines how the signal becomes active. Default is Level, where signal is active anytime input voltage exceeds threshold level. Edge option is where the signal becomes active anytime a transition from low to high is detected.

Note: Threshold is determined by the board being used. See 2D Scanner manual for this information.

# Glossary

**2D** - Two dimensional.

**DXF** - CAD file format.

**exe** - executable file format.

**I/O** - Input/Output.

**OTF** - On The Fly.

**STL** - CAD file format.

**TCP** - in reference to the robot, Tool Point Center.

**TCP/IP** - Communication methods; Transmission Control Protocol / Internet Protocol.





To learn more, visit [www.ipgphotonics.com](http://www.ipgphotonics.com)

© Copyright 2016 IPG Photonics Corporation

This user guide and any data disclosed therein is the property of IPG Photonics Corporation and its affiliates, and constitutes and contains proprietary information. Neither receipt nor possession of this document confers or transfers any right to duplicate, use, or disclose any information contained herein except as expressly authorized in writing by IPG Photonics